Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UltraPoi OrbPoi Pro

UltraPoi OrbPoi Pro Set Instruction Manual

Model: OrbPoi Pro
Brand: UltraPoi

1. Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your UltraPoi OrbPoi Pro Set. This set includes LED Contact Poi Balls with UltraKnob Pro Handles, designed for flow arts enthusiasts of all skill levels. Please read this manual thoroughly to ensure proper use and enjoyment of your product.



Image 1.1: UltraPoi OrbPoi Pro Set with LED UltraKnob Pro Handles.

2. What's Included

Your UltraPoi OrbPoi Pro Set comes with the following components:

- 2x OrbPoi Cases
- 2x Ultra Knob
- 2x UltraKnob Pro LED Shells
- 2x OrbPoi Pro LED Shells
- 1x Braided Rope
- 1x S-Hook Clip
- 2x Dual Head Micro USB Cable
- 1x Gear Bag
- 1x Instruction & Color Guide



Image 2.1: All components included in the UltraPoi OrbPoi Pro Set.




Image 2.2: Detailed view of OrbPoi Pro components.

3. Setup

3.1 Charging the OrbPoi Pro

The OrbPoi Pro features rechargeable batteries. To charge, gently push the rope towards the ball to expose the plastic orb shell. You can also pull on the shell from the other side. Once the Micro USB port is exposed, plug in the provided dual-head Micro USB cable. The UltraKnob Pro LED handles are charged in the same manner.

3.2 Adjusting Rope Length

The braided rope can be adjusted to your desired length. To do this, expose the plastic shell of the poi (as described for charging). Then, pull the entire shell out. Remove the O-rings to separate the shell. You can then use the extra rope provided to customize the length. Measure your desired length, cut the rope with sharp scissors, and heat the tip with a lighter to form a melted cap on the end. Use the original ropes as a guide for setup.

3.3 Video Guide: Setup & Features

Your browser does not support the video tag.

Video 3.1: This video demonstrates the setup, charging, button controls, and rope adjustment for the UltraPoi OrbPoi Pro Set.

4. Operating Instructions

The OrbPoi Pro features intuitive button controls for managing color modes and flash patterns. The controls for both the poi heads and the handles operate identically.

4.1 Power On/Off (Button Lock Feature)

- **To Turn On:** Click the button twice within a 3-second window. This

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09LWPKSLZ

More documents and user manuals: **https://manuals.plus/**