

[Manuals.plus](#) /

> [BERIBES](#) /

> BERIBES Bluetooth Headphones Over Ear, 65H Playtime and 6 EQ Music Modes Wireless Headphones with Microphone, HiFi Stereo Foldable Lightweight Headset, Deep Bass for Home Office Cellphone PC Ect.

BERIBES

BERIBES Bluetooth Headphones

Instruction Manual

1. PRODUCT OVERVIEW

The BERIBES Bluetooth Headphones are designed to provide a high-quality audio experience with exceptional comfort and extended battery life. Featuring advanced Bluetooth 5.3 technology and multiple EQ sound modes, these headphones are suitable for various activities, from listening to music to making calls.



Image: The BERIBES Bluetooth Headphones in black, showcasing their sleek over-ear design.

2. WHAT'S IN THE BOX

- 1 x BERIBES Wireless Bluetooth Headphone
- 1 x USB Type-C Charging Cable
- 1 x 3.5mm Audio Cable (for wired mode)
- 1 x User Manual

3. SETUP GUIDE

3.1 Charging the Headphones

Before first use, fully charge your BERIBES headphones. A full charge takes approximately 2.5 hours. The built-in 500mAh battery provides over 65 hours of continuous playtime and more than 950 hours of standby time.

1. Connect the supplied USB Type-C charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a compatible USB power source (e.g., wall adapter, computer USB port).
3. The LED indicator will show the charging status. Refer to the LED Indicator section for details.



Image: Visual representation of the BERIBES headphones' extended battery life, highlighting 65 hours of music time and 950 hours of standby time.

3.2 Bluetooth Pairing

The headphones feature the latest Bluetooth 5.3 chip for fast and stable connections up to 33 feet (10 meters). They can connect to two smart devices simultaneously, allowing seamless switching between them.


1. Ensure the headphones are powered off.
2. Press and hold the Multi-Function Button until the LED indicator flashes, indicating pairing mode.
3. On your device (smartphone, PC, etc.), enable Bluetooth and search for available devices.
4. Select "BERIBES WH202A" from the list of found devices.
5. Once connected, the LED indicator will change (refer to the LED Indicator section).



Image: A visual representation of the advanced Bluetooth 5.3 chip, emphasizing low latency, low power consumption, and signal stability.

4. OPERATING INSTRUCTIONS

4.1 Controls Overview



**Enjoy
Extraordinary
Sound Quality**

Image: A person wearing BERIBES headphones, illustrating the enjoyment of extraordinary sound quality.

Button/Interface	Function
Multi-Function Button	Power On/Off, Play/Pause, Answer/End Call, Enter Pairing Mode
Volume Up / Next Track (+)	Short press: Next Track; Long press: Volume Up
Volume Down / Previous Track (-)	Short press: Previous Track; Long press: Volume Down
EQ Button	Cycle through 6 EQ Music Modes
3.5mm Audio Interface	Connect for wired audio playback
Type-C Charging Interface	Connect for charging
Microphone	For hands-free calls
LED Indicator	Displays power, pairing, and charging status

4.2 Music Playback and EQ Modes

The headphones feature dual 40mm dynamic sound units and 6 selectable EQ modes to customize your listening experience.

- **Playing Music:** After successful Bluetooth pairing, start playback on your connected device. Use the Multi-Function Button to Play/Pause.
- **Changing Tracks:** Short press the '+' button for the next track, and the '-' button for the previous track.
- **Adjusting Volume:** Long press the '+' button to increase volume, and the '-' button to decrease volume.
- **EQ Modes:** Press the EQ Button to cycle through the 6 available sound modes: Pop, Rock, Vocal, Jazz, BassUp, and Classic. Choose the mode that best suits your music genre.



Image: Illustration showing the BERIBES headphones' multiple sound effects, including Pop, Rock, Vocal, Jazz, BassUp, and Classic EQ modes.

4.3 Call Functions

The integrated microphone allows for clear hands-free calls.

- **Answering/Ending Calls:** Press the Multi-Function Button once to answer an incoming call or end an ongoing call.
- **Rejecting Calls:** Press and hold the Multi-Function Button for 2 seconds to reject an incoming call.

- **Voice Assistant:** Double-press the Multi-Function Button to activate your device's voice assistant (e.g., Google Assistant, Hey Siri).

4.4 Wired Mode

When the battery is low or if you prefer a wired connection, use the included 3.5mm audio cable.

1. Plug one end of the 3.5mm audio cable into the headphone's 3.5mm audio interface.
2. Plug the other end into your audio source's 3.5mm jack.
3. The headphones will automatically switch to wired mode. Note that controls on the headphones may be limited in wired mode, and audio adjustments will primarily be done via the connected device.

5. MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. For ear pads, gently wipe with a damp cloth and allow to air dry completely. Avoid harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the headphones in a cool, dry place. The foldable design allows for compact storage.
- **Water Resistance:** The headphones are waterproof. However, avoid prolonged submersion in water. Ensure the charging port is dry before charging.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in constant use.

Comfort for hours

suitable for long time wearing and convenient to carry everywhere



Rotatable 90°



Adjustable Headband



90° Swirling

Image: Features contributing to comfort, including 90-degree rotatable earcups, an adjustable headband, and 90-degree swiveling for a comfortable fit during long periods of use.

6. TROUBLESHOOTING

Problem	Possible Solution
Headphones do not power on.	Ensure the headphones are charged. Connect to a power source using the Type-C cable.
Cannot pair with device.	Ensure headphones are in pairing mode (flashing LED). Turn off and on Bluetooth on your device. Move headphones closer to the device. Clear previous Bluetooth connections on your device.
No sound or low volume.	Check volume levels on both headphones and the connected device. Ensure headphones are properly paired. Try playing different audio sources. If in wired mode, ensure the 3.5mm cable is fully inserted.

Problem	Possible Solution
Sound quality is poor.	Try switching between the 6 EQ modes. Ensure there are no obstructions between the headphones and the device. Move away from sources of interference (e.g., Wi-Fi routers, other Bluetooth devices).
Microphone not working.	Ensure the headphones are connected via Bluetooth. Check microphone settings on your connected device.
Headphones disconnect frequently.	Ensure the headphones are within the 33ft (10m) Bluetooth range. Avoid physical obstructions. Ensure the battery is sufficiently charged.

7. SPECIFICATIONS

Feature	Detail
Model Name	WH202A
Connectivity Technology	Wireless (Bluetooth), Wired (3.5mm Jack)
Wireless Communication Technology	Bluetooth 5.3
Bluetooth Range	10 Meters (33 feet)
Battery Life	65 Hours (Playtime)
Standby Time	950 Hours
Charging Time	2.5 Hours
Audio Driver Size	40 Millimeters
Frequency Range	20 Hz - 30000 Hz
Impedance	32 Ohms
Sensitivity	116.4 dB
Noise Control	Sound Isolation
Control Method	Buttons
Water Resistance Level	Waterproof
Item Weight	6.08 ounces (0.38 lbs)
Material	Plastic (Headphones), Memory Protein (Earmuffs)
Color	Black

8. WARRANTY AND SUPPORT

BERIBES provides comprehensive after-sale protection for your headphones:

- **Return Policy:** 30-day return period from the date of purchase.
- **Warranty:** 12-month warranty covering manufacturing defects.
- **User Support:** Lifetime worry-free user support. For any questions or issues regarding the product, please contact BERIBES customer service. We aim to reply within 10 hours.

For support, please refer to the contact information provided on the product packaging or the official BERIBES website.