

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Porodo PD-STWLEP006

Porodo Soundtec Wireless ANC In-Ear Earbuds

Model: PD-STWLEP006

INTRODUCTION

Thank you for choosing the Porodo Soundtec Wireless ANC In-Ear Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

SAFETY INFORMATION

To prevent damage to your device or injury to yourself or others, please read all safety information before using the device.

- Do not disassemble, repair, or modify the earbuds or charging case.
- Keep the device away from water, moisture, and other liquids.
- Avoid exposing the device to extreme temperatures (below 0°C or above 45°C).
- Do not use the device during a thunderstorm to avoid electric shock or device malfunction.
- Clean the earbuds and charging case with a soft, dry cloth only.
- Prolonged exposure to high volume levels may cause hearing damage. Adjust volume to a safe level.

PACKAGE CONTENTS

Ensure all items are present in your package:

- Porodo Soundtec Wireless ANC In-Ear Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual
- Multiple Sizes of Eartips

PRODUCT OVERVIEW

Familiarize yourself with the components of your Porodo Soundtec Earbuds.



Figure 1: Earbuds seated in their charging case, showing the overall design and charging indicators.



Figure 2: Individual earbuds, highlighting their ergonomic design and touch control areas.



Figure 3: The compact charging case in a closed position, showing its sleek finish and LED indicators.




Figure 4: Earbuds worn by a user, demonstrating their comfortable and secure fit for active use.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

- **Charging the Case:** Connect the USB charging cable to the charging port on the case and a power source. The LED indicators on the case will show charging status.
- **Charging the Earbuds:** Place the earbuds into the charging case. Ensure they are properly seated. The earbuds will automatically begin charging. The LED indicators on the earbuds (if present) or case will indicate charging.
- **Wireless Charging:** The charging case supports wireless charging. Place the case on a compatible wireless charging pad.

2. Pairing with Your Device (Bluetooth)

Follow these steps to connect your earbuds to a Bluetooth-enabled device:

1. Ensure the earbuds are fully charged.
2. Open the charging case. The earbuds will automatically enter pairing mode (indicated by flashing LED lights on the earbuds).
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn Bluetooth ON.
4. Search for available devices. Select "Porodo Soundtec" from the list.
5. Once connected, the earbud LEDs will stop flashing or turn off, and you will hear a confirmation tone.
6. If pairing fails, place the earbuds back in the case, close the lid, wait a few seconds, and then repeat the steps.

OPERATING INSTRUCTIONS

Touch Controls

The Porodo Soundtec Earbuds feature intuitive touch controls on each earbud. The specific functions may vary slightly, but common controls include:

Action	Function
Single Tap (Left/Right)	Play/Pause music, Answer/End call
Double Tap (Right)	Next Track

Action	Function
Double Tap (Left)	Previous Track
Triple Tap (Right)	Volume Up
Triple Tap (Left)	Volume Down
Long Press (2 seconds)	Activate Voice Assistant (Siri, Google Assistant)
Long Press (3 seconds)	Toggle ANC/Transparency Mode
Long Press (during incoming call)	Reject Call

Active Noise Cancellation (ANC)

The earbuds feature Active Noise Cancellation to reduce ambient noise and Transparency Mode to allow you to hear your surroundings.

- To toggle between ANC On, Transparency Mode, and ANC Off, long press the touch control area on either earbud for approximately 3 seconds.
- A voice prompt will confirm the mode change.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds, especially the eartips and charging contacts, with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, always store the earbuds in their charging case to protect them from dust, dirt, and physical damage.
- **Battery Care:** To preserve battery life, avoid fully discharging the earbuds or case frequently. Charge them regularly, even if not in constant use.
- **Avoid Extreme Conditions:** Do not expose the earbuds to extreme temperatures, direct sunlight, or high humidity.

TROUBLESHOOTING

If you encounter issues with your earbuds, try the following solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close, then reopen. Turn off and on Bluetooth on your device. Forget "Porodo Soundtec" from your device's Bluetooth list and re-pair.
Only one earbud working	Ensure both earbuds are charged. Place both earbuds back in the case, close the lid, then reopen. Check if both earbuds are properly connected to your device.
No sound	Check device volume. Ensure earbuds are connected. Try playing different audio.
Poor sound quality	Ensure earbuds are clean. Try different eartip sizes for a better seal. Move closer to your device to avoid interference.

Problem	Solution
Earbuds not charging	Ensure charging cable is securely connected. Check charging contacts on earbuds and case for debris. Try a different charging cable or power source. Ensure wireless charging pad is compatible and properly aligned.

SPECIFICATIONS

Key technical specifications for the Porodo Soundtec Wireless ANC In-Ear Earbuds:

Feature	Detail
Model Name	PD-STWLEP006
Connectivity Technology	Wireless (Bluetooth 5.0)
Noise Control	Active Noise Cancellation (-24dB)
Ear Placement	In Ear
Control Type	Touch Controls
Charging	Wired (USB), Wireless Charging
Product Dimensions	4.93 x 2.24 x 4.75 cm
Item Weight	80 g
Manufacturer	PORODO

WARRANTY AND SUPPORT

Porodo products are designed with quality and reliability in mind. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Porodo website.

Official Porodo Website: [Visit Porodo Store on Amazon.ae](https://www.amazon.ae)

© 2024 Porodo. All rights reserved.

This manual is subject to change without notice.

Documents - Porodo – PD-STWLEP006



[\[pdf\]](#) Accessories Catalog

Porodo Product Catalogue 2022 221008054246 oskarne assets o brand catalogue |||

Product Catalogue 2022 Porodo was launched in 2014 with the aim of providing the latest in mobile ... e PD-STWLEP001 Porodo Soundtec FM Wireless Over-Ear Headphone PD-STWLEP005 Kid s Wireless Earbuds **PD-STWLEP006** Wireless ANC Earbuds PD-TWSAPP-WH Porodo Soundtec Wireless Earbuds Pro - White PD-S... lang:tl score:27 filesize: 11.19 M page_count: 109 document date: 2022-10-08



[\[pdf\]](#) Accessories Catalog

Porodo Product Catalogue 2022 8 oct — Silicone Sport Watch Band For Apple 42 44mm PDSILNS44

Nike Strap PD STWLEP007 Soundtec Airpods 4th Gen 221010092034 oskarne assets o brand catalogue Brand s Catalogs Porodowaslaunchedin2014withtheaimof

providingthelatestinmobileaccessoriesatan affordablepricewithoutcompromisingon quality

Throughourrigorousdesignand |||

Product Catalogue 2022 Porodo was launched in 2014 with the aim of providing the latest in mobile ... e PD-STWLEP001 Porodo Soundtec FM Wireless Over-Ear Headphone PD-STWLEP005 Kid s Wireless Earbuds **PD-STWLEP006** Wireless ANC Earbuds PD-TWSAPP-WH Porodo Soundtec Wireless Earbuds Pro - White PD-S... lang:tl score:25 filesize: 5.35 M page_count: 109 document date: 2022-10-10