Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Balsam Hill 2809422

Balsam Hill 7.5ft Pre-Lit Classic Blue Spruce Artificial Christmas Tree Instruction Manual

Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and storage of your Balsam Hill 7.5ft Pre-Lit Classic Blue Spruce Artificial Christmas Tree. This tree features 2,960+ meticulously crafted tips and 1,000 hand-strung Clear LED lights, designed for a realistic appearance and convenient setup.

What's in the Box

- 7.5ft Classic Blue Spruce Artificial Christmas Tree sections
- Durable Christmas Tree Stand
- Easy Plug Lighting System (integrated)
- Christmas Tree Storage Bag
- Cotton Fluffing Gloves
- Extra Bulbs
- On/Off Foot Pedal (for Clear LED models)



Figure 1: Contents of the Balsam Hill Christmas Tree box. Includes tree sections, a durable stand, a storage bag, cotton fluffing gloves, extra bulbs, and an on/off foot pedal.

Setup Instructions

Follow these steps to assemble your artificial Christmas tree. It is recommended to wear the provided cotton fluffing gloves during assembly to protect your hands and shape the branches.

Step-by-Step Assembly

1. **Assemble the Tree Stand:** Unfold the durable metal tree stand into an X-shape and ensure it is stable. Tighten the eye bolt to secure the base.
2. **Insert Tree Section 1 (Bottom):** Carefully insert the bottom tree section into the assembled stand. Ensure it is firmly seated.
3. **Fluff Branches (Bottom Section):** Starting from the trunk and working outwards, gently spread and shape the branches of the bottom section. Ensure all individual branch tips are fanned out to create a full appearance.

4. **Insert Tree Section 2 (Middle):** Place the middle tree section onto the bottom section. The Easy Plug technology will automatically connect the lights as sections are stacked.
5. **Fluff Branches (Middle Section):** Repeat the fluffing process for the middle section, ensuring branches are spread evenly.
6. **Insert Tree Section 3 (Top):** Place the top tree section onto the middle section. The lights will connect automatically.
7. **Fluff Branches (Top Section):** Complete the fluffing process for the top section, paying attention to the tree's peak.
8. **Connect to Power:** Plug the single power cord from the tree's base into a wall outlet. Use the included foot pedal to easily turn the lights on and off.



Figure 2: Easy Setup - Tree sections click together, and lights connect automatically through the trunk with Easy Plug technology.



Figure 3: Easy Assembly and Shaping - Visual guide for unfolding the stand, inserting sections, and fluffing branches.

Setup Demonstration Video

Video 1: A demonstration of the Balsam Hill 7.5 ft Christmas Tree assembly process, including insights and tips.

Video 2: Watch how easy it is to set up this Balsam Hill tree, highlighting the simplicity of the assembly process.

Operating Your Tree

Lighting Features

Your Balsam Hill tree is pre-lit with 1,000 hand-strung, UL Certified Clear LED lights. These lights provide a warm, inviting glow and are designed for durability and energy efficiency. The hand-strung design helps to reduce the appearance of wires, contributing to a more natural look.



Figure 4: Hand-Strung Lights - Close-up view of the carefully placed Clear LED lights for a balanced and festive glow.

Easy Plug Technology

The innovative Easy Plug system simplifies tree assembly by integrating light connections directly within the tree's trunk. This means you only need to connect a single plug to a wall outlet, eliminating the need to manually connect multiple light strands between sections.

Foot Pedal Control

An on/off foot pedal is included with your tree for convenient control of the lights. Simply step on the pedal to turn the lights on or off.

Maintenance

Fluffing and Shaping

Upon initial setup and after storage, your tree will require fluffing to achieve its full, natural appearance. Wear the provided cotton gloves and gently spread each branch and individual tip, working from the trunk outwards and from the bottom

sections upwards. Bend the tips to fill any gaps and create a dense silhouette. First-time shaping may take over an hour to achieve the desired fullness.

Light Bulb Replacement

Your tree comes with extra bulbs. If a light bulb burns out, carefully remove it and replace it with a new one from the spare parts provided. The UL Certified LED lights are designed for longevity, but occasional replacement may be necessary.

Storage

Proper storage of your Balsam Hill tree ensures its longevity and ease of setup for future seasons. The less compressed the tree is during storage, the less work will be required for fluffing next year.

Disassembly Steps

1. **Unplug and Remove Ornaments:** Ensure the tree is unplugged from the wall outlet. Carefully remove all ornaments and decorations.
2. **Dismantle Sections:** Starting from the top, carefully lift each tree section off the one below it. The hinged branches will fold upwards for easier handling.
3. **Store in Bag:** Place each dismantled section into the provided Christmas tree storage bag. If the ribbon that came with your tree is still available, use it to tie up the branches before folding them back up to minimize compression.
4. **Store Stand:** Fold the tree stand and place it in the storage bag along with the tree sections.
5. **Choose a Cool, Dry Location:** Store the bag in a cool, dry place away from direct sunlight or extreme temperatures.



Figure 5: Easy Storage - Tree sections are neatly packed into the durable storage bag for off-season protection.

Troubleshooting

Lights Not Working

- **Check Connections:** Ensure all tree sections are properly seated and the Easy Plug connections are secure.
- **Power Source:** Verify the tree is plugged into a working electrical outlet and the foot pedal is engaged.
- **Individual Bulbs:** Check for any loose, broken, or missing bulbs. Replace any faulty bulbs with the provided spares.
- **Fuses:** Inspect the fuses in the plug. Replace if necessary.

Tree Instability

- **Stand Assembly:** Ensure the tree stand is fully unfolded and the eye bolt is tightened securely.
- **Section Seating:** Verify that all tree sections are fully inserted and seated correctly into each other and the stand.

Specifications

Feature	Detail
Brand	Balsam Hill
Model Number	2809422
Product Dimensions	60"D x 60"W x 90"H (7.5ft tall)
Color	Clear LED
Material	Metal, Polyvinyl Chloride
Item Weight	50.4 Pounds
Tip Count	2960
Light Count	1000
Light Type	Pre-Lit Clear LED
Base Type	Stand
UPC	196041202265

Warranty and Support

Your Balsam Hill Christmas tree is designed for quality and durability. For any product-related inquiries or support, please contact Balsam Hill customer service.

This product is returnable until January 31, 2026. For detailed return policies and customer support, please visit the Balsam Hill Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09M1M6VKS

More documents and user manuals: **https://manuals.plus/**