

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HUYVMAY](#) /

› [HUYVMAY Fitness Tracker T6F User Manual](#)

HUYVMAY T6F

HUYVMAY Fitness Tracker T6F User Manual

Model: T6F

1. PRODUCT OVERVIEW

The HUYVMAY Fitness Tracker T6F is a versatile activity tracker designed for children and women. It features a clear LED display and offers multiple functions without requiring a smartphone application or Bluetooth connection. Its simple operation makes it suitable for users seeking a straightforward fitness monitoring device.

Multifunctional Fitness Watch



Image: The HUYVMAY Fitness Tracker T6F displaying its various functions including pedometer, calories, distance, IP68 waterproof rating, time/date, 3 alarm clocks, 21-day runtime, stopwatch, and USB charging.

Key Features:

- Time, Date, and Week Display
- Pedometer (Step Counter)
- Distance Tracking
- Calorie Counter
- 3 Alarm Clocks with Vibration
- Stopwatch Function
- IP68 Waterproof Rating
- Direct USB Charging
- Long Battery Life (up to 20 days)

2. SETUP

2.1 Charging the Device

Before initial use, fully charge your fitness tracker. The device features a built-in USB plug for direct charging.

1. Gently remove the strap from one side of the watch face to reveal the USB charging connector.
2. Insert the USB connector into any standard USB port (e.g., computer, wall adapter, power bank).
3. Charge the device for approximately 1 hour. A full charge typically provides over 20 days of use.

USB Charge & 20 Days Runtime

no need charging cable, directly plug in any USB ports, plug and play




Image: The fitness tracker connected directly to a power bank via its integrated USB connector for charging.

2.2 Initial Power On and Display Activation

To conserve energy, the display does not remain constantly active. To view information, press button A located on the side of the watch.

2.3 Setting Time, Date, and User Data

The fitness tracker allows for setting the current time, date, and personal user data (such as weight and height) to ensure accurate tracking of steps, distance, and calories. Specific instructions for navigating the settings menu are typically found in the detailed manual provided with the product. Generally, this involves pressing and holding button A to enter setting mode and then using short presses to adjust values and confirm selections.

Pedometer Function

You can click a button to zero the data to re-count any time

Note: to get accurate steps/distance/calories burned data, please refer to user manual to set user's correct weight and height in watch



Image: A HUVMAY Fitness Tracker T6F on a wrist, displaying the pedometer function. Icons below indicate time/date, pedometer, alarming clock, stopwatch, and IP68 waterproof features.

3. OPERATING INSTRUCTIONS

3.1 Navigating Functions

The fitness tracker operates using a single button (Button A). Short presses of Button A will cycle through the main functions:

- Time/Date/Week display
- Pedometer (Steps)
- Distance
- Calories Burned
- Alarm Clock
- Stopwatch

3.2 Pedometer and Activity Tracking

The device automatically tracks your steps, calculates distance, and estimates calories burned throughout the day. To reset the pedometer data, typically a long press on Button A while on the pedometer screen

will zero out the current day's data, allowing you to start a new count at any time.

3.3 Setting and Using the Alarm Clock

The fitness tracker includes up to three vibrating alarm clocks. To set an alarm:

1. Cycle to the Alarm Clock function using Button A.
2. Press and hold Button A to enter alarm setting mode.
3. Use short presses of Button A to adjust the hour and minute, and long presses to confirm and move to the next setting.
4. Once set, the watch will vibrate at the designated time. The vibration is designed to be noticeable to the wearer without disturbing others.



Image: A HUYVMAY Fitness Tracker T6F on a wrist, illustrating the vibrating alarm clock feature with subtle wave graphics.

3.4 Using the Stopwatch

To use the stopwatch function:

1. Cycle to the Stopwatch function using Button A.
2. Press and hold Button A to start the stopwatch.
3. A short press will pause/resume the stopwatch.

4. A long press will reset the stopwatch to zero.

3.5 Water Resistance (IP68)

The device has an IP68 waterproof rating, meaning it is resistant to dust and can withstand immersion in water up to 1.5 meters for up to 30 minutes. This allows for use during hand washing, in the rain, showering, and swimming for 1 to 2 hours. However, it is important to avoid exposure to hot water, as this can compromise the waterproof seals.



Image: Two HUYVMAY Fitness Trackers, one black and one pink, shown with water droplets, emphasizing their IP68 waterproof capability for activities like washing hands, rain, showering, and swimming.

3.6 Clear Display

The LED display provides clear visibility of information, even in low-light conditions or darkness.

Clear Display Even In The Dark



Image: The HUYVMAY Fitness Tracker T6F display illuminated and clearly visible in a dark environment.

4. MAINTENANCE

4.1 Cleaning

To maintain the device's appearance and hygiene, regularly clean the watch face and silicone strap. Use a soft, damp cloth to wipe away dirt or sweat. Avoid using harsh chemicals or abrasive materials, as these can damage the device.

4.2 Charging Practices

Ensure the USB charging port is clean and dry before charging. Charge the device fully when the low battery indicator appears to prolong battery life.

4.3 Water Resistance Care

While the device is IP68 waterproof, avoid exposing it to hot water, steam, or prolonged submersion beyond the recommended limits. After swimming or exposure to chlorinated/salt water, rinse the watch with fresh water and dry it thoroughly.

4.4 Storage

When not in use for extended periods, store the fitness tracker in a cool, dry place away from direct sunlight and extreme temperatures. It is advisable to charge the device periodically (e.g., every few months) even when stored, to prevent deep discharge of the battery.

5. TROUBLESHOOTING

If you encounter issues with your HUYVMAY Fitness Tracker T6F, please refer to the following common solutions:

- **Device not turning on or charging:** Ensure the USB connector is fully inserted into a functional USB port. Charge for at least 1 hour. If the issue persists, try a different USB port or charging adapter.
- **Display not activating:** Press Button A firmly. The display is designed to turn off to save power.
- **Inaccurate step, distance, or calorie readings:** Verify that your personal weight and height settings are correctly entered into the device. Refer to the detailed manual for instructions on adjusting these settings.
- **Strap tearing or damage:** The silicone strap is designed for comfort and durability, but excessive force or sharp objects can cause damage. Handle the strap gently when putting on or taking off the watch. Replacement straps may be available from the manufacturer or seller.
- **Water ingress:** Although IP68 rated, exposure to hot water or prolonged submersion beyond specified limits can cause damage. Ensure the device is not exposed to conditions outside its rating.

6. SPECIFICATIONS

Brand	HUYVMAY
Model Number	T6F
Display Type	LED
Screen Size	32 Millimeters
Shape	Round
Connectivity Technology	USB (No App, No Bluetooth required)
Water Resistance	IP68 (Suitable for swimming 1-2 hours, avoid hot water)
Battery Type	Lithium-ion / Lithium-polymer
Battery Life (Typical)	Up to 20 days
Charging Time	Approximately 1 hour
Functions	Pedometer, Distance, Calories, 3 Alarms, Stopwatch, Time/Date/Week
Product Dimensions (L x W x H)	22.86 x 3.4 x 1.24 cm
Product Weight	30.62 grams (1.08 Ounces)
Strap Material	Silicone

Intended Age Group

Children, Women



Les bracelets de montre s'adaptent aux circonférences du poignet : 145 ~ 200 mm

Image: A diagram illustrating the dimensions of the fitness tracker (30mm width) and the adjustable wrist circumference range of 145-200 mm.

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your product or contact the seller directly. The seller for this product is HuiRuiYuan. Please retain your proof of purchase for any warranty claims.