



Manuals.plus /

› KEMEI /

› KEMEI KM-5031 Multi-use 11-in-1 Electric Shaving Machine User Manual

KEMEI KM-5031

KEMEI KM-5031 Multi-use 11-in-1 Electric Shaving Machine User Manual

Brand: KEMEI | Model: KM-5031

INTRODUCTION

Thank you for choosing the KEMEI KM-5031 Multi-use 11-in-1 Electric Shaving Machine. This versatile grooming kit is designed for men, offering a comprehensive solution for various shaving and trimming needs. With multiple interchangeable heads and guide combs, it provides precision and convenience for facial hair, body grooming, and more. Please read this manual thoroughly before first use to ensure safe and optimal performance of your device.

SAFETY INFORMATION

CAUTION: Use with caution to avoid cuts. Do not use near water or while charging. Clean after each use to prevent bacterial growth. Keep out of reach of children.

Always ensure the device is switched off before attaching or detaching any accessories. Do not attempt to repair the device yourself; contact qualified personnel for service. Store the device in a dry place when not in use.

PACKAGE CONTENTS

The KEMEI KM-5031 grooming kit includes the following items:

- Main Trimmer Unit
- Full Size Trimmer Head
- Precision Trimmer Head
- Shaver Head (2 units)
- Nose Trimmer Head
- Design Trimmer Head
- Various Guide Combs (for different cutting lengths)

- Cleaning Brush
- Lubricating Oil
- Charging Cable (USB)
- Hair Comb
- Charging Stand



Image: All components of the KEMEI KM-5031 grooming kit, including the main unit, various trimmer heads, guide combs, cleaning brush, oil, and charging cable.



Image: The KEMEI KM-5031 product packaging, highlighting the 'Super 11 IN 1 Grooming Kit' and visually presenting the main trimmer and its various attachments.

PRODUCT OVERVIEW

The KEMEI KM-5031 features a sleek design with a powerful motor and durable stainless steel blades. It is equipped with a long-lasting Li-ion battery for cordless operation and offers fast charging capabilities.



Kemei®
KM-5031

OFF





Image: The main KEMEI KM-5031 trimmer unit, showcasing its ergonomic design and the Kemei KM-5031 branding on the silver-colored central panel.

Key Features:

- **Super Professional Blade:** Ensures precise and efficient trimming.
- **High Speed Motor:** Provides powerful and consistent performance.
- **Li-ion Battery:** Offers extended cordless use.
- **Fast Charge:** Quick charging capability (2 hours for 60 minutes of use).
- **USB Direct Drive:** Convenient charging via USB.
- **LED Indicator:** Red light for charging, green for fully charged.

Kemei®

Personal care

MODEL:KM-5031

SUPER GROOMING KIT



FULL SIZE TRIMMER
Define hair around neckline precisely and evenly.



PRECISION TRIMMER
Define both straight or curved lines and edges.



SHAVER
Shave and finish lines and edges to ensure close, clean smooth results.



NOSE TRIMMER
Trim nose hair safely for maximum comfort.



SHAVER
Shave and finish lines and edges to ensure close, clean smooth results.



DESIGN TRIMMER
Personalized trimmed beard, all sorts of modeling.



PRODUCT FEATURES



SUPER PROFESSIONAL BLADE



HIGH SPEED MOTOR



FAST CHARGE
TIME: 2 HOURS
WORK TIME:
2 HOURS
600 milliampere lithium battery.



GLOW RED WHILE CHARGING
TURN GREEN FULL CHARGED



Li-ion BATTERY



DIRECT DRIVE
USB CHARGE

Image: Detailed view of the KEMEI KM-5031's features and functions of each attachment, including full size trimmer, precision trimmer, shaver, nose trimmer, and design trimmer, along with technical specifications like battery type and charging time.

SETUP

Initial Charging:

1. Before first use, fully charge the trimmer for approximately 2 hours.
2. Connect the USB charging cable to the trimmer and a suitable USB power adapter (not included) or a computer USB port.
3. The LED indicator light will illuminate red during charging.
4. Once fully charged, the LED indicator light will turn green.
5. A full charge provides approximately 60 minutes of cordless operation.

Attaching and Detaching Heads:

1. Ensure the trimmer is switched off before changing heads.
2. To attach a head, align the head with the main unit and gently push it down until it clicks into place.
3. To detach a head, hold the main unit firmly and push the head upwards from the front until it releases.
4. Guide combs can be attached to the trimmer heads by sliding them onto the blade until they lock.

OPERATING INSTRUCTIONS

The KEMEI KM-5031 is designed for dry operation. Always ensure your skin and hair are dry before use.

General Usage:

- Turn on the trimmer by sliding the power switch.
- Hold the trimmer at a comfortable angle against the skin.
- Move the trimmer slowly and steadily against the direction of hair growth for optimal results.
- Turn off the trimmer after use.

Specific Head Functions:

- **Full Size Trimmer:** Ideal for precise and even trimming of beard, sideburns, and neckline. Use with or without guide combs for desired length.
- **Precision Trimmer:** Designed for creating fine lines, contours, and detailed styling.
- **Shaver Head:** For a clean, close shave on smaller areas or to finish edges.
- **Nose Trimmer:** Gently insert the trimmer into the nostril or ear canal. Move in a circular motion to trim unwanted hair.
- **Design Trimmer:** Specialized for personalized trimming and shaping of beard lines and patterns.

MAINTENANCE

Cleaning:

1. Always turn off and unplug the trimmer before cleaning.
2. Detach the trimmer head.

3. Use the provided cleaning brush to remove hair clippings from the blades and inside the trimmer head.
4. The trimmer heads can be rinsed under running water, but ensure the main unit does not come into contact with water. Dry the heads thoroughly before reattaching.
5. Wipe the main unit with a dry or slightly damp cloth. Do not use abrasive cleaners or solvents.

Lubrication:

1. After cleaning and drying the blades, apply a small drop of the provided lubricating oil to the teeth of the trimmer blade.
2. Turn on the trimmer for a few seconds to allow the oil to distribute evenly.
3. Wipe off any excess oil. Regular lubrication helps maintain blade sharpness and prolongs the life of the trimmer.

TROUBLESHOOTING

- **Trimmer not turning on:** Ensure the battery is fully charged. Connect to the charger and check the LED indicator.
- **Poor trimming performance:**
 - Clean the blades and trimmer head thoroughly to remove any trapped hair.
 - Apply lubricating oil to the blades.
 - Ensure the correct trimmer head and guide comb are properly attached.
 - The battery might be low; recharge the device.
- **Device gets hot during use:** This is normal for electronic devices during operation. If it becomes excessively hot, turn it off and allow it to cool down before resuming use. Ensure blades are clean and lubricated.

SPECIFICATIONS



Image: The KEMEI KM-5031 trimmer held in a hand, illustrating its compact size with a measurement indicating a length of approximately 15 cm (6 inches).

Feature	Detail
Brand	KEMEI
Model Name	Multi-use 11 in 1 electric shaving (KM-5031)
Item Model Number	MT521
Power Source	Battery Powered
Operating Function	Dry
Battery Life	60 minutes
Charging Time	2 hours (Fast Charge)
Blade Material	Stainless Steel
Color	BLACK AND silver
Item Weight	15 Grams
Package Dimensions	22.1 x 19 x 7.7 cm
Manufacturer	KEMEI
Recommended Uses	Face
Special Features	Portable

WARRANTY AND SUPPORT

For any questions, technical support, or warranty claims regarding your KEMEI KM-5031 Electric Shaving Machine, please refer to the warranty information provided at the point of purchase or contact KEMEI customer service directly. Keep your purchase receipt as proof of purchase.