

[Manuals.plus](#) /

› [DL-pro](#) /

› DL-pro Meat Grinder Coupling Instruction Manual

DL-pro 418076

DL-pro Meat Grinder Coupling Instruction Manual

Model: 418076

Brand: DL-pro

1. PRODUCT OVERVIEW

This product is a set of three replacement couplings for the drive shaft of meat grinders used in various kitchen machines. It is designed to replace original parts with numbers 00418076 and 418076 (also replaces 00028106, 028106, 00020470, 020470).

The coupling ensures proper power transmission from the motor to the meat grinder attachment, allowing for efficient operation of your food processor.



Image 1: Three DL-pro meat grinder couplings.

2. COMPATIBILITY

This coupling is compatible with a wide range of Bosch and Siemens kitchen machines, including models from the MUM4, MUM5, MWF1, MUZ4, MUZ5, MF1, MK44, and MX45 series, as well as ProfiMixx, HomeProfessional, Champion, and Electronic models.

Please refer to the detailed compatibility lists below to ensure this part is suitable for your specific appliance model. The images display comprehensive lists of compatible devices.

Ersatzteil passend für folgende Geräte:

Marke	Nr.	Modell	BOSCH	MUM4450EU/02	
BOSCH	0710014642(00)	MUM4450	BOSCH	MUM4450EU/03	
BOSCH	0712012011(00)	FW/UM4	BOSCH	MUM4485/05	
BOSCH	0712012013(00)	FW/UM4	BOSCH	MUM4486/01	ProfiMixx 44
BOSCH	0712012016(00)	FW/UM4	BOSCH	MUM4486/02	ProfiMixx 44
BOSCH	MFW1501/01	Champion	BOSCH	MUM4486/03	ProfiMixx 44
BOSCH	MFW1501/02	Champion	BOSCH	MUM4585SU/01	Family Microtronic
BOSCH	MFW1501/03	Champion	BOSCH	MUM4585SU/03	Family Microtronic
BOSCH	MFW1501/04	Champion	BOSCH	MUM4585SU/04	Family Microtronic
BOSCH	MFW1501/05	Champion	BOSCH	MUM4630/03	electronic
BOSCH	MFW1501/06	Champion	BOSCH	MUM4655/01	ProfiMixx 46
BOSCH	MFW1501/07	Champion	BOSCH	MUM4655/02	ProfiMixx 46
BOSCH	MFW1501/08	Champion	BOSCH	MUM4655/03	ProfiMixx 46
BOSCH	MFW1501COE/05	collection	BOSCH	MUM4655EU/01	ProfiMixx 46
BOSCH	MFW1501COE/06	collection	BOSCH	MUM4655EU/02	ProfiMixx 46
BOSCH	MFW1507/03	Champion	BOSCH	MUM4655EU/03	ProfiMixx 46
BOSCH	MFW1507/04	Champion	BOSCH	MUM4655EU/04	ProfiMixx 46
BOSCH	MFW1507/05	Champion	BOSCH	MUM4655EU/05	ProfiMixx 46
BOSCH	MFW1511/03	Champion	BOSCH	MUM4655EU/07	ProfiMixx 46
BOSCH	MFW1511/04	Champion	BOSCH	MUM4655GB/01	ProfiMixx 46
BOSCH	MFW1511/05	Champion	BOSCH	MUM4655GB/02	ProfiMixx 46
BOSCH	MFW1545/01	Champion	BOSCH	MUM4655GB/03	ProfiMixx 46
BOSCH	MFW1545/02	Champion	BOSCH	MUM4655IL/01	ProfiMixx 46
BOSCH	MFW1545/03	Champion	BOSCH	MUM4655IL/02	ProfiMixx 46
BOSCH	MFW1545/04	Champion	BOSCH	MUM4655IL/03	ProfiMixx 46
BOSCH	MFW1545/05	Champion	BOSCH	MUM4656COE/03	collection
BOSCH	MFW1545/06	Champion	BOSCH	MUM4657/03	TheOne
BOSCH	MFW1545/07	Champion	BOSCH	MUM4657/04	TheOne
BOSCH	MFW1550/01	Champion	BOSCH	MUM4657/05	TheOne
BOSCH	MFW1550/02	Champion	BOSCH	MUM4657/07	TheOne
BOSCH	MFW1550/03	Champion	BOSCH	MUM4675EU/01	ProfiMixx 46
BOSCH	MFW1550/04	Champion	BOSCH	MUM4675EU/02	ProfiMixx 46
BOSCH	MFW1550/05	Champion	BOSCH	MUM4675EU/03	ProfiMixx 46
BOSCH	MFW1550/06	Champion	BOSCH	MUM4675EU/04	ProfiMixx 46
BOSCH	MFW1550/07	Champion	BOSCH	MUM4675EU/05	ProfiMixx 46
BOSCH	MFW1550COE/03	collection	BOSCH	MUM46CR2/03	electronic
BOSCH	MFW1550COE/04	collection	BOSCH	MUM46CR2/04	electronic
BOSCH	MFW1550ME/02	Champion	BOSCH	MUM46CR2/05	electronic
BOSCH	MFW1550ME/03	Champion	BOSCH	MUM4756EU/02	ProfoMixx 47 microtronic
BOSCH	MFW1550ME/04	Champion	BOSCH	MUM4756EU/03	ProfiMixx 47 microtronic
BOSCH	MUM4406/02	ProfiMixx 44	BOSCH	MUM4756EU/04	ProfiMixx 47 microtronic
BOSCH	MUM4406/03	ProfiMixx 44	BOSCH	MUM4756EU/05	ProfiMixx 47 microtronic
BOSCH	MUM4406/04	ProfiMixx 44	BOSCH	MUM4756EU/06	ProfiMixx 47 microtronic
BOSCH	MUM4406/05	ProfiMixx 44	BOSCH	MUM4756EU/07	ProfiMixx 47 microtronic
BOSCH	MUM4406/07	ProfiMixx 44	BOSCH	MUM4757COE/05	collection
BOSCH	MUM4450(01)		BOSCH	MUM4780/05	ProfiMixx 47 microtronic
BOSCH	MUM4450/00		BOSCH	MUM4780/06	ProfiMixx 47 microtronic
BOSCH	MUM4450/02		BOSCH	MUM4780/07	ProfiMixx 47 microtronic
BOSCH	MUM4450EU/01		BOSCH	MUM48140DE/05	

Image 2: Partial list of compatible Bosch models (Part 1).

Ersatzteil passend für folgende Geräte:

BOSCH	MUM48140DE/07		BOSCH	MUM58244/02	
BOSCH	MUM4855/05		BOSCH	MUM58244/04	
BOSCH	MUM4855/07		BOSCH	MUM58250/02	
BOSCH	MUM4856EU/05		BOSCH	MUM58250/04	
BOSCH	MUM4856EU/07		BOSCH	MUM58252RU/02	
BOSCH	MUM4875EU/05		BOSCH	MUM58252RU/04	
BOSCH	MUM4875EU/07		BOSCH	MUM58257/02	
BOSCH	MUM4880/05		BOSCH	MUM58257/04	
BOSCH	MUM4880/07		BOSCH	MUM58258/02	
BOSCH	MUM48CR2/05		BOSCH	MUM58258/04	
BOSCH	MUM50112/03		BOSCH	MUM58259/04	
BOSCH	MUM50112/04		BOSCH	MUM58M59/04	
BOSCH	MUM52131/02		BOSCH	MUM59340GB/02	
BOSCH	MUM52131/03		BOSCH	MUM59340GB/04	
BOSCH	MUM54240/01		BOSCH	MUM59363/02	HomeProfessional
BOSCH	MUM54240/02		BOSCH	MUM59363/04	HomeProfessional
BOSCH	MUM54251/01		BOSCH	MUM59M54/02	HomeProfessional
BOSCH	MUM54251/02		BOSCH	MUM59M54/04	HomeProfessional
BOSCH	MUM54251/04		BOSCH	MUM59M55/02	HomeProfessional
BOSCH	MUM54270DE/02		BOSCH	MUM59M55/04	HomeProfessional
BOSCH	MUM54270DE/04		BOSCH	MUM59S81DE/02	HomeProfessional
BOSCH	MUM54270DE/06		BOSCH	MUM59S81DE/04	HomeProfessional
BOSCH	MUM55761/02		BOSCH	MUZ4FW1(00)	
BOSCH	MUM55761/04		BOSCH	MUZ4FW101(00)	
BOSCH	MUM55761/06		BOSCH	MUZ4FW3(00)	
BOSCH	MUM56340/01		BOSCH	MUZ5BS1(00)	BakingSensation
BOSCH	MUM56340/02		BOSCH	MUZ5FW1(00)	
BOSCH	MUM56340/04		SIEMENS	MF15500TR/05	
BOSCH	MUM56340AU/01		SIEMENS	MF15500TR/06	
BOSCH	MUM56340AU/02		SIEMENS	MK445046(00)	
BOSCH	MUM56740/02		SIEMENS	MK445046/02	
BOSCH	MUM56740/04		SIEMENS	MX4501(00)	
BOSCH	MUM56S40/01		SIEMENS	MZ10211(00)	
BOSCH	MUM56S40/02		Toastmaster	MZ4TO02(00)	
BOSCH	MUM56Z40/02		Turmix	MK498516(00)	VARIO-TRONIC MRF
BOSCH	MUM57860/01	HomeProfessional			
BOSCH	MUM57860/02	HomeProfessional			
BOSCH	MUM57860/04	HomeProfessional			
BOSCH	MUM57860/05	HomeProfessional			
BOSCH	MUM57860AU/02	HomeProfessional			
BOSCH	MUM57860AU/04	HomeProfessional			
BOSCH	MUM57B224/02				
BOSCH	MUM57B224/04				
BOSCH	MUM58224/02				
BOSCH	MUM58224/04				
BOSCH	MUM58225/02				
BOSCH	MUM58225/04				
BOSCH	MUM58231/02				
BOSCH	MUM58231/04				

Image 3: Partial list of compatible Bosch and Siemens models (Part 2).

If your specific model is not listed or you are unsure about compatibility, please contact the manufacturer or seller for assistance.

3. INSTALLATION AND SETUP

The DL-pro coupling is designed for easy replacement of a worn or broken drive shaft coupling in compatible kitchen machines. While specific installation steps may vary slightly depending on your appliance model, the general procedure involves:

1. **Safety First:** Always unplug your kitchen machine from the power outlet before attempting any installation or maintenance.
2. **Access the Coupling:** Carefully disassemble the part of your kitchen machine that houses the meat grinder drive shaft. This may involve removing the meat grinder attachment and potentially some housing components. Refer to your appliance's original manual for specific disassembly instructions.
3. **Remove Old Coupling:** Once the drive shaft is accessible, gently remove the old, damaged coupling. It may be held in place by friction or a simple locking mechanism.
4. **Install New Coupling:** Align the new DL-pro coupling with the drive shaft and press it firmly into place until it is securely seated. Ensure the O-ring is properly positioned for a snug fit.
5. **Reassemble:** Reassemble your kitchen machine by reversing the disassembly steps. Ensure all components are securely fastened before plugging the appliance back in.
6. **Test Functionality:** After reassembly, perform a brief test run of your meat grinder attachment without any food to ensure the new coupling operates smoothly and correctly.

If you encounter any difficulties during installation, it is recommended to consult a qualified technician or refer to online resources specific to your appliance model.

4. OPERATING INSTRUCTIONS

Once the DL-pro coupling is correctly installed, your meat grinder attachment will function as intended. Operate your kitchen machine according to its original manufacturer's instructions for grinding and processing meat.

- Ensure the meat grinder attachment is securely fastened to the machine before operation.
- Do not overload the meat grinder; process ingredients in manageable quantities.
- Avoid forcing hard or frozen items through the grinder, as this can damage the coupling or other components.
- Always use the food pusher provided with your appliance to feed ingredients, never your hands.

5. MAINTENANCE

Proper maintenance will extend the life of your DL-pro coupling and your kitchen machine.

- **Cleaning:** After each use, disassemble the meat grinder attachment and clean all parts thoroughly. The coupling itself can be wiped clean with a damp cloth. Do not use abrasive cleaners or harsh chemicals.
- **Drying:** Ensure all parts, including the coupling, are completely dry before reassembling the appliance or storing it.
- **Storage:** Store the kitchen machine and its attachments in a clean, dry place.
- **Inspection:** Periodically inspect the coupling for any signs of wear, cracks, or damage. Replace the coupling if any damage is observed to prevent further issues.

6. TROUBLESHOOTING

If you experience issues after installing the new coupling, consider the following:

- **Meat Grinder Not Operating:**
 - Ensure the appliance is properly plugged in and powered on.
 - Verify that the meat grinder attachment is correctly assembled and securely attached to the machine.
 - Check if the new coupling is fully seated on the drive shaft.
 - Inspect the drive shaft itself for any damage or misalignment.
- **Unusual Noises or Vibrations:**
 - Disassemble and reassemble the meat grinder attachment and coupling to ensure all parts are correctly aligned.
 - Check for any foreign objects lodged within the grinder mechanism.
 - If the issue persists, the internal components of the appliance or the meat grinder attachment may require professional inspection.
- **Coupling Breaks Again:**
 - Ensure you are not overloading the meat grinder or processing excessively hard ingredients.
 - Verify that the appliance model is indeed compatible with this coupling.
 - Inspect the motor's drive shaft for any irregularities that might be causing undue stress on the coupling.

For persistent issues, contact customer support or a qualified service technician.

7. SPECIFICATIONS

Feature	Detail
Outer Diameter	34 mm
Length	35 mm

Color	White
Material	Plastic
Application	Drive Shaft Coupling for Meat Grinders
Quantity	3 couplings per package
Model Number	418076

8. WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or technical support, please refer to the purchase documentation or contact the seller directly. DL-pro aims to provide high-quality replacement parts and customer satisfaction.

If you have questions about the product or require assistance, please reach out to the customer service department of DL-pro or the retailer from whom you purchased the item.

© 2024 DL-pro. All rights reserved.

This manual is for informational purposes only. Always follow the safety guidelines provided with your appliance.