

Sunnyglade 6x4 Ft Pop-Up Canopy Tent

Sunnyglade 6x4 Ft Pop-Up Canopy Tent: Instruction Manual

Model: 6x4 Ft Pop-Up Canopy Tent

1. INTRODUCTION

Thank you for choosing the Sunnyglade 6x4 Ft Pop-Up Canopy Tent. This manual provides essential information for the safe and efficient assembly, operation, maintenance, and storage of your canopy. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always ensure the canopy is properly secured to the ground using the provided stakes and ropes to prevent it from tipping over in windy conditions.
- Keep the canopy away from heat sources and open flames to prevent fire hazards.
- Do not use the canopy in thunderstorms, heavy rain, strong winds, or lightning conditions. Disassemble and store the canopy during adverse weather.
- Always follow the manufacturer's instructions for setup, use, and dismantling.
- Ensure all locking mechanisms are fully engaged during setup to maintain structural integrity.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Pop-Up Steel Frame (1)
- Canopy Fabric Top (1)
- Carrying Bag (1)
- Ground Stakes (4)

4. SETUP INSTRUCTIONS

Follow these steps for quick and easy assembly:

1. **Unpack the Frame:** Remove the folded frame from the carrying bag and place it in the desired setup location.
2. **Partially Expand the Frame:** With a person at each corner, gently pull the legs outwards to partially expand the frame. Do not fully extend the legs yet.
3. **Attach the Canopy Fabric:** Drape the canopy fabric over the partially expanded frame. Ensure the corners of the fabric align with the frame's corners. Secure the fabric to the frame using the integrated Velcro strips.
4. **Fully Expand the Frame:** Continue pulling the legs outwards until the frame is fully expanded and the top locking mechanisms click into place.
5. **Extend the Legs:** Press the push-button sliders on each leg and extend them to the desired height. Ensure each leg locks securely into position.
6. **Secure with Stakes:** Use the provided ground stakes to anchor each leg firmly into the ground. For additional stability, especially in breezy conditions, attach guy ropes (not included) to the canopy corners and stake them down.

EASY TO INSTALL




Image: Visual guide showing the three main steps for easy canopy installation: 1. Remove from bag, 2. Partially expand frame, 3. Drape fabric and fully expand.




Image: Detailed view of the canopy's features, including the frame locking position, the four stakes used to fix the tent, and a close-up of the 185T Oxford waterproof fabric with water droplets.



STAKES

Stake set of four 7 inch steel stakes

Image: Close-up showing a metal stake securing the canopy leg base into the grass, with a set of four stakes displayed below.

5. OPERATING INSTRUCTIONS (USAGE)

The Sunnyglade Pop-Up Canopy is designed for temporary outdoor shade and shelter. Its 185T Oxford fabric with silver coating provides effective UV protection and water resistance.

- **Shade and Shelter:** Position the canopy to maximize shade coverage. It is suitable for various outdoor activities such as beach trips, camping, picnics, garden events, and social gatherings.
- **Adjusting Height:** The legs can be adjusted to different heights by pressing the push-button sliders. Ensure all legs are adjusted to the same height for stability.
- **Wind and Weather:** Always monitor weather conditions. While the canopy offers some wind resistance when properly staked, it is not designed for strong winds or severe weather. Disassemble if conditions worsen.



Image: The Sunnyglade 6x4 Ft Pop-Up Canopy Tent set up by a lake, providing shade for people sitting on a blanket, demonstrating its use in an outdoor setting.

6. MAINTENANCE

- **Cleaning Fabric:** Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners, as this may damage the fabric's coating. Allow the fabric to air dry completely before folding and storing.
- **Cleaning Frame:** Wipe the steel frame with a damp cloth to remove dirt and debris. Ensure the frame is dry to prevent rust.
- **Inspection:** Regularly inspect the frame for any signs of damage, bending, or loose connections. Check the fabric for tears or excessive wear. Address any issues promptly to ensure safe operation.

7. STORAGE

Proper storage extends the life of your canopy:

1. **Disassembly:** Reverse the setup steps. Retract the legs, then unlock and collapse the frame.
2. **Dry Completely:** Ensure both the canopy fabric and the frame are completely dry before folding and storing to prevent mold, mildew, and rust.
3. **Fold Neatly:** Fold the canopy fabric neatly and place it back into the carrying bag. Fold the frame compactly and place it into the carrying bag as well.
4. **Store Safely:** Store the carrying bag in a cool, dry place, away from direct sunlight and extreme temperatures.



Image: A close-up view of the canopy frame in its folded, compact state, ready for storage or transport.

185T Oxford Fabric with Silver Coating

Waterproof & UV Protection



**Comes with
Carrying Bag**

Image: The 185T Oxford fabric with silver coating, highlighting its waterproof and UV protection properties, alongside the included portable carrying bag.

8. TROUBLESHOOTING

If you encounter issues with your canopy, refer to the following common solutions:

- **Canopy Not Expanding/Collapsing Smoothly:** Ensure all locking pins are disengaged before attempting to collapse. Check for any obstructions or bent frame components. Apply a silicone-based lubricant to moving parts if necessary.
- **Canopy Instability:** Verify that all legs are fully extended and locked, and that the top frame is fully expanded and locked. Ensure all ground stakes are firmly inserted. In windy conditions, additional weights (e.g., sandbags) or guy ropes are recommended.
- **Water Pooling on Top:** Ensure the canopy fabric is taut and properly secured to the frame. Adjust the leg height if necessary to create proper tension and allow water runoff.

9. SPECIFICATIONS

Feature	Specification
Brand	Sunnyglade
Model	6x4 Ft Pop-Up Canopy Tent
Dimensions	6x4 feet (Floor Area: 24 sq ft)
Material (Canopy)	185T Oxford Fabric with Silver Coating
Material (Frame)	Powder-Coated Alloy Steel
Color	Light Brown
Item Weight	8.1 kg
UV Protection	Yes
Water Resistance Level	Waterproof
Frame Type	Pop-Up/Instant
Recommended Uses	Beach, Camping, Outdoor Activities, Picnic, Social Gathering

10. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the product packaging or contact Sunnyglade customer service directly through their official website or the retailer where the product was purchased. Please have your model number (6x4 Ft Pop-Up Canopy Tent) and ASIN (B09M8C5XB8) available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question