



[Manuals.plus](#) /

› [hofstein](#) /

› hofstein Salmi LED Ceiling Light Instruction Manual

hofstein Salmi

hofstein Salmi LED Ceiling Light Instruction Manual

Model: Salmi

INTRODUCTION

Thank you for choosing the hofstein Salmi LED Ceiling Light. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before installation and retain them for future reference.

hofstein®



Image: The hofstein Salmi LED Ceiling Light installed in a modern living room, showcasing its sleek design and warm illumination.

SAFETY INFORMATION

- **Electrical Safety:** Installation must be performed by a qualified electrician in accordance with local wiring regulations. Always disconnect power at the main circuit breaker before installation, maintenance, or cleaning.
- **Handling:** Handle the fixture with care to avoid damage. Do not apply excessive force.
- **Environment:** This fixture is designed for indoor use only (IP20 rating). Do not expose to moisture or extreme temperatures.
- **Light Source:** The LED light source is not replaceable. Do not attempt to disassemble the LED module.
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use abrasive cleaners or solvents.

PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- 1x Salmi LED Ceiling Light Fixture
- 1x Remote Control
- Mounting Hardware (screws, anchors)
- Instruction Manual (this document)



Image: Overview of the Salmi LED Ceiling Light components, including the main fixture, mounting bracket, and remote control.

SPECIFICATIONS

Feature	Value
Model Number	Salmi
Brand	hofstein

Feature	Value
Dimensions (L x W x H)	80 cm x 20 cm x 8 cm (approx. 31.5 in x 7.9 in x 3.1 in)
Weight	2.24 kg (approx. 4.94 lbs)
Material	Metal, MDF (wood look), Plastic (diffuser)
Color	Black, Brown, Wood Look
Light Source	Integrated LED
Power Consumption	24 Watts
Luminous Flux	150 - 1500 Lumens (Dimmable)
Color Temperature	2700 - 6000 Kelvin (Adjustable)
Average Lifespan	20,000 hours
Switching Cycles	10,000 times
Voltage	230 Volt
Protection Rating	IP20
Protection Class	I
Special Features	Dimmable, Remote Control Included



Image: Detailed dimensions of the Salmi LED Ceiling Light, including mounting points.

SETUP AND INSTALLATION

Important: Ensure power is disconnected at the main circuit breaker before beginning installation.

- 1. Prepare Mounting Location:** Choose a suitable location on the ceiling. Mark the drilling points for the mounting bracket using the fixture as a template.
- 2. Drill Holes:** Drill holes at the marked positions. Insert appropriate wall anchors if necessary.
- 3. Attach Mounting Bracket:** Secure the mounting bracket to the ceiling using the provided screws. Ensure it is firmly attached.
- 4. Electrical Connection:** Connect the household electrical wires to the terminal block on the fixture. Ensure correct polarity (Live, Neutral, Earth). If unsure, consult a qualified electrician.
- 5. Mount the Fixture:** Carefully align the ceiling light fixture with the mounting bracket and secure it. Ensure all wires are tucked safely inside the canopy.

6. **Restore Power:** Once the fixture is securely mounted and wired, restore power at the main circuit breaker.



Image: Internal view of the Salmi LED Ceiling Light, illustrating the wiring compartment and mounting bracket for installation reference.

OPERATING INSTRUCTIONS

The hofstein Salmi LED Ceiling Light is operated using the included remote control.

Remote Control Functions:

- **Power On/Off:** Press the **ON/OFF** button to turn the light on or off.
- **Dimming:** Use the **+** and **-** buttons to adjust the brightness (luminous flux) from 150 to 1500 lumens.
- **Color Temperature Adjustment:** Use the **Warm** and **Cool** buttons (or similar icons) to change the color temperature from warm white (2700K) to cool white (6000K).
- **Memory Function:** The light typically retains the last brightness and color temperature setting when turned off and on again, provided there is a short delay between operations.



Image: The remote control for the Salmi LED Ceiling Light, demonstrating its ability to adjust both brightness (lumens) and color temperature (Kelvin).

MAINTENANCE

- **Cleaning:** Disconnect power before cleaning. Wipe the fixture with a soft, dry, or slightly damp cloth. Do not use harsh chemicals, abrasive cleaners, or sprays directly on the fixture.
- **Light Source:** The integrated LED light source is designed for long-term use and is not user-replaceable.
- **Inspection:** Periodically check the fixture for any signs of damage or loose connections. If any issues are found, disconnect power and consult a qualified technician.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Light does not turn on.	No power supply, loose wiring, remote control battery dead.	Check circuit breaker. Verify wiring connections. Replace remote control battery.
Remote control not working.	Battery dead, remote out of range, obstruction.	Replace remote control battery. Ensure remote is within effective range and pointed towards the fixture. Remove any obstructions.
Light flickers or dims unexpectedly.	Unstable power supply, faulty wiring, internal component issue.	Check household electrical supply. Verify wiring. If problem persists, disconnect power and contact customer support.
Cannot change brightness or color temperature.	Remote control issue, light fixture malfunction.	Ensure remote control battery is functional. Try resetting the light by turning off power at the breaker for 30 seconds, then turning it back on.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact hofstein customer service. Refer to your purchase documentation for specific warranty terms and contact details.

You can visit the hofstein brand store for more information:[hofstein Brand Store](#)

