

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Vente-unique](#) /
- › [EXPERTLAND PRIMO Aluminum Swing Gate User Manual](#)

## Vente-unique PRIMO

# EXPERTLAND PRIMO Aluminum Swing Gate User Manual

Model: PRIMO

## PRODUCT OVERVIEW

The EXPERTLAND PRIMO Aluminum Swing Gate is designed to provide a light and contemporary entrance solution. Constructed from durable aluminum, it offers excellent weather resistance and requires minimal maintenance. Its openwork design provides privacy while allowing natural light to pass through.



Figure 1: Front view of the closed EXPERTLAND PRIMO Aluminum Swing Gate.

## SPECIFICATIONS

Feature	Detail
Brand	Vente-unique

<b>Feature</b>	<b>Detail</b>
Model Name	PRIMO
Color	Anthracite Grey (RAL 7016)
Material	Aluminum
Gate Shape	Straight
Gate Infill Type	Openwork
Motorization	Without motor
Number of Doors	2
Opening System	Swing
Opening Mechanism	Manual
Maximum Opening Angle	120°
Included Equipment	Handle, Key lock, Door stopper
Opening Direction	Inward swinging
Length	300 cm
Height	158 cm
Depth	4.6 cm
Total Length (including posts)	305 cm
Total Height (including posts)	166 cm
Product Weight	53 kg
Package 1 Dimensions	162 cm (L) x 29 cm (W) x 20 cm (H)
Package 1 Weight	25 kg
Package 2 Dimensions	143 cm (L) x 36 cm (W) x 14 cm (H)
Package 2 Weight	27 kg




Figure 2: Detailed dimensions of the gate and its components.

## SETUP AND INSTALLATION

Proper installation is crucial for the functionality and longevity of your EXPERTLAND PRIMO gate. It is recommended that installation be performed by individuals with appropriate construction knowledge and tools.

### Pre-Installation Checklist:

- Verify all package contents against the packing list. Ensure both packages (25 kg and 27 kg) are received and intact.
- Confirm the gate dimensions (300 cm length, 158 cm height) are suitable for your intended opening. The total required opening width including posts is 305 cm, and total height is 166 cm.
- Ensure the ground is level and stable where the gate posts will be installed.
- Gather necessary tools: measuring tape, level, drill, wrenches, concrete mix (if installing new posts), safety gear.

### Installation Steps (General Guidance):

1. **Prepare Posts:** If existing posts are not present, install two sturdy posts (e.g., concrete or metal) at the correct distance (305 cm center-to-center for the gate's total length). Ensure they are plumb and securely anchored. The gate is designed for inward swinging.
2. **Attach Hinges:** Secure the gate hinges to the prepared posts according to the manufacturer's instructions. Ensure the hinges are level and aligned to allow for smooth gate operation.
3. **Mount Gate Panels:** Carefully lift and attach the two gate panels to the hinges. This step may require two or more people due to the weight and size of the panels.
4. **Install Locking Mechanism:** Attach the handle, key lock, and door stopper as per the provided hardware instructions. Ensure the lock engages smoothly and securely.
5. **Adjust and Test:** Open and close the gate multiple times to check for smooth operation. Make any necessary adjustments to the hinges or stopper to ensure proper alignment and a 120° maximum opening angle.



Figure 3: Gate components and partial assembly view.

## OPERATING INSTRUCTIONS

---

The EXPERTLAND PRIMO gate operates manually. Follow these guidelines for safe and effective use:

- **Opening:** To open the gate, unlock the key lock and push the gate panels inward. The gate is designed to swing inwards up to a maximum of 120 degrees.
- **Closing:** To close the gate, pull the panels back until they meet at the center. Ensure the panels align properly before engaging the lock.
- **Locking:** Use the provided key to lock the gate securely when closed. Always ensure the lock is fully engaged to prevent unintended opening.
- **Obstruction Check:** Before opening or closing, always check the gate's path for any obstructions, including children, pets, or objects.



Figure 4: The gate in an open position, demonstrating its swing capability.

## MAINTENANCE

The aluminum construction of the PRIMO gate ensures high durability and low maintenance. Regular care will preserve its appearance and functionality.

- **Cleaning:** Clean the gate periodically with mild soap and water. Use a soft cloth or sponge. Avoid abrasive cleaners or harsh chemicals that could damage the finish. Rinse thoroughly with clean water.
- **Hinge Lubrication:** Lubricate hinges annually with a silicone-based spray or light oil to ensure smooth operation and prevent squeaking.
- **Inspection:** Regularly inspect the gate for any signs of wear, damage, or loose components. Check the integrity of the posts, hinges, and locking mechanism.
- **Rust Prevention:** While aluminum is highly resistant to rust, inspect any steel components (e.g., screws, internal lock parts) for corrosion and treat as necessary.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Gate is difficult to open/close or squeaks.	Dry or dirty hinges; misalignment.	Lubricate hinges. Check for obstructions. Adjust hinge alignment if necessary.
Lock mechanism is stiff or not engaging.	Dirt in lock; misalignment of gate panels.	Clean lock mechanism. Ensure gate panels are properly aligned when closed. Lubricate lock if needed.
Gate panels sag or are uneven.	Loose hinges; unstable posts; ground settling.	Tighten hinge bolts. Inspect posts for stability and reinforce if necessary. Check ground level.

# WARRANTY AND SUPPORT


For information regarding warranty coverage and customer support, please refer to the purchase documentation or contact Vente-unique customer service directly. Ensure you have your proof of purchase and product details (Model: PRIMO, Brand: Vente-unique) available when contacting support.

Vente-unique is committed to customer satisfaction. For further assistance, visit their official website or contact their support channels.

© 2024 Vente-unique. All rights reserved.

## Related Documents - PRIMO

	<p><a href="#">PRIMO Aluminum Gate Assembly and Installation Manual (Model 124021)</a></p> <p>Detailed assembly and installation guide for the PRIMO aluminum gate, model 124021. Includes parts list, step-by-step instructions with textual diagram descriptions, dimensions, and safety warnings.</p>
	<p><a href="#">Brenton 3 Seater Sofa: Assembly Instructions and Care Guide</a></p> <p>Detailed assembly guide and maintenance instructions for the Vente-Unique Brenton 3 Seater sofa. Includes parts list, step-by-step assembly, and care tips to ensure longevity.</p>
	<p><a href="#">Manuel d'instructions PRIMO - Porte en Aluminium</a></p> <p>Découvrez le manuel d'instructions pour la porte en aluminium PRIMO (modèle 124033). Guide complet pour l'assemblage, l'installation et l'entretien de votre portail.</p>

 <p>Primo CERAMIC GRILLS America's Most Award-Winning Flavor</p> <p>Owners Manual</p> <p>PrimoGrills.com</p>	<p><a href="#">Primo Ceramic Grills Owners Manual - Master the Art of Grilling</a></p> <p>Comprehensive owners manual for Primo Ceramic Grills, covering history, advantages, safety, assembly, first use, cooking guides for various meats and vegetables, and frequently asked questions. Learn to maximize your grilling experience with Primo.</p>
 <p>LAPIOTA</p> <p>Vente-unique</p>	<p><a href="#">LAPIOTA Sofa Assembly and Care Instructions   Vente-unique</a></p> <p>Detailed assembly instructions and care guide for the LAPIOTA sofa by Vente-unique. Includes parts list, step-by-step assembly, and maintenance tips.</p>
 <p>LUREO</p> <p>Vente-unique</p>	<p><a href="#">LUREO Bedside Cabinet - Assembly Instructions and Care Guide</a></p> <p>Comprehensive assembly instructions and care guide for the LUREO bedside cabinet by Vente-Unique. Learn how to safely assemble and maintain your furniture.</p>