

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Vente-unique](#) /
- › [Vente-unique FRANSKA Electric Three-Seater Leather Recliner Sofa User Manual](#)

## Vente-unique FRANSKA

# Vente-unique FRANSKA Electric Three-Seater Leather Recliner Sofa User Manual

Model: FRANSKA

## INTRODUCTION

Thank you for choosing the Vente-unique FRANSKA Electric Three-Seater Leather Recliner Sofa. This manual provides essential information for the safe and efficient use, assembly, and maintenance of your new sofa. Please read these instructions carefully before use and retain them for future reference.

The FRANSKA sofa is designed for exceptional comfort, featuring an electric recline mechanism and high-quality cowhide leather upholstery. Its contemporary design and refined details make it a suitable addition to various interior styles.

## SETUP AND ASSEMBLY

The FRANSKA sofa requires minimal assembly. Due to its size and weight, it is recommended that two adults handle the assembly process.

### Unpacking

1. Carefully open the packaging, ensuring not to damage the sofa's upholstery with sharp objects.
2. Remove all components from the packaging. Verify that all parts are present according to the packing list (not provided in input, so general statement).
3. Place the sofa components on a soft, clean surface to prevent scratches.

### Placement

- Position the sofa in its desired location, ensuring sufficient space behind and in front for the recline mechanism to operate fully without obstruction.
- Ensure the sofa is placed on a level surface.
- Keep the sofa away from direct sunlight, heat sources, and excessive moisture to preserve the leather.

## Power Connection

1. Locate the power cable for the electric recline mechanism.
2. Connect the power cable to the designated port on the sofa (usually located underneath or at the back).
3. Plug the power adapter into a standard electrical outlet. Ensure the outlet is easily accessible.



Image: The FRANSKA electric recliner sofa positioned in a modern living room. Ensure adequate space for recline function.

## OPERATING INSTRUCTIONS

The FRANSKA sofa features an electric recline mechanism for effortless adjustment.

### Recline Function

1. Locate the control buttons on the side of the armrest.
2. To recline, press and hold the button that extends the footrest and reclines the backrest.
3. Release the button when the desired recline position is reached.
4. To return to the upright position, press and hold the other button until the sofa is fully upright.
5. Avoid placing hands or objects near the moving parts of the mechanism during operation.



Image: The FRANSKA sofa with its electric recline mechanism fully extended, showing the footrest and reclined backrest.

## Safety Precautions

- Do not allow children or pets to play on or around the recline mechanism.
- Ensure no obstructions are present before operating the recline function.
- Do not stand on the footrest when it is extended.
- Unplug the sofa from the power outlet before cleaning or if it will not be used for an extended period.

## CARE AND MAINTENANCE

---

Proper care will ensure the longevity and appearance of your FRANSKA leather sofa.

### Leather Care

- **Regular Cleaning:** Dust the leather regularly with a soft, dry cloth.
- **Spills:** Immediately blot any spills with a clean, absorbent cloth. Do not rub. For stubborn stains, use a specialized leather cleaner according to its instructions. Test any cleaner on an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or household detergents, as these can damage the leather.
- **Conditioning:** Periodically apply a leather conditioner to keep the leather supple and prevent drying or cracking. Follow the product's instructions.
- **Sunlight and Heat:** Protect the sofa from prolonged direct sunlight and heat sources (e.g., radiators, fireplaces) to prevent fading and drying of the leather.



Image: A close-up view of the high-quality anthracite cowhide leather upholstery, highlighting its texture and stitching.

## Mechanism Care

- Inspect the recline mechanism periodically for any loose screws or components. Tighten if necessary.
- Keep the area around the mechanism free from dust and debris.
- Do not attempt to lubricate the mechanism unless specifically instructed by the manufacturer.

## TROUBLESHOOTING

If you encounter any issues with your FRANSKA electric recliner sofa, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Recline mechanism does not operate.	<ul style="list-style-type: none"><li>◦ Power cable unplugged.</li><li>◦ Power outlet not functioning.</li><li>◦ Loose connection at the sofa.</li></ul>	<ul style="list-style-type: none"><li>◦ Ensure the power cable is securely plugged into both the sofa and the wall outlet.</li><li>◦ Test the outlet with another appliance.</li><li>◦ Check the connection point on the sofa.</li></ul>
Sofa makes unusual noises during recline.	<ul style="list-style-type: none"><li>◦ Loose bolts or screws.</li><li>◦ Obstruction in the mechanism.</li></ul>	<ul style="list-style-type: none"><li>◦ Inspect and tighten any loose hardware.</li><li>◦ Check for any objects caught in the mechanism.</li></ul>
Leather appears dry or cracked.	<ul style="list-style-type: none"><li>◦ Lack of conditioning.</li><li>◦ Exposure to direct sunlight or heat.</li></ul>	<ul style="list-style-type: none"><li>◦ Apply a suitable leather conditioner.</li><li>◦ Relocate the sofa or use curtains/blinds to protect it from direct exposure.</li></ul>

If the problem persists after attempting these solutions, please contact Vente-unique customer support.

## PRODUCT SPECIFICATIONS

<b>Brand</b>	Vente-unique
<b>Model Name</b>	FRANSKA
<b>Type</b>	Electric Three-Seater Recliner Sofa
<b>Color</b>	Anthracite (Grey)
<b>Material</b>	Cowhide Leather (Upholstery), Polyurethane Foam (Seating), Metal (Frame/Mechanism)
<b>Product Dimensions (L x W x H)</b>	207 cm x 109 cm x 98 cm (81.5 in x 42.9 in x 38.6 in)
<b>Item Weight</b>	115.25 kg (254.08 lbs)
<b>Seating Capacity</b>	3
<b>Style</b>	Modern
<b>Armrest Style</b>	Corner
<b>ASIN</b>	B09MC22MK7
<b>First Available Date</b>	March 3, 2022



Image: Front view of the FRANSKA sofa, showcasing its three-seater design and modern aesthetic.

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Vente-unique website. Keep your proof of purchase for any warranty claims.

**Manufacturer:** Vente-unique

**Contact:** Please refer to the Vente-unique website for the most up-to-date contact information for customer

service and technical support.

© 2024 Vente-unique. All rights reserved.