

[Manuals.plus](#) /

> [Owigift](#) /

> Owigift Refrigerator Door Handle Replacement Manual for Frigidaire FFTR1814 Series

Owigift FFTR1814LWM, FFTR1814QW0, FFTR1814QW1, FFTR1814QW2, FFTR1814QW3, FFTR1814LWL, FFTR1814LWN, FFTR1814LZ3, FFTR1814LZ4, FFT

Owigift Refrigerator Door Handle Replacement Manual

For Frigidaire FFTR1814 Series Models

1. PRODUCT OVERVIEW

This package includes two plastic refrigerator door handles, one for the freezer door and one for the fridge door. These handles are designed as aftermarket replacements for various Frigidaire and Uni Refrigerator models.



Image: Two white plastic refrigerator door handles, designed for replacement.

Video: Overview of the Refrigerator Door Handle Set, showcasing its features and design. (Duration: 0:23)

Compatible Models:

- FFTR1814LWM
- FFTR1814QW0
- FFTR1814QW1
- FFTR1814QW2
- FFTR1814QW3
- FFTR1814LWL
- FFTR1814LWN
- FFTR1814LZ3
- FFTR1814LZ4
- FFTR1814LZ5

- FFTR1814LZ7
- FFTR1814LZ8
- FFTR1817LW0
- FFTR1814QW4A
- FFTR1814QW5A
- FFTR1814QW6B
- FFTR1814QW7B
- FFTR1814QW8B
- FFTR1814QW9B
- FFTR1817LW1
- FFTR1817LW2
- FFTR1817LW3
- FFTR1817LW4

2. SETUP AND INSTALLATION

Follow these steps to replace your refrigerator door handle. Always ensure the appliance is unplugged before beginning any repair.

1. **Safety First:** Always unplug the refrigerator from the power outlet before starting the installation.
2. **Remove Old Handle:** Open the refrigerator door. Use a Phillips head screwdriver to remove the two screws securing the existing handle.
3. **Disengage Locking Tab:** Turn the handle to the side and push inward to disengage any locking tabs, then carefully pull the old handle off.
4. **Install New Handle:** First, place one end of the new handle over the pin on the refrigerator door. Push it to the side to lock it into place.
5. **Secure Handle:** Swing the handle over to align with the screw holes. Secure it firmly with the two screws using a Phillips head screwdriver.
6. **Repeat for Other Handle:** If replacing both handles, repeat the same procedure for the other door.
7. **Restore Power:** Once both handles are securely installed, plug the refrigerator back into the power outlet.

Video: Detailed instructions on how to replace a refrigerator door handle. (Duration: 0:44)

3. MAINTENANCE

To ensure the longevity and appearance of your new refrigerator door handles, regular cleaning is recommended.

- **Cleaning:** Wipe the handles regularly with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners or harsh chemicals that could damage the plastic finish.
- **Inspection:** Periodically check the screws for tightness. If they become loose, gently tighten them with a Phillips head screwdriver to prevent wobbling or detachment.

Video: General tips for maintaining and cleaning appliance parts, including refrigerator handles. (Duration: 0:55)

4. TROUBLESHOOTING

If you encounter issues with your new refrigerator door handles, consider the following:

- **Handle Loose:** If the handle feels loose after installation, ensure the screws are fully tightened. Avoid overtightening, which can strip the screw holes.
- **Compatibility Concerns:** If you are unsure about the compatibility of these handles with your specific refrigerator model, please refer to the list of compatible models in the Product Overview section. If your model is not listed, contact customer support for assistance.

5. SPECIFICATIONS

- **Material:** Plastic
- **Special Features:** Easy to Install
- **Package Includes:** 2x Refrigerator Door Handles (1 for freezer, 1 for fridge)

6. WARRANTY

These refrigerator door handles come with a lifetime warranty, ensuring long-term reliability and customer satisfaction.

7. SUPPORT

For any questions, concerns, or assistance with installation or compatibility, please contact our customer service team. We are committed to resolving your issues promptly.

- **Response Time:** We aim to solve your problem within 24 hours.

