

LASENCHOO LASENCHOO-PC001

LASENCHOO 8-Light Plug-in Sputnik Chandelier

Model: LASENCHOO-PC001

Brand: LASENCHOO

1. INTRODUCTION

Thank you for choosing the LASENCHOO 8-Light Plug-in Sputnik Chandelier. This modern lighting fixture features a distinctive Sputnik design, an adjustable hanging chain, and a convenient 16.4ft plug-in cord with an on/off switch. It is designed for easy installation without the need for a junction box and is suitable for various indoor spaces and covered outdoor areas. This manual provides essential information for safe installation, operation, and maintenance of your new chandelier.



Image 1.1: LASENCHOO 8-Light Plug-in Chandelier Overview

2. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Keep this manual for future reference.

- The lamp holder and cord are UL certified to ensure safety.
- This product is intended for **indoor use only** and is recommended for non-humid places. It is **not water resistant**.
- Always disconnect power before installing, cleaning, or performing any maintenance.

- Use only E26 base bulbs. Do not exceed the maximum wattage of 40W per bulb.
- Ensure the installation surface can support the weight of the fixture.
- If you are unsure about electrical installations, consult a qualified electrician.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation.

- Whole Chandelier Body (with pre-wired arms)
- Adjustable Hanging Chain (4.92ft)
- 16.4ft Plug-in Cord with On/Off Switch
- Necessary Assembling Accessories (e.g., hooks, screws, anchors)
- Convenient Wiring Connectors
- Installation Instruction Manual

Note: Bulbs are **NOT** included and must be purchased separately.



Image 3.1: Chandelier Components

4. SETUP AND INSTALLATION

This chandelier is designed for easy plug-in installation, eliminating the need for complex hardwiring or a junction box.

4.1 Assembly Steps

1. Carefully unpack all components and verify against the package contents list.
2. The chandelier arms come pre-wired. Screw each arm into the central ball one by one until secure.
3. Attach the adjustable hanging chain to the central ball.
4. Determine the desired hanging height. The chain length is 4.92ft and the cord length is 16.4ft, allowing for flexible placement.
5. Install the provided hooks into your ceiling or wall at the desired location. Ensure the hooks are securely fastened into a stud or using appropriate anchors for drywall.
6. Hang the chandelier using the chain and hooks. The design supports installation on both flat and sloped ceilings.
7. Route the plug-in cord to a nearby electrical outlet.
8. Install E26 base bulbs (not included) into each socket. Ensure bulbs do not exceed 40W.





Image 4.1: Installation Diagram for Flat and Sloped Ceilings



**Removable Chain & Buckle
for Height Adjustment**

**Adjustable Height
Chain Length
4.92ft**

Cord Length 16.4ft




Image 4.2: Chandelier Dimensions and Cord Length

4.2 Visual Installation Guide

Video 4.3: Official LASENCHOO Installation Guide. This video demonstrates the assembly process of the chandelier arms and general

setup.

5. OPERATING INSTRUCTIONS

Operating your LASENCHOO chandelier is straightforward:

- Plug the 16.4ft cord into a standard 120V AC electrical outlet.
- Use the integrated on/off switch located on the cord to control the light.
- If using dimmable E26 bulbs and a compatible dimmer switch (not included), you can adjust the light intensity.



Image 5.1: Plug and Switch Detail

6. MAINTENANCE

To ensure the longevity and appearance of your chandelier, follow these maintenance guidelines:

- Always turn off and unplug the chandelier before cleaning.
- Wipe the fixture with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- Regularly check all connections and bulbs to ensure they are secure.

7. TROUBLESHOOTING

If you encounter issues with your chandelier, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	1. Power cord not plugged in. 2. On/off switch is off. 3. Bulb(s) are loose or faulty. 4. Power outlet is not working.	1. Ensure the power cord is fully plugged into a working outlet. 2. Flip the on/off switch to the 'ON' position. 3. Tighten or replace the bulb(s). 4. Test the outlet with another device.
Dimming function not working	1. Non-dimmable bulbs are installed. 2. Dimmer switch is not compatible or faulty.	1. Replace with dimmable E26 bulbs. 2. Ensure you are using a compatible dimmer switch (not included).
Chandelier appears unstable	1. Hooks are not securely installed. 2. Chain is not properly attached.	1. Re-secure the hanging hooks into a stud or use appropriate anchors. 2. Verify the chain is correctly attached to the chandelier and hooks.

Problem	Possible Cause	Solution
---------	----------------	----------

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Brand	LASENCHOO
Model Number	LASENCHOO-PC001
Color	Black
Material	Metal (Iron)
Style	Mid Century Modern/Vintage/Industrial
Light Fixture Form	Chandelier
Indoor/Outdoor Usage	Indoor (Recommended for non-humid places)
Power Source	AC
Control Method	Push Button (On/Off Switch on cord)
Light Source	E26 Bulbs (Incandescent/CFL/LED/Halogen, Not Included)
Number of Light Sources	8
Max Wattage per Bulb	40W
Total Wattage	320W
Voltage	120 Volts (AC)
Bulb Base	E26
Connectivity Protocol	Plug In Cord
Mounting Type	Plug-In Design, Hanging By Hook
Required Assembly	Yes
Item Dimensions (L x W x H)	26"L x 26"W x 11"H
Item Weight	1.7 Kilograms
Cord Length	16.4ft
Chain Length	4.92ft (Adjustable)
Certification	UL Listed (Lamp holder and cord)

9. WARRANTY AND SUPPORT

LASENCHOO provides a limited warranty for this product. For specific warranty details, please refer to the documentation included with your purchase or contact customer support.

For any problems, questions, or assistance regarding your LASENCHOO 8-Light Plug-in Sputnik Chandelier, please contact our friendly service support team. Contact information can typically be found on the product packaging or the official LASENCHOO website.

© 2026 LASENCHOO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question