

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [tectake](#) /

› [tectake Corner Desk with 2 Shelves - Industrial Design Computer Desk - Model 404231 Instruction Manual](#)

**tectake 404231**

# tectake Corner Desk with 2 Shelves - Model 404231 Instruction Manual

## INTRODUCTION

---

This manual provides instructions for the assembly, operation, and maintenance of your tectake Corner Desk, Model 404231. Please read this manual thoroughly before assembly and use to ensure proper function and safety. This L-shaped desk features two integrated shelves, a dark industrial wood finish, and a black metal frame, designed to provide a functional workspace.

# ELEGANT Design

De combinatie van koel metaal en warm hout geeft deze tafel een rustieke uitstraling die perfect past in elk interieur.



## SOLIDE Constructie

De 2 zijplanken creëren extra opbergruimte: ideaal om boeken, dossiers & andere kantoorbenodigdheden altijd binnen handbereik te hebben.

Image: Overall view of the tectake Corner Desk, highlighting its L-shaped design and two side shelves.

## SAFETY INFORMATION

**Important:** Read all safety warnings and instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Avoid overloading the desk and shelves.
- Ensure the desk is properly leveled to maintain stability.
- Exercise caution when placing heavy items on the shelves to prevent tipping.
- Keep small parts away from children during assembly to prevent choking hazards.
- Do not stand or sit on the desk.

## PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact tectake customer support.

- Corner Desk components (MDF panels, steel frame parts)

- Assembly hardware (screws, bolts, plastic feet, etc.)
- Assembly instructions (this manual)

## SPECIFICATIONS

Detailed technical specifications for the tectake Corner Desk, Model 404231:

Feature	Detail
Model Number	404231
Overall Dimensions (L x W x H)	138 x 138 x 75.5 cm
Desk Depth	50 cm
Upper Side Compartment (L x W x H)	24 x 48 x 36 cm
Lower Side Compartment (L x W x H)	24 x 48 x 24.5 cm
MDF Panel Thickness	1.5 cm
Steel Support Dimensions	2 x 2 cm
Plastic Foot Adjustment	1.5 cm
Desk Top Load Capacity	200 kg
Side Compartment Load Capacity (each)	25 kg
Item Weight	25.2 kg
Materials	MDF panel, powder-coated steel, polyethylene
Recommended Assembly Persons	2
Recommended Tools for Assembly	Screwdriver (all necessary tools included)

AFMETINGEN

**Totale afmetingen**  
138 x 138 x 75,5 cm

**Diepte tafelblad**  
50 cm

**Bovenste zijvak**  
24 x 48 x 36 cm

**Onderste zijvak**  
24 x 48 x 24,5 cm


TECHNISCHE DETAILS

**Draagkracht tafelblad** 200 kg  
**Per zijvak** 25 kg

**Gewicht** ca. 25 kg  
**Materiaal** melamine gecoate MDF-plaat, gepoedercoat staal, polyethyleen

INHOUD

Hoekbureau  
Montagemateriaal  
Montagehandleiding



Afmetingen zijn bij benadering

Image: Technical diagram illustrating the dimensions of the corner desk and its components.

**ASSEMBLY INSTRUCTIONS**

This desk requires self-assembly. It is recommended that two people assemble this product. A screwdriver is the recommended tool, and all necessary assembly tools are included in the package. Refer to the detailed step-by-step instructions and diagrams provided in the box for precise guidance.

**Before You Begin**

- Unpack all components and lay them out on a clean, soft surface (e.g., a blanket or cardboard) to prevent scratches.
- Identify all parts using the included parts list and hardware pack.
- Ensure you have sufficient space for assembly.

**General Assembly Steps (Refer to included manual for detailed steps)**

1. **Assemble the Frame:** Connect the metal frame components using the provided screws and bolts. Ensure all connections are secure but do not overtighten initially.
2. **Attach Desk Panels:** Secure the MDF desk panels to the assembled metal frame. Align pre-drilled holes carefully.

3. **Install Shelves:** Mount the two side shelves to their designated positions on the frame.
4. **Adjust Leveling Feet:** Once the desk is fully assembled, place it in its desired location. Adjust the plastic leveling feet on the bottom of the frame to ensure the desk is stable and level on uneven surfaces.
5. **Final Tightening:** After all parts are in place and the desk is level, go back and securely tighten all screws and fasteners.



Door het **verwijderen van de bovenste plank** ontstaat een groot vak waarin ook een PC past.

Het **gepoedercoate stalen frame** zorgt voor eersteklas stabiliteit met een enorm draagvermogen.



De **robuuste, gecoate MDF-platen** combineren een stijlvolle houtlook met onderhoudsgemak.



De **antislip kunststof voetjes** zijn in hoogte verstelbaar om oneffenheden in de vloer te compenseren.

Image: Detail showing the beveled edge for cable management and the adjustable plastic feet for stability.

## OPERATING INSTRUCTIONS

The tectake Corner Desk is designed for general office and home use, providing a functional and organized workspace.

- **Workspace Utilization:** The L-shaped design offers an expansive surface for multiple monitors, laptops, and other work essentials.
- **Cable Management:** Utilize the beveled corner edge to route cables for computers, monitors, and other devices, helping to keep your workspace tidy and organized.
- **Storage:** The two integrated side shelves are suitable for storing books, office supplies, computer peripherals, or decorative items. Always adhere to the maximum load capacity of 25 kg per shelf to

prevent damage or instability.

## MAINTENANCE

---

Proper care and maintenance will extend the life and preserve the appearance of your tectake Corner Desk.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. For stubborn marks, use a mild soap solution and immediately dry with a clean cloth. Avoid abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish.
- **Inspection:** Periodically check all screws, bolts, and fasteners to ensure they remain tight. Retighten if necessary to maintain structural integrity and stability.
- **Protection:** Avoid placing hot items directly on the desk surface. Use coasters or protective pads under hot mugs, plates, or other objects. Protect the surface from sharp objects to prevent scratches.
- **Environment:** Keep the desk in a dry environment and avoid prolonged exposure to direct sunlight or extreme temperature changes, which can affect the wood and metal components.

## TROUBLESHOOTING

---

This section addresses common issues you might encounter with your desk and provides potential solutions.

### Desk is Unstable or Wobbly

- **Check Fasteners:** Ensure all assembly screws and bolts are securely tightened. Loose connections are a common cause of instability.
- **Adjust Leveling Feet:** The desk is equipped with adjustable plastic feet. Turn these feet clockwise or counter-clockwise to compensate for uneven floors until the desk is stable.
- **Verify Load:** Ensure the desk and shelves are not overloaded beyond their specified weight capacities. Uneven weight distribution can also cause instability.

### Difficulty During Assembly

- **Review Instructions:** Carefully re-read the detailed assembly instructions and diagrams provided in the product packaging.
- **Part Orientation:** Double-check that all parts are correctly oriented as shown in the assembly diagrams. Sometimes a part may appear similar but has a specific direction.
- **Two-Person Assembly:** Remember that assembly is recommended for two people. Having an extra pair of hands can significantly ease the process, especially when aligning larger components.
- **Contact Support:** If you continue to experience difficulties, contact tectake customer support for assistance.

## WARRANTY & SUPPORT

---

For detailed warranty information, terms, and conditions, please refer to the documentation included with your product at the time of purchase. This documentation will outline the coverage period and procedures for making a warranty claim.

For technical support, missing parts, or any other inquiries regarding your tectake Corner Desk, please visit the official tectake website or contact their customer service department using the contact information

provided in your product packaging or on their website.

When contacting support, please have the following information ready:

- **Model Number:** 404231
- **ASIN:** B09MDKJQRC
- Date of Purchase
- Description of the issue