

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ELEPHAS](#) /

› [ELEPHAS Mini Projector BL128 User Manual](#)

## ELEPHAS BL128

# ELEPHAS Mini Projector BL128 User Manual

Model: BL128

## 1. INTRODUCTION

---

Thank you for purchasing the ELEPHAS Mini Projector BL128. This portable projector is designed to provide a high-quality viewing experience with 1080P Full HD support and a large screen projection capability. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your projector to ensure optimal performance.

## 2. WHAT'S IN THE BOX

---

Please check the contents of your package. If any items are missing or damaged, please contact customer support.

- 1 x ELEPHAS Mini Projector BL128
- 1 x Detachable Tripod
- 1 x Remote Control
- 1 x User Manual (this document)
- 1 x HDMI Cable



Image: The ELEPHAS Mini Projector BL128 shown with its included accessories, including the remote control, tripod, and cables.

### 3. PRODUCT OVERVIEW

---

Familiarize yourself with the main components of your projector.

#### 3.1 Projector Components

- **Lens:** German emerald glass lens for clear projection.
- **Control Panel:** Buttons for basic navigation and settings.
- **Input Ports:** HDMI, USB, AV, Audio, Chromecast interface.
- **Speaker:** Built-in HIFI stereo speaker.
- **Cooling Vents:** For efficient heat dissipation.
- **Focus Ring:** For manual image focus adjustment.



Image: The ELEPHAS Mini Projector BL128 positioned on a table, highlighting its lens, control panel, and various ports.

#### 3.2 Remote Control

The included remote control allows for convenient operation of the projector from a distance.

# IMMERSIVE SOUND



Image: The remote control for the ELEPHAS Mini Projector BL128, featuring power, navigation, and focus buttons.

## 4. SETUP INSTRUCTIONS

### 4.1 Placement

The projector can be used indoors or outdoors. For best results, place the projector on a stable, flat surface. Ensure there is adequate space around the projector for ventilation.



Image: The projector set up on a tripod for an outdoor movie night, demonstrating flexible placement options.

## 4.2 Attaching the Tripod

The projector comes with a detachable tripod for stable positioning. Screw the tripod into the threaded hole at the bottom of the projector until secure.



Image: The ELEPHAS Mini Projector BL128 with its included tripod attached, ready for use.

### 4.3 Power Connection

Connect the power adapter to the projector's power input port, then plug the adapter into a power outlet. The power indicator light will illuminate.

### 4.4 Initial Focus Adjustment

Turn on the projector. Adjust the focus ring on the projector lens or use the digital focus function via the remote control until the projected image is clear.



Image: A remote control displaying the digital focus adjustment feature, allowing for precise image clarity.

## 5. OPERATING INSTRUCTIONS

### 5.1 Powering On/Off

- **To Power On:** Press the power button on the projector or the remote control.

- **To Power Off:** Press the power button again. The projector will enter standby mode.

## 5.2 Connecting Devices

The projector supports various input sources. Select the appropriate input source from the projector's menu after connecting your device.

- **HDMI:** Connect laptops, PCs, TV boxes, TV sticks, game consoles, or DVD players using an HDMI cable.
- **USB:** Insert a USB flash drive to play media files directly.
- **AV:** Use the AV port for older devices with composite video output.
- **Audio Out:** Connect external speakers or headphones via the 3.5mm audio jack for enhanced sound.
- **Chromecast Interface:** Connect a Chromecast device for streaming.

**Note: This projector does not support built-in WiFi or Bluetooth connectivity. For streaming services like Netflix, Amazon Prime, or Hulu, an external streaming device such as an Amazon Fire Stick or Roku Stick connected via HDMI is required due to HDCP copyright restrictions.**



Image: A group of people enjoying a movie projected by the ELEPHAS Mini Projector BL128, which is connected to a TV stick for content.

## 5.3 Adjusting Projection Size and Zoom

The projector supports a screen size of up to 200 inches. Use the zoom function (50%-100%) via the remote control to adjust the image size without moving the projector.



Image: An illustration showing the projector's zoom function, allowing the projected image size to be adjusted from 75% to 100%.

## 5.4 Audio Output

The projector features a built-in HIFI stereo speaker for clear audio. For a more immersive experience, connect external speakers or a sound system using the 3.5mm audio out port.



Image: A close-up view of the projector's built-in HIFI stereo speaker, designed for excellent sound quality.



Image: A visual representation of the projector delivering immersive sound, indicating support for Dolby Audio.

# 6. MAINTENANCE

---

## 6.1 Cleaning the Lens

Gently wipe the projector lens with a soft, lint-free cloth. Avoid using abrasive cleaners or excessive force, which can scratch the lens.

## 6.2 Cleaning the Projector Body

Use a soft, dry cloth to clean the exterior of the projector. Do not use liquid cleaners directly on the device.

## 6.3 Ventilation

Ensure the projector's ventilation ports are clear of obstructions to maintain proper airflow. The efficient heat dissipation system helps reduce fan noise and prolong the projector's lifespan.



Image: The projector operating quietly, illustrating its advanced cooling system designed to minimize fan noise.

## 7. TROUBLESHOOTING

If you encounter issues with your projector, refer to the following common problems and solutions.

### 7.1 No Image or Distorted Image

- **Check Power:** Ensure the projector is properly connected to a power source and turned on.
- **Input Source:** Verify that the correct input source (HDMI, USB, AV) is selected in the projector's menu.
- **Cable Connection:** Ensure all cables (HDMI, AV) are securely connected to both the projector and the source device.
- **Focus Adjustment:** Adjust the focus ring or use the digital focus function to sharpen the image.
- **Resolution:** Ensure the source device's output resolution is compatible with the projector (up to 1080P).

### 7.2 No Sound

- **Volume Level:** Check the volume settings on both the projector and the source device.
- **Mute Function:** Ensure the projector or source device is not muted.
- **Audio Output:** If external speakers are connected, ensure they are powered on and properly connected to the projector's audio out port.
- **Source Audio:** Verify that the audio is working on the source device itself.

### 7.3 Remote Control Not Working

- **Batteries:** Replace the batteries in the remote control.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the projector's IR receiver.

## 8. SPECIFICATIONS

Detailed technical specifications for the ELEPHAS Mini Projector BL128.

Feature	Specification
Product Dimensions	6 x 4.4 x 2.4 inches
Item Weight	1 pounds
Item Model Number	BL128
Manufacturer	ELEPHAS
Brand	ELEPHAS

Feature	Specification
Recommended Uses	Indoor/Outdoor
Special Features	1080P Full HD, 2 HiFi Stereo Speakers, 6000:1 Contrast Ratio, Adjustable Tripod, Zoom 50%-100%
Connectivity Technology	HDMI, USB, AV, Audio, Chromecast interface
Display Resolution	1920 x 1080 (1080P HD Support)
Screen Support	Up to 200 inches
Color Support	24-bit true color (more than 16.77 million colors)

## 9. WARRANTY AND SUPPORT

---

ELEPHAS provides comprehensive support for its products.

### 9.1 Warranty Information

This ELEPHAS projector comes with a **3-year factory support**. Please retain your proof of purchase for warranty claims.

### 9.2 Certifications

ELEPHAS projectors are certified with CE, FCC, and RoHS, ensuring compliance with international safety and environmental standards.

### 9.3 Customer Support

For any questions, technical assistance, or warranty inquiries, please contact ELEPHAS customer support through the official website or your purchase platform.