



Manuals.plus /

› PINDOWS /

› PINDOWS Men's Digital Sport Watch Instruction Manual

PINDOWS PDS-603

PINDOWS PDS-603 Men's Digital Sport Watch Instruction Manual

Model: PDS-603

1. INTRODUCTION

Thank you for choosing the PINDOWS PDS-603 Men's Digital Sport Watch. This multi-functional timepiece is designed for durability and precision, featuring a robust build and a variety of useful functions including multiple alarms, a stopwatch, countdown timer, dual time display, and 50-meter water resistance. Please read this manual carefully to understand the full capabilities of your watch and ensure proper operation and maintenance.

2. PRODUCT OVERVIEW

2.1 Watch Components and Buttons



LIGHT BUTTON

START/PAUSE BUTTON

DATE DISPLAY

TIME DISPLAY

ADJUSTMENT BUTTON

MODE BUTTON

FUNCTION FILE



LED Backlight



30M Meters



Week Display



1/100 Second



Countdown



3 Alarms



12/24 Hour Format



Dual Time

Figure 2.1: Diagram illustrating the watch's buttons and display areas.

- **LIGHT Button:** Activates the LED backlight.
- **START/PAUSE Button:** Used to start/pause the stopwatch or countdown, and to adjust values during setting.

- **DATE DISPLAY:** Shows the current date.
- **TIME DISPLAY:** Shows the current time (digital).
- **ADJUSTMENT Button:** Used to reset the stopwatch, switch between 12/24 hour format, and confirm settings.
- **MODE Button:** Cycles through different modes (Time, Stopwatch, Alarm, Dual Time, Countdown).

2.2 Product Dimensions

PRODUCT SIZE

WEAR BAND LENGTH



CASE DIAMETER =2.1In /54mm



DIAL CASE THICKNESS =0.78In /20mm

BAND WIDTH =0.91In /23mm

Figure 2.2: Diagram detailing the dimensions of the watch case and band.

- **Wear Band Length:** 170mm - 240mm
- **Total Length:** 9.4 inches (260mm)
- **Case Diameter:** 2.1 inches (54mm)
- **Dial Case Thickness:** 0.78 inches (20mm)
- **Band Width:** 0.91 inches (23mm)

3. KEY FEATURES

- **Multi-Functional Design:** Equipped with 3 alarm groups, 50M water resistance, a single-color night light, dual time zone display, countdown timer, stopwatch, calendar week display, and 12/24 hour format.
- **Durable and High Quality:** Features an imported Japanese movement and battery drive for precise timekeeping and long battery life. The watch utilizes IP vacuum plating and a 304 stainless steel buckle for enhanced strength, anti-oxidation properties, and resistance to fading or yellowing over time.
- **High Brightness & Comfort:** Designed with a high-brightness backlight for clear visibility in low light conditions. The dial window uses a high-transparency acrylic mirror for a cool appearance and easy readability. The case and strap are made from high-quality rubber and resin, ensuring comfortable wear.

4. SETUP AND BASIC OPERATION

4.1 Initial Setup

Your watch comes with 2 CR2 batteries pre-installed. No initial battery setup is required. If the display is dim or unresponsive, battery replacement may be necessary (refer to Section 5.3).

4.2 Time and Date Setting

1. From the normal time display mode, press the **MODE** button repeatedly until the seconds start flashing. This indicates you are in time setting mode.
2. Press the **ADJUSTMENT** button to cycle through the settings: seconds → hour → minute → year → month → day.
3. Use the **START/PAUSE** button to increase the flashing value. Hold the button to increase rapidly.
4. Once all settings are correct, press the **MODE** button to exit the setting mode and return to the normal time display.

4.3 12/24 Hour Format

In normal time display mode, press the **ADJUSTMENT** button to toggle between 12-hour (with AM/PM indicator) and 24-hour formats.

4.4 Dual Time Setting

1. Press the **MODE** button until you reach the Dual Time mode (indicated by 'T2' or similar).
2. Press and hold the **ADJUSTMENT** button until the hour digit starts flashing.
3. Use the **START/PAUSE** button to set the hour.
4. Press the **ADJUSTMENT** button to move to the minute setting.
5. Use the **START/PAUSE** button to set the minute.
6. Press the **MODE** button to exit Dual Time setting.

4.5 Alarm Setting

The watch supports 3 independent alarms (AL1, AL2, AL3).

1. Press the **MODE** button until you reach the Alarm mode (indicated by 'AL' and the alarm number).
2. Press and hold the **ADJUSTMENT** button until the hour digit starts flashing.

3. Use the **START/PAUSE** button to set the alarm hour.
4. Press the **ADJUSTMENT** button to move to the minute setting.
5. Use the **START/PAUSE** button to set the alarm minute.
6. Press the **MODE** button to exit alarm setting.
7. To activate/deactivate an alarm, in Alarm mode, press the **START/PAUSE** button. An alarm icon will appear/disappear to indicate its status.

4.6 Backlight

LED BACKLIGHT FEARLESS OF DARKNESS




Figure 4.1: The watch's LED backlight illuminated.

Press the **LIGHT** button at any time to illuminate the display for a few seconds, allowing for easy reading in dark environments.

5. ADVANCED FUNCTIONS

5.1 Chronograph (Stopwatch)

1. Press the **MODE** button until you reach the Stopwatch mode (indicated by 'STW' or similar).
2. Press the **START/PAUSE** button to start the stopwatch.
3. Press the **START/PAUSE** button again to pause the stopwatch.
4. While paused, press the **ADJUSTMENT** button to reset the stopwatch to zero.
5. Press the **MODE** button to exit Stopwatch mode.

5.2 Countdown Timer

1. Press the **MODE** button until you reach the Countdown Timer mode (indicated by 'TMR' or similar).
2. Press and hold the **ADJUSTMENT** button until the hour digit starts flashing.
3. Use the **START/PAUSE** button to set the desired countdown hour.
4. Press the **ADJUSTMENT** button to move to the minute setting.
5. Use the **START/PAUSE** button to set the desired countdown minute.
6. Press the **ADJUSTMENT** button to move to the second setting.
7. Use the **START/PAUSE** button to set the desired countdown second.
8. Press the **MODE** button to exit setting mode.
9. Press the **START/PAUSE** button to start the countdown.
10. Press the **START/PAUSE** button again to pause/resume the countdown.
11. When the countdown reaches zero, an alarm will sound. Press any button to stop the alarm.

6. CARE AND MAINTENANCE

6.1 Water Resistance (50M)



Figure 6.1: The watch is designed for 50M precision waterproofing.

Your PINDOWS PDS-603 watch is designed with 50-meter (5ATM) water resistance. This means it is suitable for:

- Cold baths
- Being drenched in rain
- Swimming
- Handwashing

IMPORTANT NOTE:

- DO NOT press any buttons while the watch is submerged in water.

- DO NOT wear the watch when taking a hot shower or using a sauna. Exposure to hot water or steam can cause water mist to enter the watch, potentially damaging internal components.
- Avoid exposing the watch to strong impacts or extreme temperatures.

6.2 Cleaning

To maintain the appearance of your watch, wipe it regularly with a soft, dry cloth. For more stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Avoid using chemical cleaners or abrasive materials.

6.3 Battery Replacement

The watch uses 2 CR2 batteries. When the display becomes dim or the watch stops functioning, it is likely time to replace the batteries. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

7. TROUBLESHOOTING

- **Watch not displaying time/blank screen:** Check if the battery needs replacement. Ensure no buttons are stuck.
- **Buttons unresponsive:** Ensure the watch is not in a locked mode (if applicable, though this model does not have a specific lock function). Try pressing the MODE button to cycle through modes. If unresponsive, battery may be low.
- **Water mist inside the watch:** This indicates a breach in the water resistance, often due to exposure to hot water/steam or pressing buttons underwater. Immediately stop using the watch and seek professional repair to prevent further damage.
- **Time is inaccurate:** Ensure the time has been set correctly. If the issue persists, the battery may be low or the movement may require servicing.

8. SPECIFICATIONS

Model Number	PDS-603
Manufacturer	PINDOWS
Dimensions (L x W x H)	25 x 5.3 x 1.8 cm
Weight	65 grams
Water Resistance	50 Meters (5ATM)
Battery Type	2 x CR2 batteries
Movement	Japanese Quartz

9. WARRANTY AND SUPPORT

PINDOWS offers a one-year refund service for this product. If you encounter any issues or require assistance with your PDS-603 watch, please refer to the electronic manuals provided or contact PINDOWS customer support through the retailer's platform where you purchased the product. We are committed to providing professional support and ensuring your satisfaction.