

Bajaj GX-75

Bajaj GX-75 750W Mixer Grinder User Manual

Model: GX-75 (410562)

1. INTRODUCTION

Thank you for choosing the Bajaj GX-75 750W Mixer Grinder. This appliance is designed to simplify your kitchen tasks, offering efficient grinding and blending capabilities. Please read this manual carefully before operating the appliance to ensure safe and optimal performance. Keep this manual for future reference.



BAJAJ GX 75 MIXER GRINDER

Your efficient kitchen
companion



**Powerful 750W
Titan Motor**



Image 1.1: The Bajaj GX-75 Mixer Grinder with its main unit and four accompanying jars.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before use.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Ensure the voltage indicated on the appliance matches your local mains voltage before connecting.
- Keep hands and utensils away from moving blades during operation to prevent severe injury.
- Always ensure the lid is securely locked in place before operating the mixer grinder.
- Unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Avoid processing extremely hot liquids to prevent pressure buildup and potential injury.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- The motor unit is equipped with an overload protector. If the motor stops due to overload, switch off the appliance, unplug it, and allow it to cool down for a few minutes before restarting.

3. PRODUCT COMPONENTS

The Bajaj GX-75 Mixer Grinder comes with the following components:

- **Main Motor Unit:** The base unit housing the 750W motor and speed control knob.
- **1.5L Liquidizing Jar:** For blending liquids, making milkshakes, and purees.
- **1.0L Dry/Wet Grinding Jar:** Suitable for grinding spices, coffee beans, and wet pastes.
- **0.4L Chutney Jar:** Ideal for small quantities of chutneys and dips.
- **1.5L Polycarbonate Blending/Juicer Jar with Fruit Filter:** For extracting juices and blending larger quantities.
- **Lids:** Secure lids for each jar.
- **Spatula:** For mixing and scraping ingredients.



Image 3.1: Overview of the 1.2L Liquidising Jar, 1L Wet Grinding Jar, 0.4L Chutney Jar, and 1.5L Juicer Jar.

4. SETUP

Follow these steps for initial setup:

1. **Unpacking:** Carefully remove all components from the packaging. Retain the packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash all jars, lids, and blades with warm soapy water. Rinse thoroughly and dry completely. Wipe the main motor unit with a damp cloth. Do not immerse the motor unit in water.

3. **Placement:** Place the motor unit on a stable, flat, and dry surface, away from heat sources and water. Ensure there is adequate ventilation around the unit.
4. **Power Connection:** Ensure the speed control knob is in the 'OFF' position before plugging the appliance into a suitable power outlet.

5. OPERATING INSTRUCTIONS

Operating your Bajaj GX-75 Mixer Grinder is straightforward. Always ensure the appliance is unplugged before attaching or detaching jars.

5.1 Attaching a Jar

1. Place the ingredients into the desired jar. Do not overfill; ensure ingredients are below the maximum fill line.
2. Securely place the lid on the jar.
3. Align the jar's locking lugs with the slots on the motor unit.
4. Gently push down and turn the jar clockwise until it locks firmly into place.

5.2 Using the Speed Control

The mixer grinder features a 3-speed rotary switch with an incher facility.

- **OFF:** The appliance is switched off. Always start and end in this position.
- **Speed 1 (Low):** For light grinding or blending.
- **Speed 2 (Medium):** For general grinding and blending tasks.
- **Speed 3 (High):** For heavy-duty grinding and quick blending.
- **Incher/Pulse:** Turn the knob counter-clockwise to the 'P' (Pulse) position and hold for short bursts of power. This is useful for coarse grinding or for quickly mixing ingredients. Release the knob to return to 'OFF'.



Image 5.1: The 3-speed control knob with pulse function on the Bajaj GX-75 Mixer Grinder.

5.3 General Usage Tips

- For best results, process ingredients in small batches.
- Do not run the mixer grinder continuously for more than 3-5 minutes. Allow a cooling period of 2-3 minutes between cycles.
- When grinding hard ingredients, add a small amount of water if necessary to facilitate grinding and prevent motor strain.
- Always ensure the appliance is switched off and unplugged before removing the jar or adding ingredients during operation.

6. CLEANING AND MAINTENANCE

Regular cleaning and proper maintenance will extend the life of your mixer grinder.

6.1 Cleaning the Motor Unit

- Always unplug the appliance before cleaning.
- Wipe the motor unit with a soft, damp cloth.
- Do not use abrasive cleaners or immerse the motor unit in water.

6.2 Cleaning Jars and Blades

- After each use, immediately rinse the jars and blades to prevent food from drying on them.
- Wash jars, lids, and blades with warm soapy water using a soft brush or sponge. Be extremely careful when handling blades as they are sharp.
- Rinse thoroughly and dry completely before storing.
- **Note:** The jars and blades are **not dishwasher safe**. Hand wash only.

7. TROUBLESHOOTING

If you encounter any issues with your mixer grinder, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Motor not starting	No power supply; Overload protector tripped; Jar not locked correctly.	Check power connection; Allow motor to cool and reset overload protector; Ensure jar is securely locked.
Burning smell from motor	Overloading; Continuous operation for too long; New motor smell (initial uses).	Reduce load; Allow motor to cool; Initial burning smell is normal for new motors, it will dissipate. If persistent, contact service.
Leakage from jar	Lid not properly secured; Worn out gasket; Overfilling.	Ensure lid is tight; Check and replace gasket if worn; Do not overfill the jar.
Ineffective grinding	Insufficient liquid; Blades are dull; Incorrect jar used for task.	Add more liquid (for wet grinding); Contact service for blade replacement; Use appropriate jar for the ingredient type.

If the problem persists after attempting these solutions, please contact Bajaj customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	Bajaj
Model	GX-75 (410562)
Power	750 Watts
Voltage	230 Volts
Number of Speeds	3 Speed with Incher Facility
Jars Included	1.5L Liquidizing Jar, 1.0L Dry/Wet Grinding Jar, 0.4L Chutney Jar, 1.5L Polycarbonate Blending/Juicer Jar
Blade Material	Stainless Steel
Body Material	Plastic
Product Dimensions (D x W x H)	8.7D x 20.5W x 11.8H Centimeters
Item Weight	4080 Grams
Special Feature	Built-in Grinder, Motor Overload Protector



Image 8.1: Dimensions of the Bajaj GX-75 Mixer Grinder main unit.

9. WARRANTY AND SUPPORT

9.1 Warranty Information

The Bajaj GX-75 Mixer Grinder comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects and faulty materials under normal domestic use. It does not cover damage resulting from misuse, neglect, accidental damage, unauthorized repairs, or normal wear and tear. Please retain your purchase receipt as proof of purchase to avail warranty services.

9.2 Customer Support

For any service, repair, or warranty claims, please contact Bajaj customer support. You can find their contact details on the warranty card included with your product or by visiting the official Bajaj website.

Manufacturer: Bajaj Electricals Ltd, #45/47 Veer Nariman Road, Mumbai-400001, Mumbai.

