

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Majority](#) /

› [Majority Belford Portable Radio User Manual](#)

## Majority BEL-BLK

# Majority Belford Portable Radio User Manual

Model: BEL-BLK

Brand: Majority

## INTRODUCTION

The Majority Belford Portable Radio is designed for convenient and reliable audio entertainment on the go. This compact AM/FM radio features a long-lasting rechargeable battery, a telescopic antenna for enhanced reception, and a headphone jack for personal listening. It is built for durability and ease of use, making it an ideal companion for various outdoor and indoor activities.

## WHAT'S IN THE BOX

- 1x Majority Belford Portable AM/FM Radio
- 1x Micro USB Charging Cable
- 1x User Guide

# What's in the box




Image: The Majority Belford radio, its packaging, and the included micro USB charging cable.

## PRODUCT OVERVIEW

The Majority Belford radio is designed with user-friendly controls and a robust build. Its compact size and integrated handle make it highly portable.



Image: Front view of the Majority Belford radio, showcasing its speaker grille and tuning dial.



Image: The Majority Belford radio with its integrated carry handle, ideal for portability.



Image: Side view highlighting the volume control and 3.5mm headphone jack.




Image: Top view displaying the AM/FM band selector and the manual tuning knob.

The radio features an analogue tuning dial with clear frequency markings for both AM and FM bands. A 'Tune' indicator light illuminates when optimal reception is achieved. The integrated telescopic antenna ensures strong signal pickup, and the foldable carry handle provides easy transport.

## SETUP

- 1. Charging the Battery:** Before first use, fully charge the radio using the supplied Micro USB cable. Connect the Micro USB end to the radio's charging port and the USB-A end to a compatible USB power adapter (not included) or a computer USB port. The 'ON/CHARGE' indicator light will illuminate red during charging and turn off when fully charged. A full charge takes approximately 3 hours and provides up to 10 hours of playback.
- 2. Extending the Antenna:** For optimal reception, extend the telescopic antenna fully. For FM reception, the antenna should be extended vertically. For AM reception, the internal ferrite bar antenna is used, and rotating the radio may improve signal.

## OPERATING INSTRUCTIONS

- Power On/Off and Band Selection:** Locate the 'BAND' switch on the top of the radio. Slide it to 'FM' for FM radio, 'AM' for AM radio, or 'OFF' to power down the unit.
- Tuning to a Station:** Rotate the 'TUNE' dial on the top right of the radio to scan for stations. The 'TUNE' indicator light (green) will glow brightest when you are accurately tuned to a strong station.
- Adjusting Volume:** Use the 'VOL' dial on the right side of the radio to increase or decrease the volume.
- Using Headphones:** For private listening, plug any standard 3.5mm headphones into the headphone jack located on the right side of the radio, below the volume dial. The internal speaker will automatically mute when headphones are connected.

Video: A demonstration of the Majority Belford AM FM Radio, showcasing its features and operation.

## MAINTENANCE

- Clean the radio with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the radio away from extreme temperatures, direct sunlight, and moisture.
- When not in use for extended periods, store the radio in a cool, dry place and ensure it is fully charged every few months to maintain battery health.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound or very low volume	Volume too low; Radio off; Headphones connected; Battery low.	Increase volume; Turn radio on; Disconnect headphones; Charge battery.
Poor reception	Antenna not extended; Weak signal area; Interference.	Fully extend antenna; Reposition radio; Move away from electronic devices.
Radio not charging	Cable not connected properly; Faulty cable/adapter; Charging port issue.	Ensure secure connection; Try a different USB cable/adapter; Contact support if issue persists.

## SPECIFICATIONS

- Product Dimensions:** 7.48 x 1.97 x 3.94 inches
- Item Weight:** 4.4 ounces
- Model Number:** BEL-BLK
- Batteries:** 1 Lithium Ion battery (included)
- Brand:** Majority
- Color:** Black
- Special Feature:** AM/FM
- Connectivity Technology:** USB
- Tuner Technology:** FM
- Power Source:** Battery Powered
- Radio Bands Supported:** FM, AM



## WARRANTY AND SUPPORT

Majority offers a **3-year extended warranty** for their products upon registration. To activate your extended warranty and gain access to all benefits and lifetime technical support, please register your Majority product within 30 days of purchase. You can find more information and register your product on the official Majority website or by contacting their customer service department. For technical support or warranty claims, please refer to the contact information provided in your user guide or visit the Majority support website. Majority is a Cambridge-UK based home audio brand with an experienced and friendly customer service department dedicated to assisting you.

© 2024 Majority. All rights reserved.

## Related Documents - BEL-BLK

 The cover of the Majority P2 Party Speaker User Manual. It features a dark blue background with the text 'Majority P2 Party Speaker' in white, 'User Manual' in smaller white text, and the 'MAJORITY' logo at the bottom.	<p><a href="#"><u>Majority P2 Party Speaker User Manual - Features, Setup, and Safety</u></a></p> <p>Comprehensive user manual for the Majority P2 Party Speaker. Learn about its features, Bluetooth connectivity, USB/SD playback, microphone usage, troubleshooting, specifications, and safety guidelines.</p>
 The cover of the Majority Naga 40 Soundbar User Manual. It features a dark blue background with the text 'Naga 40 Soundbar' in white, 'User Manual' in smaller white text, and the 'MAJORITY' logo at the bottom.	<p><a href="#"><u>Majority Naga 40 Soundbar User Manual - Setup and Operation Guide</u></a></p> <p>Get the most out of your Majority Naga 40 Soundbar with this comprehensive user manual. Learn about setup, connections, features, troubleshooting, and safety. Enhance your home audio experience.</p>
 The cover of the Majority Pulse 4 Party Speaker User Manual. It features a dark blue background with the text 'Majority Pulse 4 Party Speaker' in white, 'User Manual' in smaller white text, and the 'MAJORITY' logo at the bottom.	<p><a href="#"><u>Majority Pulse 4 Party Speaker - User Manual &amp; Features</u></a></p> <p>Comprehensive user manual for the Majority Pulse 4 Party Speaker, detailing its features, controls, setup, Bluetooth connectivity, audio playback options (USB, SD Card, Line In), microphone usage, troubleshooting guide, specifications, and warranty information.</p>
 The cover of the Majority MP3 Pro Player User Manual. It features a dark blue background with the text 'Majority MP3 Pro Player' in white, 'User Manual' in smaller white text, and the 'MAJORITY' logo at the bottom.	<p><a href="#"><u>Majority MP3 Pro Player User Manual</u></a></p> <p>User manual for the Majority MP3 Pro Player, detailing its features, operation, music management, Bluetooth connectivity, settings, troubleshooting, and warranty information.</p>

 <p><b>Homerton 2 Music System</b> User Manual  MAJORITY</p>	<p><a href="#"><u>Majority Homerton 2 Music System User Manual   Setup, Features &amp; Troubleshooting</u></a> Comprehensive user manual for the Majority Homerton 2 Music System, covering setup, controls, features like DAB/FM radio, Bluetooth, Spotify, CD playback, network connectivity, and troubleshooting.</p>
 <p><b>Majority Everest Soundbar System: User Manual and Setup Guide</b> Comprehensive guide for the Majority Everest Soundbar system, covering box contents, setup instructions, connectivity options (Bluetooth, HDMI ARC, Optical, AUX, USB), remote control functions, audio settings, and safety information.</p>	

Documents - Majority – BEL-BLK

no relevant documents