

UBeesize TBC001

UBeesize Phone Tripod Instruction Manual

Model: TBC001

Brand: UBeesize

INTRODUCTION

Thank you for choosing the UBeesize Phone Tripod. This portable and flexible tripod is designed to enhance your mobile photography and videography experience, offering stability and versatility for various shooting scenarios. Please read this manual carefully to ensure proper setup and operation of your device.

WHAT'S IN THE BOX

- Flexible Tripod
- Wireless Bluetooth Remote
- Universal Phone Holder



Image: The UBeesize Phone Tripod, showing the flexible legs, phone holder, and wireless remote control.

KEY FEATURES

- **Premium Quality Construction:** Features flexible legs made of thick premium metal with a rubber coating and sturdy foam, ensuring durability and stability. Non-skid rubber feet provide a secure grip on various surfaces.
- **Lightweight and Compact Design:** Extra-flexible legs allow for instant bending and wrapping around objects, offering diverse shot compositions. Easily straightened for storage or transport, it can also function as a selfie stick.
- **Multi-Angle Shots:** The updated clip rotates 360 degrees, supporting portrait, vertical, and high-angle phone orientations. A 360° rotatable ball joint provides smooth angle control for your phone or camera.
- **Functional Accessories:** Includes an upgraded universal phone holder (compatible with phones up to 5.23 inches wide) and a wireless Bluetooth remote (compatible with most cell phones, operating up to 30 feet away). Compatible with digital cameras and GoPro via a standard adapter screw thread.

Flexible Rotation



Horizontal Shot



Vertical Shot



High-angle Shot



Image: The flexible legs of the UBeesize tripod allow for versatile positioning, including horizontal, vertical, and high-angle shots.

Wide Compatibility



Camera



GoPro



Phone

Image: The tripod's head allows for 360-degree panoramic and vertical shooting, providing full flexibility for capturing content.

1. Attaching Your Device

1. **For Smartphones:** Extend the universal phone holder. Place your smartphone securely into the holder, ensuring it is centered and stable. The holder can accommodate phones up to 5.23 inches wide.
2. **For Cameras/GoPro:** Remove the phone holder if attached. Screw your digital camera or GoPro onto the standard adapter screw thread on the tripod's ball head until secure.



For phones up to 4.5in



For camera



**For sport camera
free camera screw Included**

Image: A smartphone securely mounted on the UBeesize tripod, ready for use.

2. Pairing the Wireless Bluetooth Remote

1. Ensure the remote has a CR2032 battery installed (included).
2. Turn on the remote by sliding the ON/OFF switch. The LED indicator will flash.
3. On your smartphone, go to Bluetooth settings and search for available devices.
4. Select "UBeesize" or a similar name from the list to pair. The LED indicator on the remote will stop flashing once paired.
5. Open your camera app. Press the appropriate button on the remote (iOS or Android) to capture photos or start/stop video recording.



Image: A detailed diagram of the UBeesize Bluetooth remote, highlighting its iOS and Android buttons and ON/OFF switch.

OPERATING INSTRUCTIONS

Adjusting the Tripod

- **Flexible Legs:** Bend and shape the tripod legs to achieve desired height and angle. Wrap them around objects like railings or branches for unique perspectives.
- **Ball Head Adjustment:** Loosen the knob on the ball head to adjust the angle of your device. Tighten the knob to secure the position. The 360° rotation allows for seamless transitions between portrait and landscape modes.
- **Selfie Stick Mode:** Straighten the flexible legs and hold the tripod by the legs to use it as a handheld selfie stick.



Image: The UBeesize tripod's flexible legs allow it to securely wrap around various objects, providing stable mounting options.

Record Wonderful Moments

Video Record



Family Photo



Live Streaming



Image: The tripod is versatile for various applications, including video recording, capturing family photos, and facilitating live streaming.

MAINTENANCE

- **Cleaning:** Wipe the tripod with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the tripod in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If the Bluetooth remote's LED indicator does not light up or pairing fails, replace the CR2032 battery.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Tripod is unstable or tips over.	Legs not properly adjusted; uneven surface; device too heavy or off-center.	Ensure legs are spread wide and evenly. Adjust legs to conform to the surface. Center your device on the holder. Check device weight against the 2.2 lbs limit.
Bluetooth remote not pairing.	Remote is off; battery low/dead; Bluetooth not enabled on phone; remote too far from phone.	Turn on the remote. Replace the CR2032 battery. Enable Bluetooth on your phone. Ensure remote is within 30 feet of your phone.
Phone not fitting in holder.	Phone is too wide; phone case is too bulky.	The holder supports phones up to 5.23 inches wide. Remove bulky phone cases if necessary.

SPECIFICATIONS






Feature	Detail
Model Name	UB-TBA00BK
Item Model Number	TBC001
Package Dimensions	9.37 x 3.46 x 2.09 inches
Item Weight	6.9 ounces
Weight Limit	2.2 Pounds
Maximum Height	20 Centimeters
Material	Plastic, Metal, Rubber, Foam
Color	Black
Tripod Head Type	Ball Heads
Remote Battery	1 CR2032 (included)
Compatible Devices	IOS and Android Smartphones (up to 5.23 inches wide), Digital Cameras, GoPro

WARRANTY AND SUPPORT

UBeesize products are manufactured to high-quality standards. For any product-related inquiries, technical support, or warranty claims, please refer to the contact information provided on the product packaging or visit the official UBeesize website. Please retain your proof of purchase for warranty purposes.

© 2025 UBeesize. All rights reserved.

Related Documents - TBC001

	<p>UBeesize TR67 Professional Video Tripod User Manual</p> <p>User manual for the UBeesize TR67 Professional Video Tripod, including assembly instructions, features, and warnings.</p>
	<p>UBeesize 10.2" Ring Light with Tabletop Tripod - Operating Instructions</p> <p>Operating instructions for the UBeesize 10.2-inch Ring Light with Tabletop Tripod, covering setup, lighting modes, and phone holder attachment for content creators.</p>
	<p>UBeesize TR50 Professional Tripod Operating Instructions</p> <p>This document provides operating instructions for the UBeesize TR50 Professional Tripod, detailing setup, adjustments, and features for cameras and smartphones.</p>
	<p>UBeesize 62-inch Selfie Stick Tripod with Bluetooth Remote - User Guide</p> <p>Learn how to set up and use your UBeesize 62-inch selfie stick tripod with Bluetooth remote for capturing photos and videos. Includes setup instructions, pairing guide, and feature descriptions.</p>
	<p>UBeesize 12-Inch Ring Light with 62-Inch Tripod Stand User Manual</p> <p>This user manual provides instructions for the UBeesize 12-inch LED ring light and 62-inch tripod stand, detailing setup, assembly, phone holder attachment, lighting modes, and package contents.</p>

10" Ring Light with Tripod Stand

Contact us: customer@ubee-size.com



— Instruction Manual —

[UBeesize 10-Inch Ring Light with Tripod Stand: Instruction Manual](#)

Comprehensive guide for the UBeesize 10-inch Ring Light with Tripod Stand, covering setup, operation, lighting modes, and Bluetooth remote shutter usage for photography and videography.