

## vidaXL shoe cabinet without door

# vidaXL Shoe Cabinet (Model: shoe cabinet without door) - Instruction Manual

Model: shoe cabinet without door | Brand: vidaXL

## 1. INTRODUCTION

Thank you for choosing the vidaXL Shoe Cabinet. This manual provides essential information for the safe assembly, installation, and maintenance of your new shoe storage unit. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: The vidaXL Shoe Cabinet, black, featuring six open compartments for shoe storage, positioned in a modern hallway setting.

### Product Overview

This shoe cabinet is designed to provide an organized storage solution for your footwear. It features six compartments and can be used as a freestanding unit or securely mounted to a wall.

- **Color:** Black
- **Material:** Engineered Wood (Particle Board)
- **Dimensions:** 31.5 x 35 x 90 cm (Length x Width x Height)
- **Number of Shelves:** 6
- **Mounting Type:** Floor-standing or Wall-mounted

## 2. SAFETY INFORMATION

**WARNING:** To prevent tipping, this product must be used with the provided wall attachment device. Failure to do so can result in serious injury or death from furniture tip-over. Always secure the cabinet to a wall according to the instructions.

- Always assemble the product on a clean, soft surface to prevent scratches.
- Ensure all screws and fasteners are tightened securely before use.
- Do not allow children to climb on or play with the cabinet.
- Distribute weight evenly across shelves to maintain stability.

## 3. ASSEMBLY INSTRUCTIONS

This product requires assembly. Please follow the step-by-step instructions provided in the packaging. Ensure all components are present before starting assembly.

**Required Tools (Not Included):**

- Screwdriver (Phillips head recommended)
- Hammer (for dowels, if applicable)
- Drill (for wall mounting)
- Level

**General Assembly Steps:**

1. Unpack all components and verify against the parts list in your package.
2. Attach the side panels to the base and top panels using the provided fasteners.
3. Insert the shelves into the designated slots or attach them with fasteners.
4. Secure the back panel to the unit.
5. Proceed to the installation section for securing the unit.



Image 3.1: Illustration of the engineered wood material construction, emphasizing its durability and finish.

**4. INSTALLATION**

The shoe cabinet can be installed as a freestanding unit or wall-mounted for added stability and safety.

**Freestanding Installation:**

Place the assembled cabinet on a flat, level surface. Ensure it is stable and does not wobble. For optimal stability, especially in households with children or pets, wall mounting is strongly recommended.

**Wall Mounting (Recommended):**

To prevent tipping, the cabinet **must** be secured to a wall using the anti-tipping device included. The type of wall material determines the appropriate mounting hardware. Consult a professional if you are unsure about the correct fasteners for your wall.

1. Position the cabinet in its desired location against the wall.
2. Mark the wall through the holes in the anti-tipping bracket (usually located at the top rear of the cabinet).
3. Drill pilot holes into the wall at the marked locations, using a drill bit appropriate for your wall type and chosen fasteners.
4. Attach the anti-tipping bracket to the wall using suitable screws and wall plugs (not always included, may need to be purchased separately based on wall type).
5. Secure the cabinet to the bracket using the provided screws.
6. Ensure the cabinet is firmly attached to the wall and does not move.



Image 4.1: Detailed dimensional drawing of the shoe cabinet, showing approximate overall dimensions of 32 cm width, 35 cm depth, and 92 cm height, with internal shelf spacing details.



Image 4.2: Back view of the shoe cabinet, illustrating the structure and potential wall mounting points.

## 5. Usage

The vidaXL Shoe Cabinet is designed for storing shoes and other small items. Each of the six compartments can hold one pair of shoes, depending on their size and style. The open design allows for easy access and ventilation.

- Place shoes neatly into the compartments.
- Avoid overloading shelves to prevent damage or instability.
- The top surface can be used for decorative items or small accessories, but do not place excessively heavy objects.



Image 5.1: Detail of the interior shelves, demonstrating the space available for shoes.

## 6. Care and Maintenance

Proper care will ensure the longevity and appearance of your vidaXL Shoe Cabinet.

- **Cleaning:** Wipe clean with a dry cloth. For stubborn marks, a slightly damp cloth followed by a dry cloth can be used. Avoid abrasive cleaners or harsh chemicals.
- **Dusting:** Regularly dust the surfaces to prevent buildup.
- **Spills:** Immediately wipe up any spills to prevent moisture damage to the engineered wood.
- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Retighten if necessary.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or material degradation.

## 7. Troubleshooting

| Problem                    | Possible Cause                                   | Solution                                                                                                                |
|----------------------------|--------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| Cabinet is wobbly/unstable | Loose fasteners; uneven floor; not wall-mounted. | Ensure all screws are tightened. Place on a level surface. <b>Wall mount the cabinet using the anti-tipping device.</b> |
| Difficulty during assembly | Incorrect part orientation; missing a step.      | Review the assembly diagram and instructions carefully. Ensure parts are oriented correctly.                            |
| Scratches on surface       | Improper handling during assembly or use.        | Use a soft cloth for cleaning. Avoid dragging objects across the surface.                                               |

## 8. Product Specifications

| Feature                | Detail                                                                                |
|------------------------|---------------------------------------------------------------------------------------|
| Brand                  | vidaXL                                                                                |
| Model Number           | shoe cabinet without door (Part Number: 809000)                                       |
| Color                  | Black                                                                                 |
| Material               | Engineered Wood (Particle Board)                                                      |
| Dimensions (L x W x H) | 31.5 x 35 x 90 cm (Approximate, refer to dimension diagram for detailed measurements) |

| Feature           | Detail                           |
|-------------------|----------------------------------|
| Item Weight       | 17.54 kg                         |
| Number of Shelves | 6                                |
| Mounting Type     | Floor-standing, Wall-mounted     |
| Assembly Required | Yes                              |
| Special Features  | Portable (when not wall-mounted) |
| GTIN              | 08720286646809                   |
| ASIN              | B09MH5V8WC                       |

## 9. WARRANTY AND SUPPORT

For warranty information, missing parts, or support inquiries, please refer to the documentation included with your purchase or contact vidaXL customer service directly. Keep your proof of purchase for warranty claims.

**Return Policy:** This product typically has a 30-day return policy for refund or replacement, as per the seller's terms. For further assistance, visit the official vidaXL website or contact your retailer.

© 2024 vidaXL. All rights reserved. Information in this manual is subject to change without notice.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

