

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Gvirtue](#) /
- › [Gvirtue Universal Vizio Control VZ-7LC Remote Instruction Manual](#)

Gvirtue VZ-7LC

Gvirtue Universal Vizio Control VZ-7LC Remote Instruction Manual

Model: VZ-7LC

Brand: Gvirtue


1. INTRODUCTION

This instruction manual provides comprehensive guidance for the Gvirtue Universal Vizio Control VZ-7LC remote. This remote is designed to replace your original Vizio Smart TV remote, offering broad compatibility and ease of use without requiring complex programming.

2. KEY FEATURES

- **Universal Compatibility:** Designed for a wide range of Vizio Smart TVs, including LED, QLED, LCD, 4K UHD, HDR, and SmartCast D, E, M, P, V Series.
- **No Programming Required:** Ready to use directly out of the box with compatible Vizio TVs.
- **Dedicated Quick Access Hotkeys:** Features direct access buttons for popular streaming services like Vudu, Netflix, Prime Video, Xumo, Hulu, iHeartRadio, Crackle, Sleep, Redbox, and Watch Free.
- **Infrared Technology:** Ensures reliable signal transmission to your television.
- **Durable Construction:** Made from ABS material with soft plastic buttons for comfortable use.

Gvirtue New Remote Fit for Vizio Smart TV



Stable Performance

Upgraded Smart Chip

No Programming Required

Farther Transmitting Distance



Image: Gvirtue VZ-7LC remote highlighting key features such as stable performance and no programming requirement.

3. COMPATIBILITY

The Gvirtue VZ-7LC remote is compatible with various Vizio Smart TV models and series, including but not limited to:

- Vizio SmartCast D, E, M, P, V Series
- Vizio 4K LED, LCD, HDR, UHD Smart TVs
- Vizio LED, QLED, LCD TVs of various sizes (e.g., 24, 32, 40, 43, 48, 50, 55, 60, 65, 70, 75 inches)

Gvirtue New Remote Fit for Vizio Smart TV



Vizio 4K LED LCD HDR TV



Vizio FHD UHD HDTV TV



Vizio Smartcast TV

Image: The Gvirtue VZ-7LC remote demonstrating compatibility with different Vizio Smart TV types.

4. GETTING STARTED: BATTERY INSTALLATION

To begin using your Gvirtue VZ-7LC remote, you will need to install two AAA batteries (not included). Follow these steps:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) ends align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Open The Battery Compartment.
According To the Battery Compartment + / -Marked.
Insert Two Fresh **AAA** Bettries.
(This Remote Control Is Not Included Battery)



Image: Detailed view of the remote's battery compartment and proper battery insertion.

5. SETUP AND INITIAL USE

The Gvirtue VZ-7LC remote is designed for immediate use with most Vizio Smart TVs without any complex setup or programming. Simply insert the batteries, point the remote at your Vizio TV, and it should function directly.

Gvirtue New Remote Fit for Vizio Smart TV



Image: The remote ready for use with a Vizio TV, emphasizing no setup is needed.

Video: Demonstration of the Gvirtue universal remote control for Vizio Smart TVs, showing its functionality and ease of use.

6. OPERATING INSTRUCTIONS: BUTTON FUNCTIONS

The Gvirtue VZ-7LC remote features a standard layout for intuitive control of your Vizio Smart TV. Below is a general overview of the main buttons and their functions:



Image: Front view of the Gvirtue VZ-7LC remote, displaying all control buttons.

- **Power Button ():** Turns the TV on or off.
- **Input:** Cycles through available input sources (HDMI 1, HDMI 2, etc.).
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and select options.
- **Back:** Returns to the previous screen or menu.
- **Home (Δ):** Accesses the SmartCast home screen or main menu.
- **CC (Closed Captioning):** Toggles closed captions on or off.
- **Volume (+/-):** Adjusts the TV volume.
- **Mute ():** Mutes or unmutes the TV audio.
- **Channel (+/-):** Changes the TV channel.
- **Numeric Keypad (0-9):** Directly enters channel numbers.

- **Quick Access Hotkeys:** Dedicated buttons for Vudu, Netflix, Prime Video, Xumo, Hulu, iHeartRadio, Crackle, Sleep, Redbox, and Watch Free for instant access to these applications.
- **Menu:** Opens the TV's main settings menu.
- **Info:** Displays information about the current program or input.



Image: The remote's quick access hotkeys for popular streaming platforms.

7. TROUBLESHOOTING

If you encounter issues with your Gvirtue VZ-7LC remote, please refer to the following common troubleshooting steps:

- **Remote Not Responding:**
 - Ensure batteries are inserted correctly with proper polarity (+/-).
 - Replace old batteries with new AAA batteries.
 - Check for any obstructions between the remote and the TV's infrared sensor.
 - Ensure you are within the effective operating range of the TV.

- **Specific Buttons Not Working:**

- Verify that the remote is pointed directly at the TV.
- Clean the remote's infrared emitter (the small LED at the front) and the TV's IR receiver with a soft, dry cloth.

- **TV Not Turning On/Off:**

- Confirm the TV is plugged into a working power outlet.
- Try using the power button directly on the TV to rule out a TV issue.



Video: A brief overview of a replacement remote for Vizio Smart TVs, demonstrating basic functionality which can be helpful for troubleshooting.

8. SPECIFICATIONS

Model Number	VZ-7LC
Brand	Gvirtue
Compatible Devices	Vizio Smart TVs (LED, QLED, LCD, 4K UHD, HDR, SmartCast D/E/M/P/V Series)
Connectivity Technology	Infrared
Power Source	2 x AAA Batteries (not included)
Material	ABS
Dimensions	17.1 x 4.7 x 2.1 cm (approx. 6.73 x 1.85 x 0.83 inches)
Weight	80 g (approx. 2.82 oz)




Image: Physical dimensions of the Gvirtue VZ-7LC remote.

9. MAINTENANCE

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the remote. Avoid using liquid cleaners or abrasive materials.
- **Battery Care:** Remove batteries if the remote will not be used for an extended period to prevent leakage. Replace batteries promptly when they are depleted.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the remote or exposing it to excessive force, as this can damage internal components.

10. WARRANTY AND SUPPORT

For any warranty claims, technical support, or further inquiries regarding your Gvirtue VZ-7LC remote control, please refer to the

contact information provided with your product packaging or visit the official Gvirtue website for customer service details.

