reiga 52-inch Modern Smart Walnut Color Ceiling Fan

reiga 52-inch Modern Smart Walnut Color Ceiling Fan User Manual

Model: 52-inch Modern Smart Walnut Color Ceiling Fan

Introduction

Thank you for choosing the reiga 52-inch Modern Smart Walnut Color Ceiling Fan. This fan is designed to provide efficient air circulation and ambient lighting for your living space. Featuring a reversible DC motor, dimmable LED light kit, and convenient remote control, it offers versatile functionality for year-round comfort. Please read this manual thoroughly before installation and operation to ensure safe and optimal performance.



Image: The reiga 52-inch Modern Smart Walnut Color Ceiling Fan, showcasing its sleek design and walnut-colored blades.

Safety Information

Always follow basic safety precautions when installing and operating electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- **Read all instructions:** Before beginning installation, read all instructions and safety information.
- **Electrical Safety:** All electrical wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.

- **Disconnect Power:** Before installing or servicing the fan, disconnect power by turning off the circuit breakers to the fan and light switch.
- **Mounting Structure:** Ensure the mounting structure (outlet box) is securely attached to the building structure and is rated for fan support of at least 35 lbs (15.9 kg).
- **Blade Clearance:** Ensure there is adequate clearance from the fan blades to the floor (at least 7 feet / 2.13 meters) and to any walls or obstructions.
- **Do not bend blade holders:** When installing, balancing, or cleaning the fan, do not bend the blade holders.
- **Avoid contact:** Do not insert objects into the path of the fan blades while the fan is operating.

Package Contents

Carefully unpack all components and ensure you have received all items listed below. If any parts are missing or damaged, contact customer support immediately.

- Motor Housing Assembly
- Fan Blades (3)
- Light Kit Assembly
- Remote Control with Wall Mount
- Downrods (6-inch and 10-inch options)
- Mounting Bracket
- Canopy
- Hardware Pack (screws, washers, wire nuts)
- Instruction Manual



Image: A visual representation of the fan's components, including the unique wave-shaped blades, interchangeable downrods (6" and 10"), and the matte lamp cover.

Setup and Installation

Professional installation is recommended. Ensure power is disconnected at the circuit breaker before proceeding.

1. **Prepare the Mounting Location:** Ensure the electrical outlet box is securely fastened to the building structure and can support the fan's weight.
2. **Install the Mounting Bracket:** Attach the mounting bracket to the outlet box using the provided screws and washers.
3. **Assemble the Downrod:** Select the desired downrod (6-inch or 10-inch) and insert it into the motor housing. Secure with the provided pin and screw.
4. **Hang the Fan:** Carefully lift the fan assembly and hang it on the mounting bracket hook.
5. **Perform Electrical Wiring:** Connect the fan's electrical wires to the household wiring according to the wiring diagram in the detailed manual. Use the provided wire nuts to secure connections. Ensure all connections are tight and properly

insulated.

6. **Attach the Canopy:** Slide the canopy up to the ceiling and secure it to the mounting bracket with the canopy screws.
7. **Install the Fan Blades:** Attach each fan blade to the motor housing using the blade screws. Ensure they are securely fastened.
8. **Install the Light Kit:** Connect the light kit wires to the fan's light kit wires. Secure the light kit assembly to the bottom of the fan motor housing.



Image: The reiga ceiling fan seamlessly integrated into a modern living room setting, demonstrating its aesthetic appeal post-installation.

Operating Instructions

Your reiga ceiling fan comes with a multi-functional remote control for convenient operation.

Remote Control Functions



Image: The remote control for the reiga ceiling fan, illustrating its buttons for fan speed, light dimming, and color temperature adjustments (Warm Light, Full Light, Cool Light).

- **Power Button:** Turns the fan and light ON/OFF.
- **Fan Speed Control:** Adjusts fan speed from 1 (lowest) to 6 (highest).
- **Light ON/OFF:** Toggles the light on or off.
- **Light Dimming:** Press and hold the light button to dim or brighten the light.
- **Color Temperature Adjustment:** Cycle through warm white (2700K), neutral white (3500K), and cool white (5000K) light settings.
- **Timer Function:** Set the fan to turn off automatically after 1 hour, 3 hours, or 8 hours.
- **Reverse Function:** Changes the direction of the fan blades.

Reversible DC Motor (Summer/Winter Mode)

The reversible DC motor allows you to optimize air circulation for different seasons.

- **Downdraft Mode (Summer):** Blades rotate counter-clockwise, pushing cool air down. This creates a wind-chill effect, making you feel cooler.

- **Updraft Mode (Winter):** Blades rotate clockwise, drawing air up towards the ceiling. This helps to circulate warm air trapped near the ceiling, distributing it throughout the room and reducing heating costs.




Image: A visual explanation of the fan's reversible function, showing downdraft mode for summer (air pushed down) and updraft mode for winter (air drawn up).

Maintenance

Regular maintenance will help prolong the life and performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **Blade Cleaning:** The fan blades can be easily cleaned with a duster or a soft, damp cloth.
- **Tighten Screws:** Periodically check all screws and connections for tightness. Retighten as necessary.
- **No Lubrication Needed:** The fan's motor is permanently lubricated and does not require oiling.

Troubleshooting

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker and wall switch; Verify all wire connections are secure; Replace remote battery or re-pair remote.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use a balancing kit (not included) to balance blades; Ensure mounting bracket is securely fastened.
Light does not work	Loose wire connection to light kit; Faulty LED module.	Check light kit wiring connections; Contact customer support for LED module replacement if necessary.
Noisy operation	Loose screws; Fan not level; Motor hum.	Check and tighten all screws; Ensure fan is installed level; A slight motor hum is normal for DC motors, but excessive noise may indicate an issue.

Specifications

Feature	Detail
Brand	reiga
Model	52-inch Modern Smart Walnut Color Ceiling Fan
Fan Size	52 inches
Color	Walnut
Motor Type	Reversible DC Motor
Light Kit	Dimmable LED Light Kit
Control Method	Remote Control
Speed Settings	6 Speeds
Timer Function	1H, 3H, 8H
Room Type Recommendation	Living Room, Bedroom, Patio, Office, Kitchen




Image: Diagram illustrating the dimensions of the 52-inch ceiling fan, including its 13-inch height and 52-inch blade span.

Warranty and Support

reiga products are manufactured to the highest quality standards. For warranty information or technical support, please contact reiga customer service. Keep your purchase receipt as proof of purchase.
For assistance, please visit the official reiga store or contact their customer support channels as listed on their website or product packaging.
Online Store: reiga Official Store on Amazon

© 2024 reiga. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question