

[Manuals.plus](#) /

> [E ECSEM](#) /

> E ECSEM Smartwatch Band Instruction Manual

E ECSEM SENBONO S09/S09 Plus/S80/S82/ S30/Z08S Compatible Bands

Instruction Manual: E ECSEM Replacement Watch Straps

Compatible with SENBONO S09/S09 Plus/S80/S82/ S30/Z08S Smartwatches

PRODUCT OVERVIEW

These E ECSEM replacement watch straps are designed for compatibility with various SENBONO smartwatch models, including S09, S09 Plus, S80, S82, S30, and Z08S. Crafted from high-performance silicone, these bands offer a comfortable, breathable, and lightweight wearing experience. They feature a quick-fit design for easy installation and removal, and are available in multiple colors to suit individual preferences.



Image: A collection of E ECSEM silicone watch bands in different colors (black, blue, white, green) attached to a smartwatch, illustrating the product's aesthetic and variety.

INSTALLATION GUIDE

The E ECSEM replacement watch straps are designed for quick and direct installation using integrated metal pins. No special tools are required for attachment or removal.

Attaching the Band:

1. Locate the quick-release pin on the back of the watch band.
2. Align one end of the pin with the corresponding lug hole on your SENBONO smartwatch.
3. While holding the quick-release lever, gently push the pin inwards and guide the other end into the opposite lug hole.
4. Release the lever and ensure both ends of the pin are securely seated within the watch lugs. Gently tug on the band to confirm it is locked in place.

Removing the Band:

1. Turn your smartwatch over to access the quick-release pin on the underside of the band.
2. Pull the quick-release lever inwards to retract the pin.
3. Gently detach the band from the watch lugs.



Image: A detailed view of the quick-release pin on the watch band, highlighting the mechanism used for installation and removal.




Image: The two separate components of a black and grey silicone watch band, illustrating how they connect to the smartwatch.

WEARING AND USAGE

These silicone bands are designed for comfort and flexibility, suitable for daily wear and various activities. The material is lightweight and breathable, making it ideal for extended use.

- **Adjustable Fit:** The bands are designed to fit most wrist sizes, typically ranging from 5.5 inches to 8.0 inches. Utilize the tang buckle to adjust the strap for a secure yet comfortable fit.
- **Air Circulation:** For optimal comfort and skin health, wear your band loosely enough to allow for air circulation between the band and your skin. This helps prevent moisture buildup and irritation.
- **Versatile Use:** The durable silicone material is suitable for workouts, outdoor activities, and everyday business or casual wear.

MAINTENANCE AND CARE

Proper care will extend the lifespan of your watch bands and maintain hygiene.

- **Regular Cleaning:** Clean and dry the back side of the band regularly, especially after workouts or periods of sweating.

- **Cleaning Method:** Simply rinse the band with clean water. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Always ensure the band is thoroughly dry before reattaching it to your smartwatch and wearing it.

TROUBLESHOOTING

Skin Irritation or Discomfort:

If you notice any signs of skin irritation, redness, itching, or experience any discomfort while wearing the band:

- Immediately discontinue use of the band.
- Clean your wrist and the band thoroughly.
- Ensure the band is not worn too tightly.
- If symptoms persist, consult a healthcare professional.

Band Fading or Breaking:

While these bands are designed for durability, if you experience issues such as fading or breakage within the warranty period, please refer to the "Warranty and Support" section for assistance.

SPECIFICATIONS

Product Type	Replacement Smartwatch Band
Brand	E ECSEM
Compatible Models	SENBONO S09, S09 Plus, S80, S82, S30, Z08S Smartwatches
Material	High-Performance Silicone
Clasp Type	Tang Buckle
Wrist Size Compatibility	5.5" - 8.0" (adjustable)
Features	Quick-fit design, lightweight, breathable, flexible, multi-color options

WARRANTY AND SUPPORT

E ECSEM stands behind the quality of its products. Your replacement watch band is covered by a warranty for a period of **12 months** from the date of purchase.

- **Warranty Coverage:** If your band fades or breaks within the first 12 months of purchase, you may be eligible for a replacement or a full refund.
- **Contacting Support:** For any issues or concerns regarding your E ECSEM watch band, please contact us directly. Our customer service team is available to provide assistance and resolve any problems you may encounter.

Please retain your proof of purchase for warranty claims.