

[Manuals.plus](#) /

› [tectake](#) /

› tectake® Corner Desk (Model 404231-2) Instruction Manual

tectake 404231-2

tectake® Corner Desk Instruction Manual

Model: 404231-2 | Brand: tectake

1. INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your tectake® Corner Desk (Model 404231-2). Please read these instructions carefully before assembly and use to ensure safe and correct operation. Keep this manual for future reference.



Image 1.1: The tectake Corner Desk (Model 404231-2) in a typical home office environment. This L-shaped desk features a dark wood finish and a black steel frame, designed for efficient use of corner spaces.

2. SAFETY INSTRUCTIONS

To prevent injury or damage to the product, observe the following safety guidelines:

- Always follow the assembly instructions provided.
- Ensure all fasteners (screws, bolts) are tightened securely before use. Periodically check and re-tighten as necessary.
- Do not overload the desk surface or the side shelves. Refer to the 'Specifications' section for weight limits.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Assemble and use the desk on a stable, level surface to prevent tipping.
- Avoid placing hot items directly on the desk surface without protection.
- Do not stand or sit on the desk.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- MDF Desk Panels (L-shaped desktop and shelf boards)
- Steel Frame Components
- Polyethylene Adjustable Feet
- Assembly Hardware (screws, bolts, Allen key)
- Assembly Instructions (this document)



Image 3.1: An illustrative diagram detailing the overall dimensions and the structure of the tectake Corner Desk, including the main desktop and integrated side shelves. This image also lists the package contents.

4. SETUP AND ASSEMBLY

Assembly of the tectake Corner Desk requires careful attention to the provided step-by-step instructions. It is recommended that two people perform the assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface (e.g., carpet or blanket) to prevent scratches during assembly.

2. **Identify Parts:** Refer to the parts list in the separate assembly instructions to identify each component.
3. **Assemble Frame:** Begin by assembling the steel frame components according to the diagrams. Do not fully tighten screws until all parts are loosely connected.
4. **Attach Desktop Panels:** Secure the MDF desktop panels to the assembled steel frame. Ensure proper alignment.
5. **Install Side Shelves:** Attach the side shelf boards to their designated positions within the frame.
6. **Tighten All Fasteners:** Once all components are in place, systematically tighten all screws and bolts using the provided tools. Do not overtighten.
7. **Attach Adjustable Feet:** Screw the polyethylene adjustable feet into the bottom of the desk legs.
8. **Level the Desk:** Place the desk in its desired location. Adjust the plastic feet by rotating them to ensure the desk is stable and level on uneven floors.




Image 4.1: This image highlights the removable shelf feature, designed to accommodate a PC tower or other equipment, offering flexible storage options within the side compartment.

DIMENSIONS

Dimensions totales

138 x 138 x 75,5 cm

Profondeur du plateau

50 cm

Compartiment latéral supérieur

24 x 48 x 36 cm

Compartiment latéral inférieur

24 x 48 x 24,5 cm

TECHNICITÉS

Capacité de charge

Du plateau 200 kg

Par compartiment latéral 25 kg

Poids env. 25 kg


Matériaux MDF mélaminé, acier
revêtu par poudre, polyéthylène

CONTENU

Bureau d'angle

Matériel de montage

Instructions de montage



Les mesures sont approximatives

Image 4.2: A close-up view showing the wood grain texture of the MDF panel and the adjustable plastic feet. The feet can be rotated to compensate for uneven floor surfaces, ensuring desk stability.

5. OPERATING INSTRUCTIONS

The tectake Corner Desk is designed for versatile use in various settings, including home offices, study areas, or gaming setups.

- **Work Surface:** Utilize the spacious L-shaped desktop for your computer, monitor, keyboard, and other work essentials.
- **Integrated Storage:** The two lateral shelves provide convenient storage for books, documents, office supplies, or small electronic devices. The upper shelf measures approximately 24 x 48 x 36 cm, and the lower shelf measures approximately 24 x 48 x 24.5 cm.
- **PC Tower Accommodation:** One of the side shelves can be removed to create a larger space, ideal for housing a PC tower, as shown in Image 4.1.
- **Weight Distribution:** Distribute weight evenly across the desktop and shelves to maintain stability and prevent damage.

6. MAINTENANCE

Proper care will extend the life and appearance of your desk.

- **Cleaning:** The melamine-coated MDF surface is easy to clean. Wipe with a soft, damp cloth. For stubborn marks, use a mild soap solution and dry immediately.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, solvents, or strong chemicals, as these can damage the finish.
- **Regular Checks:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten if any looseness is detected.
- **Protection:** Use coasters for drinks and protective pads under heavy or sharp objects to prevent scratches and water damage.

7. TROUBLESHOOTING

If you encounter issues with your tectake Corner Desk, refer to the following common solutions:

- **Desk is Unstable/Wobbly:**
 - Ensure all assembly screws are fully tightened.
 - Adjust the polyethylene feet on the bottom of the legs to compensate for uneven floor surfaces.
- **Parts Missing or Damaged:**
 - Carefully check all packaging materials.
 - Contact tectake customer support with your model number (404231-2) and details of the missing or damaged part.
- **Difficulty During Assembly:**
 - Review the assembly diagrams and instructions carefully.
 - Ensure components are oriented correctly before tightening.
 - Having a second person assist with assembly can often resolve difficulties.

8. SPECIFICATIONS

Feature	Detail
Model Number	404231-2
Total Dimensions (L x W x H)	Approx. 138 x 138 x 75.5 cm
Desktop Depth	Approx. 50 cm
Upper Side Compartment (L x W x H)	Approx. 24 x 48 x 36 cm
Lower Side Compartment (L x W x H)	Approx. 24 x 48 x 24.5 cm
MDF Panel Thickness	Approx. 1.5 cm
Steel Frame Dimensions (L x W)	Approx. 2 x 2 cm
Plastic Feet Adjustment Range	Approx. 1.5 cm

Feature	Detail
Desktop Load Capacity	200 kg
Side Compartment Load Capacity	25 kg per compartment
Product Weight	Approx. 25.2 kg
Materials	MDF panel, powder-coated steel, polyethylene
Assembly Recommendation	2 people

9. WARRANTY AND SUPPORT

Your tectake Corner Desk is covered by standard legal guarantees. Additionally, a 30-day return policy may apply depending on your purchase terms.

For any questions, missing parts, or support needs, please contact tectake customer service. Have your model number (404231-2) and purchase information ready for efficient assistance.