Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vicco 3700

Vicco Elias Coffee Table Instruction Manual

Model: 3700 | Anthracite/Gold Power Oak

1. Introduction

Thank you for purchasing the Vicco Elias Coffee Table. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and proper use of your new furniture. Please read this manual carefully before beginning assembly and retain it for future reference.

Important Safety Information: Furniture that is not anchored can tip over. To prevent this piece of furniture from tipping over, it must be anchored to the wall. For this purpose, use fastening fittings suitable for domestic walls. If you have any questions, consult your local hardware store. Please follow each step of the instructions carefully.

2. Product Overview

The Vicco Elias Coffee Table features a modern design with a rotatable tabletop and an open shelf for versatile functionality. It is constructed from 16 mm easy-care chipboard with a melamine resin coating.

2.1. Dimensions

Measurement	Value
Width	70 cm
Height	34 cm
Depth	70 cm
Item Weight	19.4 kg
Maximum Weight Recommendation	7 kg

Detailed dimensions are also illustrated in the images below.

2.2. Components

The package includes the following:

- Coffee table components
- Assembly instructions (this manual)
- Assembly material (hardware)

2.3. Product Features

- Rotatable tabletop for flexible use.
- Integrated open shelf for storage.
- Scratch-resistant surface.
- Easy-care melamine resin coating.



Figure 2.1: The Vicco Elias Coffee Table, showcasing its two-tiered design with a rotatable top surface. The top surface is a light wood grain, and the base is anthracite.



Figure 2.2: The coffee table positioned in a living room next to a grey sofa, demonstrating its functional use with items placed on its surface. The top section is rotated slightly to reveal the lower storage area.




Figure 2.3: A diagram illustrating the precise dimensions of the coffee table, including its width (70 cm), depth (70 cm), and overall height (34 cm), along with the individual heights of its components.

3. Setup and Assembly

Before starting assembly, ensure you have all components and tools listed in the packaging. It is recommended to assemble the table on a soft, clean surface to prevent scratches.

3.1. Required Tools (Not Included)

- Screwdriver (Phillips head recommended)
- Hammer (for dowels, if applicable)
- Measuring tape (optional, for placement)

3.2. Assembly Steps

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list provided in the box.
2. **Assemble Base Unit:** Follow the numerical sequence in the provided assembly diagram to connect the base panels using the supplied hardware. Ensure all connections are secure.
3. **Attach Rotatable Mechanism:** Secure the rotatable mechanism to the top of the base unit as indicated in the instructions. Pay attention to alignment.
4. **Attach Top Panel:** Mount the top panel onto the rotatable mechanism. Ensure it is firmly attached and can rotate smoothly.
5. **Install Feet/Glides:** Attach the plastic feet or glides to the bottom of the table to protect your floor. Note: The feet are plastic with a nail; ensure they do not scratch your floor if moving the table.
6. **Wall Anchoring (Crucial Safety Step):**

   To prevent tipping, this coffee table *must* be anchored to a wall. Use appropriate fastening fittings for your specific wall type (e.g., plasterboard, brick, concrete). Consult a local hardware store if unsure about suitable fittings. Secure the anti-tip device to the table and then to the wall according to the diagram.

Refer to the detailed assembly diagrams included in your product packaging for visual guidance on each step.



Figure 3.1: An example of the assembly diagram, showing the components and steps required for putting the coffee table together. This image provides a visual representation of the parts and their connections.

4. Operation

4.1. Using the Rotatable Top

The top surface of the Elias coffee table is designed to rotate, allowing for flexible configuration and access to the lower storage area. Gently push or pull the top panel to rotate it to your desired position. Avoid forcing the rotation if resistance is met.



Figure 4.1: The coffee table with its top surface rotated, demonstrating how the design allows for dynamic positioning and reveals the hidden storage compartment.



Figure 4.2: The coffee table with its top surface fully extended, showcasing the maximum rotation and the accessible storage space beneath.

4.2. Storage Area

The lower section of the table provides an open shelf for storing items such as books, magazines, or remote controls. Ensure items placed in the storage area do not obstruct the rotation of the top panel.

4.3. Weight Capacity

The maximum recommended weight for the table is 7 kg. Avoid placing excessively heavy items on the table, especially on the rotatable top, to prevent damage or instability.

5. Maintenance and Care

Proper care will extend the life and appearance of your Vicco Elias Coffee Table.

5.1. Cleaning

- Wipe the table surfaces with a damp cloth.

- For stubborn marks, use a mild, non-abrasive cleaner.
- Dry immediately with a clean, soft cloth to prevent water spots.
- Avoid using harsh chemicals, abrasive cleaners, or scouring pads, as these can damage the melamine resin coating.

5.2. General Care

- Avoid direct exposure to prolonged sunlight or extreme temperatures, which can cause fading or warping.
- Use coasters under hot or cold beverages to protect the surface.
- Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary.
- Do not drag the table across the floor; lift it when moving to prevent damage to the feet and floor.

6. Troubleshooting

This section addresses common issues you might encounter with your coffee table.

Problem	Possible Cause	Solution
Table wobbles or is unstable.	Loose assembly screws or uneven floor.	Check and tighten all assembly screws. Ensure the table is on a flat, level surface. If the floor is uneven, use shims under the feet. Ensure wall anchoring is correctly installed.
Top panel does not rotate smoothly.	Obstruction in the rotation mechanism or dirt/debris.	Check for any objects obstructing the rotation path. Clean the area around the rotating mechanism. Ensure the mechanism was installed correctly during assembly.
Scratches on surface.	Sharp objects or abrasive cleaning.	While the surface is scratch-resistant, it is not scratch-proof. Use coasters and avoid dragging objects. Minor scratches may be camouflaged with furniture repair pens (test in an inconspicuous area first).

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact Vicco customer support.

7. Specifications

Attribute	Detail
Brand	Vicco
Model Number	3700
Colour	Anthracite/Gold Power Oak
Product Dimensions (LxWxH)	70 x 70 x 34 cm
Material	Engineered Wood (16 mm chipboard with melamine resin coating)
Special Features	Rotatable Top, Scratch Resistant

Attribute	Detail
Item Weight	19.4 kg
Maximum Weight Recommendation	7 kg
Product Care Instructions	Wipe with Damp Cloth
ASIN	B09MJL1JTH

8. Warranty and Support

8.1. Warranty Information

For information regarding the warranty period and terms for your Vicco Elias Coffee Table, please refer to the documentation provided with your purchase or contact the retailer where the product was acquired. General return policy is 30 days for refund/replacement.

8.2. Customer Support

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact Vicco customer support or the seller directly. You can often find contact information on the seller's page or within your purchase confirmation.
Seller: ok-living
For more products and information from Vicco, visit the official store:Vicco Store on Amazon

© 2024 Vicco. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09MJL1JTH

More documents and user manuals: **https://manuals.plus/**