

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [tectake](#) /

> [tectake Nottingham Industrial Side Table - Model 404264 Instruction Manual](#)

**tectake 404264**

# tectake Nottingham Industrial Side Table - Model 404264

Instruction Manual

## 1. INTRODUCTION

---

This manual provides essential information for the safe and correct assembly, operation, and maintenance of your tectake Nottingham Industrial Side Table, Model 404264. Please read these instructions carefully before assembly and retain them for future reference.

The tectake Nottingham side table features a robust design with an industrial aesthetic, combining elegant wood-look shelves with a solid black steel frame. It offers versatile storage and display options for various living spaces.

## 2. SAFETY INFORMATION

---

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum load capacities specified in the 'Specifications' section.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Avoid placing hot items directly on the surface without protection.
- Do not stand or climb on the table.

## 3. PACKAGE CONTENTS

---

Before beginning assembly, verify that all components listed below are present and undamaged:

- Side Table Components (MDF panels, steel frame parts)
- Assembly Hardware (screws, bolts, plastic feet, etc.)
- Assembly Guide (this manual)

If any parts are missing or damaged, please contact tectake customer support.

## 4. SETUP AND ASSEMBLY

---

The tectake Nottingham side table is designed for quick and easy assembly. Follow the steps provided in the included assembly guide (if separate) or the general instructions below.

1. Unpack all components and lay them out on a clean, soft surface to prevent damage.
2. Identify the steel frame components and the MDF shelves.
3. Attach the steel frame parts together using the provided screws and tools. Ensure the diagonal braces are correctly oriented for stability.
4. Secure the MDF shelves to the steel frame at the designated levels.
5. Install the height-adjustable plastic feet onto the bottom of the steel frame. Adjust them to ensure the table is level and stable on your floor.
6. Once fully assembled, gently test the table's stability before placing any items on it.



This image displays the combination of cool metal and warm wood, creating a rustic aesthetic. It also emphasizes the solid powder-coated steel frame that ensures maximum stability.



This image highlights the easy-to-clean surface, which can be wiped with a damp cloth, and the height-adjustable anti-slip plastic feet that ensure stability.

## 5. OPERATING INSTRUCTIONS

---

The tectake Nottingham side table is designed for versatile use as a storage and display unit in various rooms.

- **Placement:** Due to its compact, square form, the table can be placed in corners, next to sofas, beds, or as a standalone accent piece.
- **Storage:** Utilize the three levels for practical storage of books, magazines, remote controls, or other household items.
- **Display:** The shelves are ideal for displaying decorative items, plants, photo frames, or small lamps.
- **Load Capacity:** Adhere to the specified load capacities for each shelf to ensure stability and longevity of the product. (Refer to Section 7: Specifications).



This image details key features such as the robust MDF board with a warm wood look, the stable powder-coated steel frame with X-braces, high load capacity (75 kg for the top shelf, 50 kg for lower shelves), 100% stability with adjustable anti-slip feet, and easy cleaning.

## 6. MAINTENANCE

---

Regular maintenance will help preserve the appearance and functionality of your side table.

- **Cleaning:** The surfaces are easy to maintain. Wipe the table with a dry or slightly damp cloth. Avoid

using harsh chemicals or abrasive cleaners, which can damage the finish.

- **Dusting:** Regularly dust the surfaces to prevent buildup.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Feet Adjustment:** Re-adjust the plastic feet if the table becomes wobbly on uneven surfaces.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your side table, consider the following common solutions:

- **Wobbly Table:** Check if all screws are tightened. Adjust the height of the plastic feet on the bottom of the legs to compensate for uneven floors.
- **Scratches/Damage:** For minor scratches on the wood-look surface, furniture repair pens or waxes may be used. For significant damage, contact customer support.
- **Assembly Difficulties:** Review the assembly instructions carefully. Ensure all parts are correctly oriented before tightening screws. Do not force parts together.

## 8. SPECIFICATIONS

---

<b>Overall Dimensions (WxDxH)</b>	approx. 40.5 x 40.5 x 60.5 cm
<b>Top Shelf Dimensions (WxD)</b>	approx. 40 x 40 cm
<b>Lower Shelves Dimensions (WxD)</b>	approx. 35 x 39 cm
<b>Distance between Top and Middle Shelf</b>	approx. 22.5 cm
<b>Distance between Middle and Lower Shelf</b>	approx. 23 cm
<b>Distance between Lower Shelf and Floor</b>	approx. 8.5 cm
<b>MDF Panel Thickness</b>	approx. 1.5 cm
<b>Steel Frame (WxD)</b>	approx. 2 x 2 cm
<b>Plastic Feet Adjustment</b>	approx. 1.5 cm
<b>Top Shelf Load Capacity</b>	75 kg
<b>Per Lower Shelf Load Capacity</b>	50 kg
<b>Weight</b>	approx. 7.6 kg
<b>Material</b>	MDF panel, powder-coated steel, polyethylene



This diagram illustrates the overall dimensions, individual shelf sizes, distances between shelves, material thickness, steel frame dimensions, plastic feet adjustment range, and load capacities for the top and lower shelves.

## 9. WARRANTY AND SUPPORT

---

For warranty information, product support, or to order replacement parts, please contact tectake customer

service. Refer to your purchase documentation for specific warranty terms and contact details. You can typically find support information on the official tectake website or through your retailer.