

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [Asmix](#) /
- › Asuka WCE01 Erase Eraser with Magnetic Eraser with Cleaner User Manual

Asmix WCE01

Asuka WCE01 Erase Eraser with Magnetic Eraser with Cleaner User Manual

Brand: Asmix | Model: WCE01

INTRODUCTION

The Asmix WCE01 Dry Erase Eraser with Cleaner is an innovative tool designed to maintain the cleanliness of your whiteboards. This product combines a dry erase eraser with a built-in pump-type cleaner, offering a convenient all-in-one solution for effective whiteboard maintenance. Its integrated magnet allows for easy storage directly on magnetic surfaces, eliminating the need for separate storage space. The WCE01 is designed for ease of use, ensuring your whiteboard remains clean and ready for use.

PRODUCT COMPONENTS





Figure 1: The Asmix WCE01 Dry Erase Eraser with Cleaner, showing its compact design with the integrated cleaner pump.

The WCE01 unit consists of:

- **Eraser Cover:** Made of PP (Polypropylene).
- **Eraser Pad:** Made of EVA (Ethylene-vinyl acetate) and Cotton.
- **Built-in Cleaner Bottle:** Made of PET (Polyethylene terephthalate) with a PP (Polypropylene) cap.
- **Neodymium Magnet:** Integrated for magnetic attachment to whiteboards.
- **Cleaner Solution:** 30 ml volume, containing purified water, surfactant, sodium citrate, sodium glyconate, and betaine.

SETUP

The Asmix WCE01 is designed for immediate use right out of the packaging. No assembly is required. The cleaner solution is pre-filled.

1. Unpack the WCE01 unit from its packaging.
2. Ensure the cleaner bottle is securely seated within the eraser unit.
3. The unit is now ready for use on any dry erase whiteboard surface.

Using as a Dry Erase Eraser

For general erasing of dry erase markers, simply use the eraser pad on the back of the unit.

クリーナーと一体型だから
片手で完結!!



Figure 2: Erasing whiteboard markings with the Asmix WCE01. The integrated design allows for single-handed operation.

- Hold the WCE01 unit comfortably in your hand.
- Press the black eraser pad firmly against the whiteboard surface.
- Move the eraser across the markings you wish to remove.
- The tapered parts of the eraser allow for precise corrections.

Using the Integrated Cleaner Spray

When whiteboard markings are difficult to remove with the eraser alone, or if the board appears dirty, use the integrated cleaner spray.

ボード汚れ専用クリーナー

細かいミストで
汚れをキレイに！



Figure 3: Applying the fine mist cleaner from the Asmix WCE01. This dedicated cleaner helps remove stubborn dirt and ghosting from whiteboards.

1. Position the spray nozzle towards the area of the whiteboard you wish to clean.
2. Press the pump mechanism to release a fine mist of cleaner solution onto the surface.
3. Immediately wipe the sprayed area with the eraser pad.
4. Repeat as necessary for heavily soiled areas.

Magnetic Storage

The WCE01 features a built-in neodymium magnet for convenient storage.

保管場所がない！

磁石内蔵で

ピタッと張り付く



Figure 4: The Asmix WCE01 magnetically adheres to a whiteboard, providing convenient storage and easy access.

- Simply place the back of the WCE01 unit against any magnetic whiteboard surface.
- The magnet will securely hold the eraser in place, ensuring it is always within reach and does not require separate storage space.

MAINTENANCE

Refilling the Cleaner Solution

When the cleaner solution runs out, it can be easily refilled using the Asmix WCE02 Cleaner Set (sold separately).

※別売り

／ クリーナー液がなくなっても安心 ／

ホワイトボード用クリーナー **リフィル**

リフィルがあるから量を気にせず
たくさん使える！ WCE02



交換もパカッと簡単♪



Figure 5: Steps for refilling the cleaner solution. The design allows for easy replacement of the cleaner bottle.





Figure 6: The Asmix WCE02 Cleaner Refill Bottle, available separately for continued use of your WCE01 eraser.

1. Gently pull the empty cleaner bottle out from the top of the WCE01 eraser unit.
2. Take a new WCE02 refill bottle.
3. Insert the new refill bottle into the opening until it clicks securely into place.
4. The WCE01 is now ready for continued use with fresh cleaner.

The Asmix WCE01 is designed to address common whiteboard cleaning challenges.

- 長く放置した文字が消えにくい
- 使っているうちに汚れが落ちにくい
- イレーザも欲しいけど保管場所に困る

こんな悩みを解決！

ホワイトボード用

クリーナーつき
イレーザ



Figure 7: The Asmix WCE01 is designed to solve common whiteboard issues such as difficult-to-erase text and accumulated dirt.

- **Problem:** Markings are difficult to erase with the dry eraser alone, or the whiteboard appears dirty with residue.
- **Solution:** Utilize the integrated cleaner spray. Spray a small amount of cleaner directly onto the stubborn markings or dirty areas, then immediately wipe with the eraser pad. The cleaner solution is formulated to break down dry erase ink and dirt for easier removal.
- **Problem:** Cleaner spray is not dispensing or is weak.
- **Solution:** Check the cleaner bottle's liquid level. If empty, replace it with an Asmix WCE02 refill. Ensure the bottle is properly seated and the pump mechanism is not obstructed.




Figure 8: Detailed dimensions of the Asmix WCE01 unit.

Feature	Detail
Model Number	WCE01
External Dimensions (L x W x H)	50 x 40 x 123 mm (2.0 x 1.6 x 4.8 inches)
Weight	80 g (2.8 oz) (including cleaner)
Eraser Cover Material	PP (Polypropylene)
Eraser Pad Material	EVA (Ethylene-vinyl acetate), Cotton
Magnet Type	Neodymium Magnet
Cleaner Bottle Material	PET (Polyethylene terephthalate)
Cleaner Bottle Cap Material	PP (Polypropylene)
Cleaner Volume	30 ml (1.0 fl oz)
Cleaner Contents	Purified water, surfactant, sodium citrate, sodium glyconate, betaine

Feature	Detail
Accessories	1 x Cleaner (pre-installed)
Compatible Refill	Asmix WCE02 Cleaner Set (sold separately)

WARRANTY AND SUPPORT

Specific warranty information for the Asmix WCE01 is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to the product packaging or contact the retailer or manufacturer directly.

