

Bower WA-RLSRGB12

Bower 12-inch RGB LED Selfie Ring Light Studio Kit (Model WA-RLSRGB12) - User Manual

Your comprehensive guide to setup, operation, and maintenance.

1. INTRODUCTION

This manual provides detailed instructions for the proper setup, operation, and maintenance of your Bower 12-inch RGB LED Selfie Ring Light Studio Kit. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. WHAT'S IN THE BOX

- 1 x Ring Light
- 1 x Tripod
- 1 x Remote (Wireless)

3. FEATURES

- **Premium 12-inch RGB LED Ring Light:** Offers 9 dynamic RGB colors, 3 white light modes (White, Natural, Warm), and 7 special effects for diverse lighting needs.
- **Adjustable 62-Inch Tripod:** Customizable height from 16 inches (fully collapsed) to 62 inches (fully extended) for various shooting angles and setups.
- **In-line & Wireless Remote Controls:** Manage lighting modes, effects, and brightness instantly with the attached in-line remote and a convenient wireless remote for maximum flexibility.
- **360-Degree Ball Head Adapter & Smartphone Mount:** Provides versatile setup options for professional photography and videography, securely holding your smartphone.
- **Adjustable Brightness:** Features 12 levels of brightness, suitable for capturing quality photos and videos in any lighting condition.
- **USB-Powered:** Conveniently powered via USB, enhancing portability for content creators.

4. SETUP INSTRUCTIONS

1. **Assemble the Tripod:**

Unfold the tripod legs to create a stable base. Extend the tripod to your desired height by loosening the locking knobs on the center column and then tightening them once the desired height is reached. The tripod can extend from 16 inches to 62 inches.





Figure 4.1: Fully assembled ring light kit on its adjustable tripod.

2. Attach the Ring Light:

Securely screw the 12-inch RGB LED ring light onto the top of the tripod stand. Ensure it is firmly attached to prevent wobbling.



Figure 4.2: Front view of the ring light and tripod.

3. Install the Smartphone Mount:

Attach the 360-degree ball head adapter and smartphone mount to the center of the ring light. Adjust the mount to securely hold your smartphone in either vertical or horizontal orientation.



Figure 4.3: Detailed view of the adjustable smartphone mount.

4. **Power Connection:**

Connect the USB cable from the ring light to a compatible USB power source (e.g., computer, wall charger, power bank). The in-line remote is integrated into this cable.



Figure 4.4: USB power cable with in-line remote.

5. OPERATING INSTRUCTIONS

1. **Power On/Off:**

Press the power button on the in-line remote or the wireless remote to turn the ring light on or off.

2. **Adjusting Brightness:**

Use the '+' and '-' buttons on the in-line remote or the wireless remote to cycle through 12 levels of brightness.

3. **Changing White Light Modes:**

Press the mode button on the in-line remote or the wireless remote to switch between the 3 white light modes: White, Natural, and Warm.



Figure 5.1: Ring light displaying various white light modes.

4. Changing RGB Colors and Special Effects:

Press the RGB/Effect button on the in-line remote or the wireless remote to cycle through 9 RGB colors and 7 special effects (Spectrum, Cycle, Cycle 2, Strobe, Transition, Transition 2, Swirl).



Figure 5.2: Overview of RGB colors and special effects.

5. Using the Wireless Remote:

The wireless remote connects via Bluetooth to your smartphone. Pair the remote with your device to control photo and video capture remotely, in addition to light settings.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the ring light and tripod. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use, collapse the tripod and store the kit in a dry, cool place away from direct sunlight and moisture.
- **Handling:** Handle the ring light and tripod with care to prevent damage to the LED bulbs or mechanical components.

7. TROUBLESHOOTING

- **Light not turning on:** Ensure the USB cable is securely connected to a working power source. Check if the power button on the in-line remote has been pressed.
- **Wireless remote not connecting:** Ensure Bluetooth is enabled on your smartphone and the remote is in pairing mode. Refer to your smartphone's manual for Bluetooth pairing instructions.
- **Unstable tripod:** Ensure the tripod legs are fully extended and the locking knobs are tightened. Place

the tripod on a flat, stable surface.

- **Smartphone not fitting in mount:** The mount is designed to fit most smartphones up to 3.6 inches wide. Ensure your phone is within this size range and remove any bulky cases if necessary.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	62 x 12 x 62 inches
Item Weight	3.09 pounds
ASIN	B09MMG4DZ7
Item Model Number	WA-RLSRGB12
Connectivity Technology	Bluetooth
Hardware Interface	USB
UPC	636980879468
Manufacturer	Bower
Date First Available	November 26, 2021

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Bower website or contact their customer service directly. Keep your purchase receipt for any warranty claims.

10. OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were available in the provided data. Please refer to the manufacturer's website for any available video resources.