

## Majority ESW-SPA-BLK AL

# MAJORITY Everest Spare Subwoofer User Manual

Model: ESW-SPA-BLK AL | Brand: Majority

## INTRODUCTION

This user manual provides essential information for the proper setup, operation, and maintenance of your MAJORITY Everest Spare Subwoofer. Please read this manual thoroughly before using the product to ensure optimal performance and safety.

## SAFETY INFORMATION

Always observe the following safety precautions to prevent electric shock, fire, or damage to the unit:

- Do not expose the subwoofer to rain or moisture.
- Do not place objects filled with liquids, such as vases, on the subwoofer.
- Ensure proper ventilation. Do not block any ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.

## PACKAGE CONTENTS

Please check the package carefully to ensure you have received all the following items:

- MAJORITY Everest Spare Subwoofer (1 unit)

*Note: This product is a spare subwoofer only and does not include the main soundbar unit or any connecting cables.*

## PRODUCT OVERVIEW


MAJORITY





**Figure 1: Front View**

This image displays the front of the Majority Everest Spare Subwoofer. The prominent feature is the bass reflex port located at the bottom, designed to enhance low-frequency sound output. The Majority brand logo is visible at the top.



**Figure 2: Side View**

This image shows a side view of the Majority Everest Spare Subwoofer, highlighting the circular speaker grille. This grille protects the internal subwoofer driver, which is responsible for producing deep bass frequencies.

The MAJORITY Everest Spare Subwoofer is designed to wirelessly connect with the MAJORITY Everest Soundbar system (sold separately). Follow these steps to integrate the subwoofer into your existing setup:

1. **Placement:** Position the subwoofer on a stable, flat surface, preferably on the floor, near your soundbar. Ensure there is adequate space around the unit for ventilation. Avoid placing it in enclosed cabinets or directly against walls that might impede sound.
2. **Power Connection:** Connect the subwoofer's power cable to a suitable wall outlet.
3. **Pairing:**
  - Turn on your MAJORITY Everest Soundbar.
  - Turn on the subwoofer. It should automatically enter pairing mode.
  - Refer to your MAJORITY Everest Soundbar's user manual for specific instructions on how to initiate pairing with a new subwoofer. Typically, there is a "Pair" or "Connect" button on the soundbar or its remote control.
  - Once successfully paired, the indicator light on the subwoofer will change, usually from blinking to solid.
4. **Sound Test:** Play audio through your soundbar system to confirm that the subwoofer is producing bass. Adjust the subwoofer level via your soundbar's remote control if necessary.

*Note: This spare subwoofer is intended to replace a lost or damaged subwoofer from an existing MAJORITY Everest Soundbar system. It cannot function as a standalone audio device.*

## OPERATING INSTRUCTIONS

Once paired with your MAJORITY Everest Soundbar, the subwoofer operates in conjunction with the soundbar. There are no direct controls on the subwoofer itself for volume or sound modes.

- **Power On/Off:** The subwoofer will typically power on and off automatically with the soundbar.
- **Volume Control:** Adjust the overall system volume and the subwoofer's bass level using the remote control provided with your MAJORITY Everest Soundbar.
- **Sound Modes:** Any sound modes or equalization settings applied to the soundbar system will affect the subwoofer's output accordingly.

*The product specifications mention "Remote control" as a controller type. This refers to the remote control of the main soundbar system, which controls the subwoofer wirelessly.*

## MAINTENANCE

Proper maintenance ensures the longevity and performance of your subwoofer:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the subwoofer. Do not use liquid cleaners or aerosol sprays, as they may damage the finish or internal components.
- **Ventilation:** Ensure that the ventilation openings are not blocked by dust or debris. Periodically clean them with a soft brush or vacuum cleaner.
- **Storage:** If storing the subwoofer for an extended period, disconnect it from power and store it in a cool, dry place, away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

If you encounter issues with your subwoofer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from subwoofer.	Subwoofer not powered on. Not paired with soundbar. Volume too low. Connection issue.	Ensure power cable is securely connected and unit is on. Re-pair the subwoofer with the soundbar (refer to Setup section). Increase subwoofer volume via soundbar remote. Check for any physical damage or interference.
Distorted or poor bass.	Incorrect placement. Subwoofer level too high. Source audio quality.	Adjust subwoofer placement (try moving it slightly). Decrease subwoofer volume via soundbar remote. Test with different audio sources to rule out source issue.
Subwoofer disconnects frequently.	Wireless interference. Too far from soundbar.	Move subwoofer closer to the soundbar. Ensure no other wireless devices are causing interference (e.g., Wi-Fi routers, cordless phones). Re-pair the subwoofer.

If the problem persists, please contact Majority customer support.

## SPECIFICATIONS

Feature	Detail
Model Name	MAJORITY Spare Subwoofer Everest
Model Number	ESW-SPA-BLK AL
Brand	Majority
Speaker Type	Subwoofer
Subwoofer Diameter	5.25 Inches
Maximum Output Power	150 Watts
Power (Total System)	300 Watts (System power, not subwoofer specific)
Dimensions (L x W x H)	20 x 20 x 25 cm (7.87 x 7.87 x 9.84 inches)
Item Weight	1 Kilogram (2.2 lbs)
Mounting Type	Floor Standing
Recommended Use	For ambient sound system (as part of the Everest Soundbar system)
Components Included	Majority Everest Subwoofer ONLY






## WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your original MAJORITY Everest Soundbar system or visit the official Majority website. Keep your proof of purchase for warranty claims.

Website: [www.majority.co.uk](http://www.majority.co.uk)

© 2024 Majority. All rights reserved.

Related Documents - ESW-SPA-BLK AL

	<p><a href="#">Audio-Technica Engineered Sound Wireless Systems Quick Start Guide</a></p> <p>This document provides a quick start guide for Audio-Technica's Engineered Sound Wireless Systems, including safety precautions, FCC/ISED compliance information, product overviews, and system connection examples.</p>
	<p><a href="#">Miele Calientaplatos Gourmet ESW 7010, 7020, 7030, 7110, 7120: Manual de Manejo e Instalación</a></p> <p>Manual completo de manejo e instalación para los Calientaplatos Gourmet Miele (serie ESW). Aprenda sobre la configuración, el uso, el mantenimiento y la seguridad de su electrodoméstico Miele.</p>
	<p><a href="#">Miele Appliance Drawer Installation Guide</a></p> <p>Comprehensive installation instructions and safety guidelines for Miele appliance drawers, including model-specific dimensions, electrical connection requirements, and ventilation details. Covers models ESW 7010, ESW 7110, ESW 7020, ESW 7120, and ESW 7030.</p>
	<p><a href="#">Miele Warming Drawer: Operating and Installation Instructions</a></p> <p>Comprehensive guide to operating and installing your Miele Warming Drawer (models ESW 6380, ESW 6380 FB, ESW 6580, ESW 6680, ESW 6780, ESW 6880). Covers safety, features, usage, cleaning, and installation procedures.</p>
	<p><a href="#">Návod na použitie a montáž Gourmet nahrievač riadu Miele</a></p> <p>Kompletný návod na použitie a montáž pre Gourmet nahrievač riadu Miele. Obsahuje bezpečnostné pokyny, návody na obsluhu, inštaláciu, čistenie a údržbu pre modely ESW 7010, ESW 7110, ESW 7020, ESW 7030, ESW 7120.</p>

**MAJORITY**  
BEN NEVIS II

Bluetooth Soundbar with Subwoofer  
BEN-BAR-BLK-2



Instructions Guide

### [Majority Ben Nevis II Bluetooth Soundbar with Subwoofer - Instructions Guide](#)

This document provides instructions for setting up and using the Majority Ben Nevis II Bluetooth Soundbar with Subwoofer, including controls, connections, Bluetooth operation, FM mode, troubleshooting, specifications, and safety information.