

[Manuals.plus](#) /

> [vidaXL](#) /

> vidaXL 114 cm Solid Acacia Wood Garden Bench Instruction Manual

vidaXL 316497

vidaXL 114 cm Solid Acacia Wood Garden Bench Instruction Manual

Model: 316497

1. PRODUCT OVERVIEW

This manual provides essential information for the assembly, use, and maintenance of your vidaXL 114 cm Solid Acacia Wood Garden Bench. Please read these instructions carefully before assembly and retain them for future reference.

The vidaXL garden bench is crafted from solid acacia wood with an oil finish, designed for outdoor use. It features a backrest with an engraved rose detail and curved armrests, offering both comfort and aesthetic appeal. Its robust construction ensures durability.



Image 1.1: Front view of the vidaXL 114 cm Solid Acacia Wood Garden Bench.

2. SAFETY INFORMATION

- **Assembly Required:** This product requires assembly. Follow all provided assembly instructions carefully.
- **Outdoor Use:** While designed for outdoor use, protect the wood from excessive moisture, direct prolonged sunlight, and extreme temperatures to prolong its lifespan.
- **Regular Maintenance:** Clean and re-oil the wood regularly as specified in the maintenance section.
- **Weight Capacity:** Do not exceed the recommended weight capacity (specific capacity not provided, use common sense for a garden bench).
- **Stable Surface:** Always place the bench on a flat, stable surface to prevent tipping.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Bench components (backrest, seat, armrests, legs)
- Hardware pack (screws, bolts, washers, Allen key)
- Assembly instructions (this document)

Note: A cushion is not included with this product.

4. ASSEMBLY INSTRUCTIONS

Follow the step-by-step instructions provided in the included assembly guide. It is recommended to assemble the bench on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Verify against the package contents list.
2. **Attach Legs:** Secure the legs to the seat frame using the provided hardware. Do not fully tighten screws at this stage.
3. **Connect Backrest:** Attach the backrest to the seat and leg assemblies. Ensure the engraved rose detail is facing outwards.
4. **Install Armrests:** Fasten the armrests to the backrest and leg supports.
5. **Final Tightening:** Once all components are loosely assembled, place the bench on a flat surface and gradually tighten all screws and bolts. Ensure the bench is stable and level.



Image 4.1: Example of bench components during assembly.

5. OPERATING INSTRUCTIONS

The vidaXL garden bench is designed for seating purposes in outdoor environments. Once assembled and placed on a stable surface, it is ready for use.

- **Placement:** Position the bench in your desired outdoor location, ensuring it is on a level and stable ground.
- **Seating:** The bench is designed to comfortably seat multiple individuals.
- **Movement:** When moving the bench, lift it rather than dragging to prevent damage to the legs or frame.



Image 5.1: The assembled garden bench ready for use.

6. MAINTENANCE

Proper maintenance will ensure the longevity and appearance of your acacia wood garden bench.

- **Cleaning:** Clean the bench regularly with a soft cloth and mild soapy water. Avoid harsh chemicals or abrasive cleaners. Rinse thoroughly and dry completely.
- **Oiling:** Acacia wood benefits from regular oiling to maintain its finish and protect it from weathering. Re-oil the bench periodically (e.g., every 3-6 months, or as needed based on exposure) using a suitable wood oil for outdoor furniture. Follow the oil product's instructions.
- **Protection:** During periods of harsh weather (heavy rain, snow, extreme sun), it is advisable to cover the bench or store it indoors to prevent damage.
- **Inspection:** Periodically check all screws and bolts and tighten them if necessary to ensure the bench remains stable.



Image 6.1: Detail of the acacia wood and armrest design.

7. TROUBLESHOOTING

- **Wobbly Bench:** If the bench feels wobbly after assembly, ensure all screws and bolts are fully tightened. Place the bench on a level surface. If the issue persists, disassemble and reassemble, ensuring all parts are correctly aligned.
- **Wood Discoloration/Fading:** This is common for outdoor wood furniture exposed to elements. Regular oiling (as per maintenance instructions) can help restore and protect the wood's color and finish.
- **Difficulty with Screw Holes:** If screws are difficult to insert, ensure you are using the correct hardware for each hole. Do not force screws; check alignment.

8. SPECIFICATIONS

Feature	Specification
Brand	vidaXL
Model Number	316497
Material	Solid Acacia Wood with Oil Finish
Overall Dimensions (L x D x H)	114 x 46 x 82 cm (44.9 x 18.1 x 32.3 inches)
Seat Dimensions (L x D)	96 x 41.5 cm
Seat Height from Ground	42 cm
Armrest Height from Ground	77 cm
Product Weight	11 kg
Color	Natural Wood (with engraved rose detail)
Assembly	Required
Cushion	Not Included



Image 8.1: Dimensional drawing of the garden bench.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer's terms and conditions or contact vidaXL customer service directly. Keep your purchase receipt as proof of purchase.

You can find more information and contact details on the official vidaXL website or through your point of purchase.



© 2025 vidaXL. All rights reserved.