

## Homecraft HomeCraft

# Homecraft Quick-Brewing 1000-Watt Automatic 30-Cup Coffee Urn

Model: HomeCraft | Brand: Homecraft

## IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact the manufacturer for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

## PARTS IDENTIFICATION

Familiarize yourself with the components of your Homecraft Coffee Urn:

- **Urn Body:** The main stainless steel container.
- **Lid:** Covers the top of the urn.
- **Percolator Stem:** The central tube through which water is pumped.
- **Brew Basket:** Holds the coffee grounds.
- **Spigot/Faucet:** For dispensing brewed beverages.
- **Handles:** For safe transport.

- **Water Level Markings:** Indicators inside and outside the urn for measuring water.
- **Power Cord:** Connects the urn to an electrical outlet.

# TWO-WAY DRIPLESS FAUCET

Perfect for serving  
large amounts of coffee



Image: Homecraft 30-Cup Coffee Urn components, including the main body, lid, percolator stem, and brew basket.

## SETUP

1. **Unpack and Wash:** Carefully unpack all components. Wash the urn body, lid, percolator stem, and brew basket with warm, soapy water. Rinse thoroughly and dry.
2. **Position the Urn:** Place the coffee urn on a stable, heat-resistant, and level surface away from the edge of the counter. Ensure the power cord is not dangling where it can be pulled or tripped over.
3. **Assemble Internal Parts:** Insert the percolator stem into the center hole at the bottom of the urn. Place the brew basket onto the percolator stem.
4. **Add Water:** Fill the urn with cold, fresh water up to the desired level, using the interior or exterior water level markings as a guide. Do not exceed the maximum fill line.
5. **Add Coffee Grounds:** For coffee, add the appropriate amount of coarse-ground coffee to the brew basket. Do not use fine-ground coffee as it may seep through the filter. For other hot beverages like tea or hot cider, follow specific recipe instructions for adding ingredients.
6. **Secure the Lid:** Place the lid securely on the urn. Ensure it is properly seated to prevent heat loss and maintain brewing efficiency.

7. **Connect Power:** Plug the power cord into a standard electrical outlet. The indicator light will illuminate, signaling that the brewing process has begun.

## OPERATING INSTRUCTIONS

The Homecraft Coffee Urn is designed for efficient and convenient beverage preparation.

- **Brewing:** Once plugged in, the urn will automatically begin the brewing cycle. Water will heat and percolate through the coffee grounds in the brew basket. The brewing time is approximately 1 cup per minute.
- **Keep Warm Function:** After the brewing cycle is complete, the urn automatically switches to a "keep warm" mode, maintaining the beverage at an optimal serving temperature for hours without over-brewing or burning.
- **Dispensing:** The two-way dripless faucet allows for easy serving. Lightly push down the serving handle to fill a single cup. For continuous dispensing, lift the handle upwards to lock it in the open position, ideal for filling carafes or multiple cups. Push the handle back down to stop the flow.



Image: Demonstrating the two-way dripless faucet for easy and clean beverage dispensing.

## Product Demonstration Video



Video: A product demonstration showing the features and operation of a similar coffee urn. This video illustrates general usage and

## MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your coffee urn.

1. **Cool Down:** Always unplug the urn and allow it to cool completely before cleaning.
2. **Disassemble:** Remove the lid, brew basket, and percolator stem.
3. **Wash Parts:** Wash the lid, brew basket, and percolator stem in warm, soapy water. Rinse thoroughly and dry. These components are dishwasher safe.
4. **Clean Urn Body:** Wipe the interior and exterior of the urn body with a damp cloth. Do not immerse the electrical base of the urn in water or any other liquid.
5. **Spigot Cleaning:** Ensure the spigot is clean and free of any residue. If necessary, use a small brush to clean inside the spigot.
6. **Descaling (Optional):** Over time, mineral deposits may build up. To descale, fill the urn with a solution of equal parts white vinegar and water. Brew the solution as you would coffee. After brewing, discard the solution, rinse the urn thoroughly, and brew a cycle of plain water to remove any vinegar odor.
7. **Storage:** Store the clean and dry urn in a cool, dry place.

## TROUBLESHOOTING

If you encounter issues with your Homecraft Coffee Urn, refer to the following common problems and solutions:

- **Urn does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the outlet is receiving power (test with another appliance).
- **Coffee is not brewing or brewing slowly:**
  - Verify that the water level is between the MIN and MAX markings.
  - Ensure the percolator stem is properly seated in the bottom of the urn.
  - Check that the brew basket is correctly placed on the percolator stem.
  - Ensure coffee grounds are coarse; fine grounds can clog the filter.
- **Coffee is not hot enough:**
  - Confirm the urn has completed its brewing cycle and is in the "keep warm" mode.
  - Ensure the lid is securely in place to prevent heat escape.
- **Spigot is leaking:**
  - Check if the spigot is fully closed.
  - Inspect the spigot for any debris or damage that might prevent a proper seal.

## SPECIFICATIONS

Feature	Detail
Brand	Homecraft
Model Name	HomeCraft
Capacity	30 Cup

Power Source	Electrical (1000-Watt)
Material	Stainless Steel
Product Dimensions	19.5"D x 9.5"W x 16"H
Item Weight	4.39 pounds
Special Feature	Keep Warm Setting
Operation Mode	Fully Automatic
Included Components	Filter
Dishwasher Safe Parts	Yes (Filter, Lid, Brew Basket, Percolator Stem)



### WARRANTY INFORMATION





This Homecraft product is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration of coverage. Keep your proof of purchase for any warranty claims.

### CUSTOMER SUPPORT

For further assistance, troubleshooting, or to inquire about replacement parts, please contact Homecraft customer support. Refer to your product packaging or the official Homecraft website for the most up-to-date contact information.

### Related Documents - HomeCraft

	<p><a href="#">HomeCraft 100-Cup Stainless Steel Coffee Urn HCCU100SS Instruction Manual   Nostalgia Products LLC</a></p> <p>Official instruction manual for the HomeCraft HCCU100SS 100-Cup Stainless Steel Coffee Urn. Includes setup, operation, safety guidelines, cleaning, maintenance, and warranty information from Nostalgia Products LLC.</p>
	<p><a href="#">HomeCraft CU30SS 30-Cup Stainless Steel Coffee Urn Instruction Manual</a></p> <p>Instruction manual for the HomeCraft CU30SS 30-Cup Stainless Steel Coffee Urn. Learn how to safely operate, clean, and maintain your coffee urn for optimal performance. Includes safety precautions, features, and warranty information.</p>

	<p><a href="#">HomeCraft 30-Cup Stainless Steel Coffee Urn: Operation and Maintenance Guide</a></p> <p>A comprehensive guide on how to operate and maintain the HomeCraft 30-Cup Stainless Steel Coffee Urn, including brewing coffee and heating water, along with cleaning instructions and helpful tips.</p>
	<p><a href="#">Homecraft Revive Sauna Heater Installation Manual</a></p> <p>Installation guide for Homecraft Revive sauna heaters (6kw, 7.5kw, 9kw). Covers electrical specifications, safety guidelines, sauna rock usage, control installation, and warranty. ETL approved.</p>
	<p><a href="#">Homecraft Apex Sauna Heater Installation and User Guide</a></p> <p>Comprehensive guide for installing and using the Homecraft Apex sauna heater, covering safety, electrical specifications, installation steps, and warranty information for models 10kW, 12kW, 15kW, and 18kW.</p>
	<p><a href="#">Homecraft Revive Slim Sauna Heater Installation Manual - 4kW, 5kW, 6kW</a></p> <p>Comprehensive installation manual for the Homecraft Revive Slim sauna heater (4kW, 5kW, 6kW). Covers safety, specifications, sauna rock requirements, installation procedures for the heater and control system, and warranty information.</p>