

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Simple Houseware](#) /
- › [Simple Houseware Standing Coat and Hat Hanger Organizer \(Model BO-09C-K\) Instruction Manual](#)

Simple Houseware BO-09C-K

Simple Houseware Standing Coat and Hat Hanger Organizer (Model BO-09C-K) Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Simple Houseware Standing Coat and Hat Hanger Organizer, Model BO-09C-K. Please read these instructions carefully before assembly and use to ensure proper function and longevity of the product.



Image: The Simple Houseware Standing Coat and Hat Hanger Organizer in black, showcasing its tree-shaped design and multiple hooks.

PRODUCT FEATURES

- **Space-Saving Design:** Provides ample storage for coats, hats, scarves, and handbags while minimizing floor space usage.
- **18 Hooks:** Equipped with 18 smooth, rounded hooks to protect garments from snags and scratches.
- **Stable Tripod Base:** Features a three-leg design for excellent stability and balance on various floor types.
- **Durable Metal Construction:** Built with strong metal and finished in classic black for long-lasting use and a sleek appearance.
- **Versatile Placement:** Lightweight and easy to move, suitable for entryways, bedrooms, offices, studios, and more.



Image: Close-up view of the top hooks, designed to prevent garment damage.



Image: Detail of the three-leg tripod base, illustrating its stability.

PACKAGE CONTENTS

Please verify that all parts listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

1. Main Pole Sections (A, B, C, D) - 1 each
2. Upper Hooks (E) - 3 pieces
3. Lower Hooks (F) - 6 pieces
4. Top Cap (G) - 1 piece
5. Long Screws (M6*68) (H) - 6 pieces
6. Short Screws (M6*28) (I) - 6 pieces
7. Decorative Caps (J) - 6 pieces
8. Allen Wrench (K) - 1 piece
9. Washers (L) - 6 pieces



Image: An illustration of the product's components and an 'Easy to Assemble' graphic.

ASSEMBLY INSTRUCTIONS

Basic assembly is required. Please follow these steps carefully:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Refer to the 'Package Contents' section to ensure all parts are present and undamaged.
2. **Assemble the Main Pole:** Connect pole section A to B, then B to C, and C to D. Ensure each section is securely threaded or clicked into place.
3. **Attach the Base Legs:** Insert the three base legs into the bottom section of the main pole (section D). Secure each leg using the provided long screws (H) and washers (L) with the Allen wrench (K).
4. **Install the Hooks:** Attach the upper hooks (E) to the designated slots on the upper pole sections and the lower hooks (F) to the lower pole sections. Secure them with the short screws (I) and decorative caps (J) using the Allen wrench (K).
5. **Place the Top Cap:** Place the top cap (G) onto the very top of the assembled pole.
6. **Final Check:** Gently shake the assembled coat rack to ensure all connections are tight and stable.

OPERATING INSTRUCTIONS

To ensure optimal performance and stability of your coat rack:

- **Distribute Weight Evenly:** For maximum stability, distribute coats, hats, and other items evenly across all available hooks. Avoid hanging heavy items predominantly on one side.
- **Maximum Load Capacity:** Do not exceed the maximum recommended load capacity of 35 pounds (approximately 15.8 kg). Overloading can compromise stability and damage the product.
- **Placement:** Place the coat rack on a flat, level surface to prevent tipping.



Image: The coat rack positioned in a living room, holding various garments.



Image: The coat rack in an entryway, demonstrating its use for coats, hats, and umbrellas.

MAINTENANCE

Regular maintenance will help keep your coat rack in good condition:

- **Cleaning:** Wipe the metal surfaces with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these may damage the finish.
- **Check Connections:** Periodically check all screws and connections to ensure they remain tight. Tighten any loose fasteners with the Allen wrench (K) as needed.
- **Indoor Use:** While durable, prolonged exposure to outdoor elements may affect the product's finish and lifespan. It is primarily designed for indoor use.

TROUBLESHOOTING

If you encounter any issues with your coat rack, refer to the following common solutions:

- **Instability/Wobbling:**
 - Ensure the coat rack is placed on a flat, level surface.
 - Check that all screws, especially those connecting the base legs, are securely tightened.
 - Verify that the weight of hung items is distributed evenly.
- **Hooks are Loose:**
 - Tighten the short screws (I) that secure the hooks to the pole sections using the Allen wrench (K).
- **Missing Parts:**
 - Refer to the 'Package Contents' section. If parts are missing upon arrival, contact Simple Houseware customer support for assistance.

SPECIFICATIONS

Brand	Simple Houseware
--------------	------------------

Model Number	BO-09C-K
Color	Black
Material	Metal
Product Dimensions	23"D x 23"W x 71"H (58.4 cm D x 58.4 cm W x 180.3 cm H)
Number of Hooks	18
Load Capacity	35 Pounds (15.8 kg)
Assembly Required	Yes
Item Weight	4.76 Pounds (2.16 kg)

Simple Houseware




Image: A visual representation of the coat rack's dimensions (23"D x 23"W x 71"H).

WARRANTY AND SUPPORT

For warranty information or technical support regarding your Simple Houseware Standing Coat and Hat

Hanger Organizer, please refer to the product packaging or contact Simple Houseware customer service directly. Keep your purchase receipt for warranty claims.