Baby Born 832493

BABY born Interactive Bottle and Spoon User Manual

Model: 832493

1. Safety Information

WARNING: Choking hazard due to small parts. Not suitable for children under 36 months.

Please ensure all packaging materials are removed before giving the product to a child. Regularly inspect the product for any damage or wear. Discontinue use if any part is broken or damaged. Keep these instructions for future reference.



Image: Back of product packaging displaying safety warnings and age recommendations (3+ years).

2. Product Overview

The BABY born Interactive Bottle and Spoon set is designed to enhance imaginative play with BABY born dolls. The interactive bottle produces realistic drinking sounds when used with compatible dolls, adding to the play experience.

Components:

- Interactive Bottle (pink and white)
- Removable Bottle Cap (orange)
- Spoon attachment (white, for pretend feeding)



Image: The complete BABY born Interactive Bottle and Spoon set, including the bottle, spoon attachment, and packaging.



Image: A detailed view of the interactive bottle with its orange cap securely in place.

3. Setup

Battery Installation:

The interactive bottle requires batteries to produce sounds. If the sounds are not working or are distorted, new batteries may be needed. Please note that batteries are included with the product.

1. Locate the battery compartment, typically on the underside or back of the bottle.
2. Using a small screwdriver (not included), open the battery compartment cover.
3. Insert the required batteries, ensuring correct polarity (+/-). Refer to the markings inside the compartment.
4. Securely close the battery compartment cover and tighten the screw.

Important: Always use the specified battery type. Do not mix old and new batteries, or different types of batteries. Remove exhausted batteries promptly.

Preparing the Bottle for Play:

1. Gently twist and pull the orange cap to remove it from the bottle.
2. The bottle can be filled with water for realistic play. Ensure the bottle is clean before filling.
3. Reattach the orange cap by aligning it and pushing it firmly into place.



Image: A child demonstrating how to remove the orange cap from the interactive bottle, preparing it for filling or play.

4. Operating Instructions

Feeding Your BABY born Doll:

1. Hold the interactive bottle and bring the nipple close to your BABY born doll's mouth.
2. Gently press the bottle against the doll's mouth. The bottle is designed to activate drinking sounds when in

contact with compatible BABY born dolls.

3. Listen for the realistic drinking sounds, indicating the doll is 'feeding'.
4. For pretend feeding with the spoon, attach the white spoon accessory to the bottle.



Image: A close-up view of a child holding the interactive bottle to the mouth of a BABY born doll, demonstrating the feeding action.

5. Maintenance

Cleaning:

- Wipe the interactive bottle and spoon attachment with a damp cloth.
- Do not immerse the electronic parts of the bottle in water.
- Ensure all parts are dry before storing.

Storage:

- Store the product in a clean, dry place away from direct sunlight.
- If storing for an extended period, remove batteries to prevent leakage and corrosion.

6. Troubleshooting

No Sound or Distorted Sound:

- **Check Batteries:** The most common cause for sound issues is low or dead batteries. Replace with fresh batteries, ensuring correct polarity.
- **Battery Corrosion:** If the product has been stored for a long time or old batteries were left inside, check for battery corrosion in the compartment. Clean any corrosion carefully with a cotton swab and rubbing alcohol, then insert new batteries.

- **Proper Contact:** Ensure the bottle is making proper contact with the compatible BABY born doll's mouth to activate the sound mechanism.

Water Leakage:

- **Cap Secure:** Ensure the orange cap is firmly and correctly attached to the bottle.
- **Inspect for Damage:** Check the bottle and cap for any cracks or damage that might cause leaks.

7. Specifications

Product Dimensions	2.48 x 5.2 x 7.09 inches
Item Weight	4.2 ounces
Model Number	832493
Manufacturer Recommended Age	36 months - 10 years
Release Date	February 1, 2022
Manufacturer	BABY Born

8. Warranty and Support

Information regarding specific warranty details or direct customer support contacts for this product was not available in the provided data. Please refer to the product packaging or the official BABY born website for the most current warranty information and customer service options.
For general inquiries or to explore other BABY born products, please visit theBaby Born Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question