

## Skyworth 32STD2000

# Skyworth 32-inch LED HD TV Instruction Manual

Model: **32STD2000**

## 1. INTRODUCTION

Thank you for purchasing the Skyworth 32-inch LED HD TV, Model 32STD2000. This manual provides important information regarding the setup, operation, and maintenance of your television. Please read it thoroughly before using the product and retain it for future reference.

This television features a 32-inch LED HD display with a resolution of 1366x768 pixels, 200 nits brightness, and a 60Hz refresh rate. It includes 2 HDMI ports and 1 USB port for versatile connectivity, and supports ATV/DVB-T/T2 TV reception systems.

## 2. SAFETY INFORMATION

### Important Safety Instructions:

- Do not expose the TV to rain or moisture to prevent fire or electric shock.
- Do not open the TV casing. Refer all servicing to qualified personnel.
- Ensure proper ventilation. Do not block ventilation openings.
- Place the TV on a stable, level surface to prevent it from falling.
- Keep the TV away from direct sunlight, heat sources, and extreme temperatures.
- Unplug the power cord during lightning storms or when unused for long periods.
- Use only attachments/accessories specified by the manufacturer.

## 3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Skyworth 32-inch LED HD TV (Model 32STD2000)
- Remote Control
- Power Cord
- TV Stand (2 pieces)
- Screws for Stand Assembly
- User Manual (this document)

## 4. SETUP

### 4.1 Unpacking

Carefully remove the TV from its packaging. It is recommended to keep the original packaging for future transportation or servicing needs.

### 4.2 Attaching the Stand

To attach the stand to your TV:

1. Place the TV face down on a soft, clean surface to prevent screen damage.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure the stands using the provided screws. Ensure they are tightened firmly.



Image: Front-left view of the Skyworth 32STD2000 TV with its stand attached. This illustrates the general appearance of the TV once the stand is assembled.

### 4.3 Wall Mounting (Optional)

If you prefer to wall mount your TV, you will need a VESA-compatible wall mount kit (not included). Refer to the wall mount kit's instructions for proper installation. Ensure the wall can support the weight of the TV.




Image: Rear view of the Skyworth 32STD2000 TV, highlighting the VESA mounting holes for wall installation. This shows where a wall mount bracket would attach.

#### 4.4 Connecting Power

Plug the power cord into the TV's power input, then plug the other end into a suitable wall outlet.

#### 4.5 Connecting External Devices

Your TV provides various connection ports:

- **HDMI Ports (x2):** For connecting high-definition devices like Blu-ray players, game consoles, or set-top boxes.
- **USB Port (x1):** For connecting USB storage devices to play media files.
- **Antenna/Cable Input:** For connecting an antenna or cable TV signal.





Image: Side profile of the Skyworth 32STD2000 TV, displaying the accessible input ports including HDMI and USB. This view helps identify where to connect external devices.

## 5. OPERATING

### 5.1 First-Time Setup

Upon first power-on, the TV will guide you through an initial setup process. This typically includes selecting

your language, country, and scanning for available TV channels (if an antenna is connected).

## 5.2 Remote Control Overview

The included remote control allows you to operate all TV functions. Familiarize yourself with the buttons for power, volume, channel selection, input source, and menu navigation.

*Note: A remote control is included with the TV.*

## 5.3 Basic Functions

- **Power:** Press the power button on the remote or TV to turn it on/off.
- **Volume:** Use the VOL +/- buttons to adjust the sound level.
- **Channel:** Use the CH +/- buttons to change channels.
- **Input Source:** Press the SOURCE or INPUT button to select between HDMI, USB, TV, etc.

## 5.4 Menu Navigation

Press the MENU button on the remote to access the TV's settings menu. Use the arrow buttons to navigate and the OK/ENTER button to confirm selections.

## 5.5 Picture and Sound Settings

Within the menu, you can adjust various settings:

- **Picture:** Adjust brightness, contrast, color, sharpness, and select picture modes (e.g., Standard, Dynamic, Movie).
- **Sound:** Adjust bass, treble, balance, and select sound modes (e.g., Standard, Music, Movie).

## 5.6 Timer Functions

The TV includes timer functions for convenience and parental control:

- **Sleep Timer:** Sets the TV to turn off automatically after a specified period.
- **On/Off Timer:** Schedules the TV to turn on or off at specific times.
- **Parental Control:** Allows setting restrictions on channels or programs.

# 6. MAINTENANCE

---

## 6.1 Cleaning the Screen

Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Never spray cleaner directly onto the screen.

## 6.2 Cleaning the TV Body

Use a soft, dry cloth to wipe the TV casing. Avoid using abrasive cleaners or solvents.

## 6.3 Storage

If storing the TV for an extended period, unplug it from the power outlet and cover it to protect against dust. Store in a cool, dry place.

# 7. TROUBLESHOOTING

---

Before contacting customer support, try the following solutions for common issues:

Problem	Possible Solution
No power	Ensure the power cord is securely plugged into both the TV and the wall outlet. Check if the outlet is working.
No picture, but sound is present	Check the input source. Ensure the connected device is turned on and functioning correctly.
No sound, but picture is present	Check the volume level. Ensure the TV is not muted. Check audio cables for external devices.
Remote control not working	Replace the batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.
Poor picture quality	Check antenna/cable connections. Adjust picture settings (brightness, contrast, sharpness).

## 8. SPECIFICATIONS

Technical specifications for the Skyworth 32STD2000 LED HD TV:

Feature	Detail
Brand	Skyworth
Model Number	32STD2000
Screen Size	32 inches
Display Technology	LED
Resolution	1366 x 768 pixels (HD)
Brightness	200 nits
Refresh Rate	60 Hz
TV Reception System	ATV/DVB-T/T2
Audio Output Power	2 x 6 Watts
HDMI Ports	2
USB Ports	1
Aspect Ratio	1.77:1
Dimensions with Stand (approx.)	720 x 188.5 x 480.7 mm
Dimensions without Stand (approx.)	720 x 81 x 423.4 mm
Shipping Dimensions (approx.)	73.2 x 49.8 x 12.2 cm
Shipping Weight (approx.)	4.74 kg

## 9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Skyworth website. Keep your purchase receipt as proof of purchase. For further assistance, you may contact Skyworth customer service.

---

© 2023 Skyworth. All rights reserved.