

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [EnHomee](#) /

› [EnHomee 12-Drawer Dresser Instruction Manual \(Model 12D-133DG\)](#)

EnHomee 12D-133DG

EnHomee 12-Drawer Dresser Instruction Manual

Model: 12D-133DG

Product

[Overview](#)

[Setup & Assembly](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

1. PRODUCT OVERVIEW

The EnHomee 12-Drawer Dresser is designed to provide ample storage space for your bedroom or other living areas. Featuring a sturdy metal frame, a durable wooden top, and 12 fabric drawers, this dresser combines functionality with a modern aesthetic. Its tall design optimizes vertical space, making it suitable for various room sizes.



Image 1.1: The EnHomee 12-Drawer Dresser, showcasing its design and storage capacity.

2. SETUP & ASSEMBLY

Assembly of the EnHomee 12-Drawer Dresser is designed to be straightforward. All necessary parts, anti-tip kits, adjusting feet, installation tools, and instructions are included in the package. Please follow the steps below and refer to the provided video for visual guidance.

2.1 Unpacking and Part Identification

Carefully unpack all components and verify against the parts list in your manual. Ensure all pieces are present and undamaged before beginning assembly.

2.2 Frame Assembly

1. Connect the side frames using the provided crossbars and screws. Ensure the "Double X" crossbar support is correctly installed at the back for enhanced stability.
2. Attach the top wooden board to the assembled frame using the designated screws.
3. Install the adjustable feet at the bottom of the frame. These can be adjusted to stabilize the dresser on uneven surfaces and protect your floor.



Image 2.1: Detail of the wooden top, adjustable feet, and anti-tipping kit components.



Image 2.2: The "Double X" crossbar support system on the back of the dresser frame, designed for stability.

Your browser does not support the video tag.

Video 2.3: Detailed assembly steps for the 12-Drawer Dresser, including frame construction and drawer insertion.

2.3 Drawer Preparation and Installation

1. Unfold each fabric drawer and insert the bottom panel to create a rigid structure.
2. Attach the knobs to the front of each drawer.
3. Slide the prepared drawers into their respective slots in the dresser frame.

2.4 Anti-Tipping Kit Installation

For safety, especially in households with children or pets, it is highly recommended to install the included anti-tipping kit. Secure the dresser to the wall according to the instructions provided with the kit.

3. OPERATION

The EnHomee 12-Drawer Dresser is designed for easy and smooth operation. Each fabric drawer slides effortlessly within its designated slot. The "Double X" crossbar support on the back enhances stability, preventing drawers from falling out even when fully extended.

- **Opening Drawers:** Gently pull the knob on the front of the drawer to open.
- **Closing Drawers:** Push the drawer back into the frame until it is fully seated.
- **Storage Capacity:** The 12 large fabric drawers provide ample space for various items such as clothing, accessories, and household goods. Each drawer is designed to hold a significant volume, for example, over 60 pairs of socks, 10+ trousers, or 45+ shirts.



Image 3.1: Illustration of the generous storage capacity of each drawer for different types of clothing.

Your browser does not support the video tag.

Video 3.2: Demonstration of the dresser in use, showcasing drawer functionality and overall appearance.

4. MAINTENANCE

Proper care and maintenance will ensure the longevity of your EnHomee dresser.

- **Cleaning the Frame and Top:** Use a damp or dry cloth to wipe down the metal frame and wooden top. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Cleaning Fabric Drawers:** For light cleaning, a dry cloth or soft brush can be used. For spills or stains, spot clean with a mild detergent and a damp cloth, then allow to air dry completely. Do not machine wash the fabric drawers.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Re-tighten

if necessary to maintain stability.

5. TROUBLESHOOTING

If you encounter any issues with your dresser, please refer to the following common solutions:

- **Loose Knobs:** If a drawer knob becomes loose or detaches, re-screw it firmly. If the screw hole is stripped, a small amount of strong adhesive (e.g., super glue) can be applied to the screw threads before re-inserting to secure it.
- **Drawers Sagging or Falling:** Ensure that the "Double X" crossbar support at the back of the dresser is correctly installed and tightened. This system is crucial for maintaining the structural integrity and preventing drawers from sagging or falling through. Avoid overfilling drawers with excessively heavy items, as this can put undue stress on the fabric and frame.
- **Unstable Dresser:** Verify that the adjustable feet are properly installed and adjusted to compensate for any unevenness in the floor. Ensure the anti-tipping kit is securely installed and attached to the wall.
- **Missing or Damaged Parts:** If you find any missing or damaged parts during installation, please contact customer support immediately for a satisfactory solution.

6. SPECIFICATIONS

Feature	Detail
Brand	EnHomee
Model Number	12D-133DG
Product Dimensions	34.6" W x 11.8" D x 52.3" H
Material	Metal frame, Wooden top, Fabric drawers
Number of Drawers	12
Room Type	Bedroom, Living Room, Closet, Entryway, Office
Load-Bearing Capacity (Top)	Up to 220 lbs (approximate)



Image 6.1: Dimensional diagram of the dresser, including height, width, and depth.

7. SUPPORT

For any inquiries, assistance with assembly, or to report missing/damaged parts, please contact EnHomee customer service. We are committed to providing a satisfactory solution. Please refer to your purchase documentation or the EnHomee official website for specific contact information.