

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Vente-unique](#) /

> [Vente-unique BENEDICTE Scandinavian Bed 160x200 cm - Anthracite Fabric - Instruction Manual](#)

Vente-unique BENEDICTE

Vente-unique BENEDICTE Scandinavian Bed

Model: BENEDICTE (160x200 cm, Anthracite Fabric)

1. INTRODUCTION

This instruction manual provides detailed guidance for the assembly, safe use, and maintenance of your Vente-unique BENEDICTE Scandinavian bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image 1.1: Fully assembled Vente-unique BENEDICTE Scandinavian bed, showcasing its anthracite fabric and wooden legs.

2. SAFETY INFORMATION

- **Adult Assembly Required:** This product requires assembly by adults. Keep children away from the assembly area.
- **Small Parts Warning:** The package contains small parts that could pose a choking hazard to children.

- **Weight Limit:** The maximum supported weight for this bed is **300 kg**. Do not exceed this limit.
- **Proper Tools:** Use appropriate tools for assembly as specified in the instructions.
- **Regular Checks:** Periodically check all bolts and fasteners to ensure they are tight. Retighten if necessary.
- **Placement:** Place the bed on a level, stable surface.
- **Fire Safety:** Keep the bed away from open flames and direct heat sources.

3. PACKAGE CONTENTS

Verify that all packages and components are present before starting assembly. If any parts are missing or damaged, contact customer support.

Package 1:

- Dimensions: 176 cm (L) x 76 cm (W) x 23 cm (H)
- Weight: 28 kg
- Contains: Headboard, side rails, hardware

Package 2:

- Dimensions: 203 cm (L) x 16 cm (W) x 15 cm (H)
- Weight: 11 kg
- Contains: Slatted bed base, support legs

Note: Mattress is not included with this bed frame.

4. ASSEMBLY INSTRUCTIONS

4.1. Tools Required (Not Included)

- Phillips head screwdriver
- Allen wrench (often included with hardware, but a set is useful)
- Rubber mallet (optional, for gentle tapping)

4.2. Step-by-Step Assembly

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface (e.g., a rug or blanket) to prevent scratches. Identify all parts against the parts list (not provided in this manual, refer to your product's specific parts list).
2. **Attach Legs to Frame:** Secure the pine wood legs to the bed frame sections using the provided hardware. Ensure they are tightly fastened.



Image 4.1: Detail of the bed frame corner with a wooden leg attached.

3. **Assemble Bed Frame:** Connect the headboard, footboard, and side rails. Use the appropriate bolts and washers, tightening them securely. Do not overtighten.
4. **Install Center Support:** If your bed frame includes a center support beam, install it now according to the instructions. This provides crucial stability for the slatted base.
5. **Place Slatted Bed Base:** Carefully place the slatted bed base into the assembled frame. Ensure it sits flush and is properly supported by the side rails and any center support.



Image 4.2: The bed frame with the 28-slat base installed, ready for a mattress.

6. **Final Tightening:** Once the entire frame is assembled, go back and gently tighten all bolts and screws to ensure maximum stability.

5. OPERATING INSTRUCTIONS

- **Mattress Placement:** Place your 160x200 cm mattress directly onto the slatted bed base. Ensure it is centered and fits snugly within the frame.
- **Weight Distribution:** Distribute weight evenly across the bed. Avoid concentrating heavy loads on small areas.
- **Movement:** When moving the bed, lift it rather than dragging it to prevent damage to the legs and frame.

6. MAINTENANCE

- **Cleaning Fabric:** For the anthracite polyester fabric, gently vacuum regularly to remove dust. For spills, blot immediately with a clean, damp cloth. Use a mild fabric cleaner if necessary, testing on an inconspicuous area first. Do not use harsh chemicals or abrasive cleaners.
- **Cleaning Frame:** Wipe the wooden legs and exposed frame parts with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying.
- **Hardware Check:** Every 3-6 months, inspect all bolts and screws. Retighten any that have become loose to maintain the bed's structural integrity and prevent squeaking.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed squeaks or wobbles	Loose hardware, uneven floor	Tighten all bolts and screws. Ensure the bed is on a level surface; use furniture pads if needed.
Slats fall out of place	Improper installation, excessive weight	Re-install slats correctly, ensuring they are seated in their holders. Do not exceed the maximum weight capacity.
Fabric stain	Spill or dirt accumulation	Blot immediately with a clean, damp cloth. For tougher stains, use a mild fabric cleaner on a hidden area first.

8. SPECIFICATIONS

Model: BENEDICTE

Brand: Vente-unique

Sleeping Dimensions: 160 x 200 cm

Overall Dimensions (L x D x H): 172 cm x 211 cm x 87 cm

Sleeping Height: 30 cm

Color: Anthracite Grey

Fabric Material: 100% Polyester

Frame Material: Plywood structure, Pine wood legs

Slatted Base: Included, 28 slats

Maximum Supported Load: 300 kg

Assembly: Self-assembly required

9. WARRANTY AND SUPPORT

For any questions, missing parts, or concerns regarding your Vente-unique BENEDICTE bed, please contact the seller or Vente-unique customer service directly. Refer to your purchase documentation for specific warranty terms and contact information.

Typically, a 30-day return policy applies. Keep your proof of purchase for any warranty claims or support requests.