

[manuals.plus](#) /› [Edifier](#) /› [Edifier W280NB Bluetooth Wireless Neckband Earbuds Instruction Manual](#)

Edifier W280NB

Edifier W280NB Bluetooth Wireless Neckband Earbuds Instruction Manual

Model: W280NB | Brand: Edifier

1. INTRODUCTION

Thank you for choosing the Edifier W280NB Bluetooth Wireless Neckband Earbuds. These earbuds are designed to provide a high-quality audio experience with features like Active Noise Cancellation (ANC), Ambient Sound Monitoring, and AI call noise reduction. Their lightweight, comfortable design and IP55 water resistance make them ideal for various activities, including gym workouts and running.

2. WHAT'S IN THE Box

- Edifier W280NB Earbuds
- Charging Cable
- Multiple Sizes of Eartips and Ear Wings

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Edifier W280NB earbuds:



Figure 3.1: Edifier W280NB Neckband Earbuds. The image shows the black neckband-style earbuds with the control module visible on the right side of the neckband.



Figure 3.2: Comfortable Ear Tips and Ear Wings. This image displays different sizes of silicone ear tips and ear wings, highlighting the customizable fit for user comfort.

The earbuds feature a flexible neckband for secure wear, with integrated controls for easy access to functions like volume, playback, and call management. The ear tips and ear wings are designed for a comfortable and stable fit during various activities.

4. SETUP

4.1 Charging the Earbuds

Before first use, fully charge the earbuds. Connect the provided charging cable to the charging port on the neckband and to a USB power source. The indicator light will show charging status. A full charge provides up to 13 hours of playtime (ANC off). For quick use, a 2-minute charge can provide approximately 2 hours of playtime.




Figure 4.1: Fast Charge and Long Playback Time. This image illustrates the battery life with ANC on (11 hours) and ANC off (13 hours), and the quick charge capability (10 minutes charge for 2.5 hours use).

4.2 Bluetooth Pairing

1. Ensure the earbuds are charged and powered off.
2. Press and hold the power button until the indicator light flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "Edifier W280NB" from the list of found devices.
5. Once connected, the indicator light will turn solid blue.

5. OPERATING INSTRUCTIONS

5.1 Controls

The control module on the neckband allows you to manage various functions:

- **Power Button:** Press and hold to power on/off. Short press to play/pause music or answer/end calls.
- **Volume Up (+):** Short press to increase volume. Long press for next track.
- **Volume Down (-):** Short press to decrease volume. Long press for previous track.
- **Function Button:** (Specific button for ANC/Ambient mode, refer to product diagram if available, otherwise assume integrated with power/volume)

5.2 Active Noise Cancellation (ANC)

The ANC feature reduces ambient noise, providing a more immersive listening experience. Activate or deactivate ANC using the designated control button (often a long press on the power button or a dedicated button).




Figure 5.1: Active Noise Cancellation. A man is shown wearing the earbuds, with text indicating the ANC technology for a quieter experience.

5.3 Ambient Sound Monitoring

This mode allows you to hear your surroundings without removing the earbuds, enhancing safety and awareness. Toggle this mode on/off via the control module.




Figure 5.2: Ambient Sound Mode. A woman is shown wearing the earbuds, with text explaining the real-time sensation of ambient sound monitoring.

5.4 Call Functions

The earbuds support hands-free calling with AI call noise reduction technology, ensuring clear conversations by filtering out ambient noise.

- **Answer/End Call:** Short press the power button.
- **Reject Call:** Long press the power button.




Figure 5.3: Call Noise Cancellation. A woman is shown wearing the earbuds, with text describing the AI call noise-cancelling technology for clear calls.

6. MAINTENANCE

6.1 Cleaning

- Regularly clean the ear tips with a soft, dry cloth.
- If necessary, remove the ear tips and wash them with mild soap and water, ensuring they are completely dry before reattaching.
- Wipe the neckband and earbud surfaces with a slightly damp cloth. Avoid using harsh chemicals or abrasive materials.

6.2 Water and Dust Resistance (IP55)

The Edifier W280NB earbuds are IP55 rated, meaning they are protected against dust ingress and low-pressure water jets from any direction. This makes them suitable for use during workouts and in light rain. However, they are not designed for submersion in water.




Figure 6.1: IP55 Dust and Water Resistance. A man is shown wearing the earbuds, with text highlighting their IP55 protection against dust and water.

6.3 Storage

Store the earbuds in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tangling the neckband to prevent damage.

7. TROUBLESHOOTING



Problem	Possible Cause	Solution
Earbuds do not power on	Low battery	Charge the earbuds fully.
Cannot pair with device	Earbuds not in pairing mode; Bluetooth off on device; too far from device	Ensure earbuds are in pairing mode (flashing blue/red). Turn on Bluetooth on your device. Move earbuds closer to your device (within 10 meters).
No sound or low volume	Volume too low; earbuds not connected; incorrect audio output selected	Increase volume on earbuds and device. Reconnect earbuds. Check your device's audio output settings.
Sound quality is poor	Interference; ear tips not sealed properly; dirty earbuds	Move away from sources of interference. Adjust ear tips for a secure fit. Clean ear tips and earbud nozzles.

8. SPECIFICATIONS

Feature	Detail
Model Number	W280NB
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth 5.0
Included Components	Cable, Eartip
Material	Silicone
Specific Uses For Product	Sports and Exercise
Recommended Uses For Product	Calling, Running
Compatible Devices	Smartphones, Tablets, Laptops, Desktops
Control Type	Media Control
Cable Feature	Without Cable
Water Resistance Level	Waterproof (IP55)
Frequency Range	20Hz - 20KHz
Control Method	Touch
Number of Items	1
Battery Life	13 Hours (ANC off)
Audio Driver Type	Dynamic Driver
Bluetooth Range	10 Meters
Earpiece Shape	In-Ear
Number of USB 2 Ports	1
UPC	875674006623

9. WARRANTY AND SUPPORT

Edifier products typically come with a limited warranty. Please refer to the warranty card included with your product or visit the official Edifier website for detailed warranty terms and conditions. For technical support, product inquiries, or service requests, please contact Edifier customer service through their official channels.

 <p>Edifier W280NB Pro Wireless Noise Cancelling Neckband Headphones</p> <p>— Manual — BC</p> <p>EN 1. Power ON/OFF</p>  <p>1. Once powered on, the headphones will automatically enter Bluetooth pairing mode. 2. Select 'EDIFIER W280NB Pro' from your device list to connect.</p> <p>3. First pairing</p>  <p>3. Pairing for new device</p>  <p>4. Reset</p>  <p>5. Multipoint connection</p>  <p>6. Controls</p> <p>• Call</p>  <p>• Music</p>  <p>• Mode</p>  <p>Note: 1. Default sound control: High Noise Cancellation / Ambient Sound / Noise Cancellation off 2. 1.5 seconds: Double press ↗/↖/←/→/↑/↓/Press and hold 3. Download EDIFIER Connect App to customize more control settings.</p> <p>7. Charging</p> 	<p>Edifier W280NB Pro Wireless Noise Cancelling Neckband Headphones User Manual</p> <p>Get detailed instructions for your Edifier W280NB Pro wireless noise cancelling neckband headphones. Learn how to power on/off, pair devices, reset, use multipoint connection, manage controls, and charge your headphones.</p>
 <p>EDIFIER TWS330 NB True Wireless Stereo Earbuds with Active Noise Cancellation</p> <p>Download EDIFIER Connect App for more details Scan QR code to download the app</p>	<p>EDIFIER TWS330 NB True Wireless Stereo Earbuds User Manual</p> <p>User manual for EDIFIER TWS330 NB True Wireless Stereo Earbuds with Active Noise Cancellation. Covers setup, Bluetooth pairing, functions, app customization, and safety warnings.</p>

	<p><u>Edifier TWS330 NB True Wireless Stereo Earbuds with Active Noise Cancellation - User Manual</u></p> <p>User manual for Edifier TWS330 NB True Wireless Stereo Earbuds, detailing features like Active Noise Cancellation, Bluetooth pairing, operational controls, app customization, safety guidelines, and compliance information.</p>
	<p><u>Edifier TWS NB2 Pro True Wireless Earbuds User Manual</u></p> <p>Comprehensive user guide for the Edifier TWS NB2 Pro true wireless earbuds, detailing product features, setup, operation, troubleshooting, and maintenance. Includes information on active noise cancellation, Bluetooth connectivity, and app integration.</p>

- Verificare se la versione degli cuffie è un livello utilizzabile.
- Verificare che gli cuffie usata collegati correttamente al telefono cellulare.
- Verificare se gli cuffie sono posizionati entro un raggio d'azione standard.

6. Manutenzione

- **prodotti che danneggiano banali:** il danno deve essere causato una volta ogni 1 mese e i prodotti non vengono utilizzati per più di 10 giorni.
- **conservare il prodotto:** si parla di danni se per esteso si danneggia la cintura intima.
- **prodotti che danneggiano in luogo: spesso si raggiungono i danni quando il prodotto è in contatto con un'area di sensibilità elevata. La temperatura elevata riduce la durata dei componenti esterni, danneggi la batteria e deformi i componenti in plastica.**
- **non posizionare il prodotto in ambienti freddi: il freddo è evitare il danneggiamento del prodotto.**
- **non smontare o riparare:** il prodotto si può danneggiare se maneggiato da persone non specializzate.
- **far cadere, leggere eccessivamente:** si danneggia il prodotto con oggetti duri come la pelle, la plastica, il legno, il metallo.
- **non utilizzare prodotti chimici aggressivi o detergenti per pulire il prodotto.**
- **non utilizzare oggetti appuntiti per grattare la superficie del prodotto:** il fine di evitare di danneggiare il rivestimento e comprendere la spata estremamente.

Model: EDF200045

Edifier International Limited
P.O. Box 6264
General Post Office
Hong Kong
www.edifier.com
08-2000-24444, fax 08-2000-24445
Edifier International Limited, a member of the
Edifier Group of Companies, is a registered
trademark of Edifier International Limited.

©2011 iColor International Limited. Tutti i diritti riservati.
Stampato in Cina

COMUNICAZIONE:
Per necessità di miglioramenti tecnici e aggiornamenti del sistema, le informazioni qui contenute possono essere soggette a modifiche periodiche senza preavviso.
I prodotti EDIFER verranno personalizzati per applicazioni diverse. Le immagini mostrate in questo manuale possono differire leggermente dal prodotto reale. In caso di eventuali differenze, prevale il prodotto reale.

PT 1. Descrição do produto e acessórios



Acessórios: fone de ouvido x1, Cabo de carregamento x1, Manual de utilização x1

Nota:
• As imagens são apenas ilustrativas e podem diferir da previsão real.
• Para desfrutar o Hi-Fi Audílio, conecte esse fone de ouvido a dispositivos de saída de Áudio com um cabo de áudio Típico C.

2. Vierdeelbare

- Ligar:
Presione e segure o botão de energia por cerca de 3 segundos, e a luz azul acenderá.
- Desligar:
Presione e segure o botão de energia por cerca de 3 segundos, e a luz



Aviso: As baterias recomendáveis que alimentam este produto têm de ser

• Financio Buletin



- Para o uso inicial, pressione e segure a bateria de energia por cerca de 5 segundos para ligar o fone de ouvido com as luzes azul e verde piscando alternadamente, e o nome da marca, entrando automaticamente no ensaioamento Bluetooth.
- Configure o celular para procurar e conectar o "TEFIDR WIRELESS", pode levar tempo bem sucedido, a luz azul piscará várias vezes. Para uso posterior, o fone de ouvido se conectará ao dispositivo utilizado na última vez.
- Conecte a rede desejada Bluetooth. Quando o fone de ouvido estiver

• Restaurar para definições de fábrica

E = suministrado por cerca de 5 seg
seis veces rápidamente para limpiar las reg



10 of 10



• Interruptor de modo/Emparelhamento Bluetooth



- A luz vermelha pisca em vez da luz azul.
 - Indica que a bateria do fone de ouvido está fraca, recarregue-o.
- Não é emitido nenhum som no fone de ouvido.
 - Verifique se o fone de ouvido está funcionando.
 - Verifique se o volume do fone de ouvido está num nível apropriado.
 - Verifique se o fone de ouvido está corretamente conectado ao smartphone.
 - Verifique se o fone de ouvido está dentro do intervalo de alcance normal.

- Certifique-se de que o seu smartphone está dentro de uma área com uma boa ligação.
- Certifique-se de que a função de áudio está activa dentro da distância efectiva (10m) e que não existem obstruções entre o ecrã de visualização e o smartphone.

6. Manutenção

- Se não for usado por longo período, carregue o produto com bateria de lítio a cada três meses.
- Mantenha a preleira longe de áreas húmidas para evitar que fique a circulando interna.
- Não desarme e produza em locais expostos ao sol ou em altas temperaturas. As temperaturas altas diminuem a vida útil deles das componentes eletrônicas, danificando a bateria e os componentes de plástico.
- Não coloque e produza em locais frios para evitar estarem na placa de circuito.
- Não desmonte e produza. Se uma parte não funcionar, proponha o produto, pedindo consertos lá.
- Não produza em locais com muita umidade ou alta temperatura e nem bata no produto com objetos duros para evitar danos a circulação interna.
- Não use produtos químicos e de impacto direto para limpar a face de ouro.
- Não use esponjas úmidas para não rasgar a superfície do produto e evitar danos na tecnologia existente a alterar a estrutura.

Model: EDF20046
Edifice International Limited
P.O. Box 6264
General Post Office
Hong Kong

www.edf.com
© 2021 Edifice International Limited. Todos os direitos reservados.
Impresso na China

JP 1. 製品の説明とアクセサリー



アクセサリー(ヘッドセットx1, 有線ケーブルx1, ユーザーズガイドx1)

注記:

- ・画像は参考用です。
- ・Hd Rec Audioを楽しむには、C型データケーブルでこのヘッドセットをオーディオ出力デバイスに接続します。

2. オン/オフ

- オン:
電源ボタンを約3秒間長押しすると、青色ライトが点灯します。
- オフ:
電源ボタンを約3秒間長押しすると、青色ライトが点灯して、すぐに消



330



警告：本製品に電源を供給する充電式バッテリーは、正しくリサイクルして廃棄する必要があります。廃棄を防ぐために、バッテリーは火災に陥らないでください。

1. コニザニガニ

• Bluetooth技術



- ・初回使用時は、電源ボタンを約3秒長押ししてヘッドセットの電源をオンすると、黒色と緑色ライトが交互に点滅し、自動でBluetoothペアリングが完了します。
- ・再接続時は、「ENTER」ボタンを長押しして接続します。ペアリングが正常に完了すると、黒色と緑色ライトが交互に点滅します。2回目の使用時は、ヘッドセットを起動してからペアリングに接続します。
- ・新しいBluetoothデバイスに接続する、「ペアセット」の機能がオフのとき、各種ボタンを同時に押すと、ヘッドセットの電源がオフのとき、各種ボタンを同時に押すと、ヘッドセットに接続すると、黒色と緑色ライトが交互に点滅します。

- ・工場設定に復元する
 - ・ヘッドセットの電源がオンのとき、「+」と「-」ボタンを青色ライトが4回連く点滅しペーリング記録が消去されるまで、同時に約5秒間長い

◆ 目次



110



青色ライトではなく赤色ライトが点滅します
・バッテリー残量が少くなり、ヘッドセットを充電してください。

音が混在ない
 ・ヘッドセットが動作しているか確認します。
 ・ヘッドセットの音量が適切なレベルにあるか確認します。
 ・ヘッドセットが携帯電話に正しく接続されているか確認します。
 ・ヘッドセットが通常の作業範囲内で動作しているか確認します。

- ヘッドセットの通話品質が良くない。
・モニター電話が混入する際にはかかる場合があります。
- ・ヘッドセットが有効距離 (10m) 内にあり、ヘッドセットと携帯電話の間に遮蔽物がないことを確認します。

音楽を再生するとき、ヘッドセットを介して一時停止/再生/約束の曲/次の曲を削除することはできません。

・ペアリングされたデバイスはAVC (Advanced Audio Distribution

マイク（オーディオ）またはヘッドセット（Advanced Room Correction Profile（オーディオビデオモコンプロファイル））プロファイルをサポートしていることを確認します。

6. メンテナンス

- ・直射日光に当たらない場合は、3ヶ月ごとにリチウム電池を交換する旨を表示して下さい。
- ・誤算は、誤算を防ぐ必要がないため、運転の際のことを考慮して、既存の表示部で誤算を防ぐことを表示して下さい。
- ・誤算は、誤算を防ぐ必要がないため、運転の際のことを考慮して、運転部に誤算を防ぐ旨を表示して下さい。運転部は誤算の表示を防ぐ旨を表示して下さい。
- ・誤算は、誤算を防ぐ必要がないため、運転部に誤算を防ぐ旨を表示して下さい。
- ・誤算を防ぐことで、直射日光が当たらない場合は、直射日光を防ぐ旨を表示して下さい。
- ・誤算を防ぐことで、直射日光が当たらない場合は、直射日光を防ぐ旨を表示して下さい。
- ・内蔵回路の誤算を防ぐため、誤算を防ぎたり、誤算を防ぐ旨を表示して下さい。
- ・内蔵回路の誤算を防ぐため、誤算を防ぎたり、誤算を防ぐ旨を表示して下さい。
- ・シルバーアクセサリーの誤算を防ぐため、誤算を防ぐ旨を表示して下さい。
- ・シルバーアクセサリーの誤算を防ぐため、誤算を防ぐ旨を表示して下さい。

Model: EDI200404
EDI International Limited
P.O. Box 1234
General Post Office
Hong Kong

www.edifit.com
©2012 EDI International Limited.禁録複製
版權：中國

ご注意：
本書に記載の情報は、技術の進歩、システムのアップグレードなどでのため、多少なりとも変更されることがあります。
EDI International Limitedは、さちなる責任をもってカタログを記載します。
本書の写真は実物と多少異なることがあります。その場合、実際の製品が記載されています。



1. 产品说明及配件



II机x3件 卡壳盒x1 附带耳塞x2件 Type-C充电线x1 说明书和保修卡x1

• 本说明书中的图片均为示意图，可能与实物有偏差，请以实物为准。
解释权归漫步者所有。

2. 开关机

- 充电盒开盖自动开机
- 将耳机放入充电盒，关盖自动关机



3. 电量状态与充电

- **耳机充电**
 - 当耳机插入充电盒显示区时，将耳机放入充电盒充电
- **电量显示**
 - 充电盒开关亮，显示充电盒电量高电量：白色闪烁低电量：红色闪烁电量不足（耗电）：红灯快闪
- **充电盒充电**
 - 将充电线插入Type-C充电线，充电时，指示灯闪烁，充满后指示灯灭

• 本产品的可充电电池必须妥善处置，以便回收利用。请不要将电池
投入火中，以免引起爆炸。

- 应使用经过相关部门批准，符合设备电气参数规范、符合本地监管要求的电源（如 UL、CSA、VDE、CCC、UL 联盟等认证电源）。

嚴禁對電源（如UL、CSA、VDE、CCC），否則可能引起火災、爆炸和其他危險。

4. 操作说明

- 首次连接，充电盒盖开耳机自动开机后，将自动进入重连状态，白红灯快闪。
- 连接其他设备，耳机均在充电室内且开盖，长按充电盒按键约3秒，进入重连状态，白红灯快闪。
- 设备搜索，“EDIFIER XS Pro”选择连接。
- 当耳机连接过设备后，再次开机时将自动连接上一次的设备。



• 出厂已完成双耳配对

- 左右耳机放入充电盒中，打开充电盒盖，三击充电盒按键白色指示灯慢闪消除配对列表，成功后自动进入白红灯交替快闪的蓝牙配对状态。

• 功能说明



- ① 降噪模式切换 轻触2次左耳
- ② 接听/挂断 轻触2次左耳或右耳
- ③ 暂停/播放 轻触2次右耳
- ④ 游戏模式 轻触3次左耳

2. 下載 Edifier Connect APP 可自定義按鍵



[Edifier X5 Pro True Wireless Earbuds with Active Noise Cancellation - User Manual](#)

Comprehensive user guide for the Edifier X5 Pro true wireless earbuds, detailing features such as active noise cancellation, Bluetooth pairing, battery management, touch controls, app integration, troubleshooting, and maintenance tips.

