

[Manuals.plus](#) /

› [VTech](#) /

› VTech My First Kidi Smartwatch (Model 80-552800) Instruction Manual

VTech 80-552800

VTech My First Kidi Smartwatch Instruction Manual

Brand: VTech | Model: 80-552800

INTRODUCTION

The VTech My First Kidi Smartwatch is designed to help young children learn about time-telling and responsibility through interactive play. This smartwatch features a friendly digital pet, engaging games, and helpful routine reminders. It is intended for ages 3-5 years.



Image: The VTech My First Kidi Smartwatch in blue, featuring a dog-themed face with glowing ears.

WHAT'S IN THE BOX

- My First Kidi Smartwatch
- Micro-USB Cable
- Quick Start Guide





Image: The retail packaging for the VTech My First Kidi Smartwatch, showing the watch and its features.

SETUP

Charging the Smartwatch

The smartwatch includes a built-in, rechargeable lithium-ion battery. To charge the device, use the provided micro-USB cable only. Connect the micro-USB cable to the charging port on the side of the watch and plug the other end into a USB power source (not included). A full charge typically takes approximately 3.5 hours.

Basic Controls

- **Touchscreen:** Interact with the watch by tapping and swiping on the display.
- **Home Button:** Located on the left side, this button returns you to the main menu.
- **Clock Button:** Located on the right side, this button can be used to check the time.
- **Ring Light:** The watch features a ring light around the screen that can change colors.

OPERATING INSTRUCTIONS

Time-Telling Features

The smartwatch offers over 20 analog and digital clock faces. Swipe left or right on the screen to change the clock face. Double-tap the clock face to hear the current time spoken aloud. The 'Time Master' app allows children to practice telling time.





Image: The smartwatch displaying an analog clock face with a dog character.

Interactive Pet Care

Care for your digital pet by feeding, walking, and grooming it using the touchscreen. You can also train your pet to perform up to 20 different tricks. The pet will react with various expressions and sounds.



Image: A child pointing at the smartwatch screen, which displays a cute dog character.

Games and Activities

The smartwatch includes several interactive games and activities:

- **Doggie Jump:** Help your pet cross the river.
- **Sneaky Toy:** Guess which basket the toy is hiding under.
- **Odd One Out:** Find the image that is different from the others.
- **Music Player:** Listen to pre-loaded music and nursery rhymes.
- **Balloon Breathing:** Practice deep breathing exercises.



Image: A grid showing various interactive activities and watch faces available on the smartwatch.

Routine Reminders

Set daily routine reminders for activities such as potty training, brushing teeth, and nap time. These reminders help children stay on track with their daily schedules.




Image: A child holding a toothbrush, with the smartwatch displaying a 'Brush your teeth!' reminder.

Watch-to-Watch Connection

Connect your My First Kidi Smartwatch with a friend's smartwatch (sold separately) to engage in additional connected activities and games.



Image: Two children's wrists, each wearing a VTech My First Kidi Smartwatch, positioned close together to illustrate the watch-to-watch connection feature.

Official Product Video

Your browser does not support the video tag.

Video: An official overview of the VTech My First Kidi Smartwatch, demonstrating its features including time-telling, pet interaction, games, and reminders.

PARENTAL CONTROLS

The smartwatch includes parental control features accessible through the settings menu. These controls allow parents to manage aspects such as game time limits and activate a 'School Mode'.

- **Game Time Per Day:** Set daily limits for game play (e.g., 15, 30, 60, 90 minutes, or disable games entirely).
- **School Mode:** When activated, the watch will only display the clock face during set hours (e.g., 7:00 AM - 11:00 PM on weekdays), preventing access to games and other interactive features. Note that activating School Mode may also disable alarms.

MAINTENANCE

- **Cleaning:** Wipe the smartwatch with a slightly damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Water Resistance:** The watch has an IPX4 waterproof rating, meaning it is resistant to splashing water but is **not** waterproof. Avoid submerging the watch in water.
- **Storage:** Store the watch in a cool, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

- **Watch not turning on:** Ensure the battery is fully charged. Connect to the micro-USB cable and allow it to charge for at least 30 minutes before attempting to power on.
- **Screen unresponsive:** Try restarting the device by holding down the Home button for a few seconds. If the issue persists, ensure the screen is clean and dry.
- **Sound issues:** Check the volume settings in the menu. Ensure the watch is not muted.
- **Connectivity problems:** When attempting to connect with another smartwatch, ensure both devices are within close proximity and follow the on-screen instructions for pairing.

SPECIFICATIONS

Feature	Detail
Operating System	VTech Proprietary OS
Special Features	Activity Tracker, Connect and play with a friend, Pet Pal, Reminders, Time-Telling, Touchscreen
Connectivity Technology	USB
Battery Cell Composition	Lithium Polymer
GPS	No GPS
Screen Size	2.17 Inches
Display Type	LCD
Resolution	240 x 240
Item Weight	3.04 ounces
Item Dimensions	8.58 x 0.94 x 2.2 inches
Water Resistance Level	IPX4 (Not Water Resistant for submersion)
Target Audience	Unisex Children
Age Range Description	Kid (3-5 years)

WARRANTY AND SUPPORT

This VTech My First Kidi Smartwatch comes with a Limited Warranty. For specific details regarding warranty coverage, duration, and how to obtain service, please refer to the warranty information provided in the Quick Start Guide included with your product or visit the official VTech support website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09MW3CR26>

More documents and user manuals: <https://manuals.plus/>