

BEISAR 7 Thrusting & 7 Vibrating

BEISAR Prostate Massager and Anal Vibrator (Model: 7 Thrusting & 7 Vibrating) Instruction Manual

Brand: BEISAR | Model: 7 Thrusting & 7 Vibrating

[Safety Information](#) [Product Overview](#) [Package Contents](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. SAFETY INFORMATION

For adult use only. Keep out of reach of children.

2. PRODUCT OVERVIEW

The BEISAR Prostate Massager and Anal Vibrator is designed for targeted stimulation. It combines multiple functions into one device, offering a versatile experience. Crafted from soft, body-safe silicone, it features an ergonomic design for comfortable use.

Key Features:

- **7 Strong Vibrating & Thrusting Modes:** Offers upgraded vibrating and thrusting with a 0.6-inch stretch, designed to stimulate specific areas.
- **3-in-1 Design:** Combines a prostate massager, anal vibrator, and cock ring. The thrusting element targets the P-spot, the rippled base vibrates the perineum, and the soft cock ring is designed for prolonged sensation.
- **Soft Silicone Material:** Made from silky smooth, body-safe silicone for comfort.
- **Ergonomic & Waterproof Design:** Shaped to fit comfortably, with a rounded top for easy insertion. Fully waterproof for use in various environments and easy cleaning.
- **Smart AI Sync APP Control:** Connects to a dedicated app for enhanced control, including recommended patterns, DIY mode, video sync, and sound-activated functions.
- **Magnetic USB Charging:** Features convenient magnetic USB charging, providing approximately 1 hour of use on a full charge.
- **Discreet Packaging:** Shipped in a discreet box.



Image: The BEISAR Prostate Massager and Anal Vibrator, showcasing its ergonomic design and dual stimulation points.

3. PACKAGE CONTENTS

Upon opening your BEISAR product package, you should find the following items:

- BEISAR Prostate Massager and Anal Vibrator
- Wireless Remote Control
- Magnetic USB Charging Cable
- User Manual
- Small tube of lubricant



4STIMULI

BRING DELICIOUS FEELING OF FULLNESS




Image: The BEISAR device, its remote control, and the magnetic USB charging cable, as typically found in the product packaging.

4. SETUP

4.1 Initial Charge

1. Locate the magnetic charging points on the device.
2. Connect the magnetic end of the USB charging cable to these points. Ensure a secure connection.
3. Plug the USB end of the cable into a compatible USB power source (e.g., computer, wall adapter).
4. Allow the device to fully charge before first use. A full charge typically provides approximately 1 hour of operation.

4.2 App Connection (Optional)

1. Download the "JoyHub" app from your smartphone's app store.
2. Ensure your device is charged and powered on.
3. Open the JoyHub app and follow the on-screen instructions to pair your BEISAR device via Bluetooth.
4. Once paired, you can control the device's functions through the app.

MORE EXCITING WAYS TO PLAY WITH APP




Image: A visual representation of the BEISAR device being controlled via a smartphone app, highlighting the various interactive modes available.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation (On-Device Buttons)

- **Power On/Off:** Press and hold the power button (usually indicated by a circle or wave icon) for a few seconds until the device activates or deactivates.
- **Thrusting Modes:** Short press the thrusting button (often indicated by an up/down arrow or wave icon) to cycle through the 7 available thrusting patterns.
- **Vibration Modes:** Short press the vibration button (often indicated by a wave icon) to cycle through the 7 available vibration patterns.
- The thrusting and vibrating functions can be operated simultaneously or independently.

5.2 Remote Control Operation

- Ensure the remote control has working batteries.
- Power on the BEISAR device using its on-device button.
- Use the corresponding buttons on the remote to control thrusting and vibration modes. The remote allows for hands-free control from a distance of up to 22 feet.



Image: The BEISAR device and its remote control, illustrating the convenience of wireless operation.

5.3 App Control (JoyHub)

- After pairing the device with the JoyHub app (see Setup section), open the app.
- Explore various control modes:
 - **Recommended:** Access pre-set patterns.
 - **DIY Mode:** Create and save your own custom patterns.
 - **Video Mode:** Synchronize sensations with video content.
 - **Sound Mode:** Device responds to ambient sounds or music.
- Adjust intensity and patterns directly from your smartphone.

5.4 Application

- Apply a water-based lubricant to the device and the desired area for comfortable insertion.
- The ergonomic design allows for stimulation of the prostate/P-spot and perineum. The cock ring feature is designed to enhance sensation.



Image: A diagram illustrating the ergonomic design and key dimensions of the BEISAR device, highlighting its suitability for both anal and perineum stimulation.

6. MAINTENANCE

6.1 Cleaning

- Always clean the device thoroughly before and after each use.
- Wash with warm water and a mild, toy-safe soap.
- Rinse thoroughly to remove all soap residue.

- Pat dry with a lint-free cloth or allow to air dry completely.
- Do not use harsh chemicals, alcohol-based cleaners, or petroleum-based lubricants, as these can damage the silicone material.



Image: The BEISAR device submerged in water, illustrating its waterproof design for easy cleaning and versatile use.

6.2 Storage

- Store the device in a clean, dry place away from direct sunlight and extreme temperatures.
- Keep it separate from other toys made of different materials to prevent damage or reactions.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or device is not charged.	Ensure the device is fully charged using the magnetic USB cable.
Remote control not working.	Remote batteries are dead or device is out of range.	Replace remote batteries. Ensure device is within 22 feet of the remote.
App connection issues.	Bluetooth not enabled or device not properly paired.	Ensure Bluetooth is enabled on your smartphone. Re-pair the device through the JoyHub app settings.
Device is too loud (thrusting modes).	This is a characteristic of the thrusting mechanism.	While vibration modes are quieter, thrusting modes may produce audible sound. This is normal operation.

8. SPECIFICATIONS

- **Brand:** BEISAR
- **Model Number:** 7 Thrusting & 7 Vibrating
- **Material:** Silicone
- **Color:** Black
- **Water Resistance Level:** Waterproof
- **Thrusting Range:** 0.6 inches
- **Charging:** Magnetic USB
- **Battery Life (Full Charge):** Approximately 1 hour
- **Remote Control Range:** Up to 22 feet
- **Dimensions:** 6.89 x 5.2 x 1.85 inches
- **Weight:** 10.86 ounces

9. WARRANTY AND SUPPORT

For any product inquiries, warranty claims, or technical support, please contact BEISAR customer service through the retailer's platform or the official brand website. Please retain your proof of purchase for warranty purposes.

10. PRODUCT VIDEOS

BEISAR Product Overview

Your browser does not support the video tag.

Video: An official product video from BEISAR, showcasing the features and functionality of the prostate massager and anal vibrator. This video provides a general overview of the device's capabilities and design.

BEISAR Thrusting and Vibration Modes Demonstration

Your browser does not support the video tag.

Video: A brief demonstration of the device's thrusting and vibration modes. This short clip highlights the different patterns and intensities available, providing a quick look at its operational aspects.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question