Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KSIX smart your tech S1905876

KSIX Slim 5000 mAh 10W Power Bank - Instruction Manual

Model: S1905876

1. Introduction

Thank you for choosing the KSIX Slim 5000 mAh 10W Power Bank. This portable charger is designed to provide reliable power for your mobile devices on the go. Its compact and lightweight design makes it an ideal companion for travel, work, or daily use. This manual will guide you through the setup, operation, and maintenance of your new power bank.

2. Product Overview

The KSIX Slim Power Bank features a 5000 mAh capacity, capable of charging most smartphones up to two times. It includes multiple USB outputs for versatile charging and LED indicators to display the remaining power level.

Key Features:

- **5000 mAh Capacity:** Provides ample power for multiple charges.
- **Compact and Lightweight Design:** Easy to carry in a backpack, handbag, or pocket.
- **Multiple USB Outputs:** Equipped with 3 USB outputs for charging various devices.
- **LED Power Indicators:** 4 LED lights show the remaining battery level.
- **Simultaneous Charging:** Allows charging of multiple devices while the power bank itself is being charged.






Figure 2.1: Front view of the KSIX Slim 5000 mAh Power Bank, showing the KSIX logo and LED indicators.

3. Setup

Before first use, it is recommended to fully charge your KSIX Slim Power Bank.

Initial Charging:

1. Connect the provided USB-A to USB-C cable to the power bank's input port (usually labeled 'Type-C' or 'Input').
2. Connect the other end of the cable to a USB wall adapter (not included) or a computer's USB port.
3. The LED indicators will light up, showing the charging progress. All four LEDs will be solid when the power bank is fully charged.



Figure 3.1: Side view of the power bank, highlighting the USB ports for charging and output.

4. Operating Instructions

Charging Your Devices:

1. Ensure the power bank is sufficiently charged (check the LED indicators).
2. Connect your device's charging cable to one of the power bank's USB output ports.
3. Connect the other end of the cable to your device.
4. The power bank will automatically begin charging your device. The LED indicators will show the remaining power.
5. To stop charging, simply disconnect your device.

LED Indicator Guide:

- **4 LEDs Solid:** 75-100% charge remaining.
- **3 LEDs Solid:** 50-75% charge remaining.
- **2 LEDs Solid:** 25-50% charge remaining.
- **1 LED Solid:** 0-25% charge remaining (recharge soon).
- **Flashing LEDs:** Indicates active charging or low battery.

5. Maintenance

- Keep the power bank away from extreme temperatures, direct sunlight, and liquids.

- Do not drop or subject the power bank to strong impacts.
- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- If not used for extended periods, charge the power bank at least once every three months to maintain battery health.

6. Troubleshooting

Power Bank Not Charging:

- Ensure the charging cable is securely connected to both the power bank and the power source.
- Try a different USB cable or wall adapter.
- Verify the power source is active.

Device Not Charging from Power Bank:

- Check if the power bank has sufficient charge (refer to LED indicators).
- Ensure the charging cable is securely connected to both the power bank and your device.
- Try a different USB output port on the power bank.
- Try a different charging cable for your device.
- Some devices may require a specific charging current; ensure compatibility.

7. Specifications

Brand	KSIX smart your tech
Model Number	S1905876
Battery Capacity	5000 mAh
Output Power	10W
Voltage	5 Volts
Connector Type	USB
Number of Ports	3
Color	Black
Product Dimensions (L x W x H)	50 x 50 x 28 cm
Weight	140 grams
Country of Origin	China

8. Warranty and Support

This KSIX product is covered by a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included with your purchase or visit the official KSIX website. For technical support or customer service inquiries, please contact your retailer or the KSIX support team through their official channels.
Please retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09MW7TZ9L

More documents and user manuals: **https://manuals.plus/**