

## Tonies 10001155

# Tonies Spanish Playtime Songs Audio Toy Figurine Instruction Manual

Brand: Tonies | Model: 10001155

## INTRODUCTION

This manual provides essential information for the setup, operation, and care of your Tonies Spanish Playtime Songs Audio Toy Figurine. This Tonie character is designed to be used with a Toniebox Audio Player (sold separately) to deliver an engaging, screen-free audio experience for children.

## SETUP


### First-Time Use

To begin, ensure your Toniebox Audio Player is connected to Wi-Fi.

Place the Spanish Playtime Songs Tonie figurine on top of your Toniebox. The Toniebox will automatically recognize the Tonie and begin downloading the content. This process may take a few moments depending on your internet connection.

Once the content is fully downloaded, the LED on the Toniebox will turn solid green, indicating it's ready to play.

# Comenzar la hora del cuento es *sencillo*.



Conéctate al WiFi  
con una configuración  
rápida y única.



Las aventuras comienzan  
cuando los niños  
colocan un Tonie encima.



Cambia el Tonie  
para empezar  
una nueva historia.



Image: This illustration demonstrates the simple three-step process for starting story time with your Toniebox. First, connect the Toniebox to Wi-Fi. Second, place a Tonie character on top to begin adventures. Third, swap out the Tonie for a new character to enjoy a different story.

## OPERATING YOUR TONIE

### Playing Content

Once the Tonie is placed on the Toniebox and the content is downloaded, the audio will begin playing automatically.

### Controls

- **Volume Control:** Squeeze the large ear of the Toniebox to increase volume, and the small ear to decrease volume.
- **Skipping Tracks:** Tap the side of the Toniebox to skip forward or backward through tracks.
- **Fast Forward/Rewind:** Tilt the Toniebox to the side to fast forward or rewind within a track.
- **Pausing:** Remove the Tonie from the Toniebox to pause playback. Place it back on to resume.



Image: The Tonies Spanish Playtime Songs figurine, a charming spotted dog character, is designed to interact seamlessly with the Toniebox for an intuitive audio experience.

## CONTENT OVERVIEW: SPANISH PLAYTIME SONGS

This Tonie figurine includes 16 traditional Spanish playtime songs, with a total run time of approximately 40 minutes.

### Tracklist:

1. El patio de mi casa
2. Chequi Morena
3. La Bamba
4. Los elefantes
5. Aserrín aserrán

6. Si tu tienes muchas ganas de aplaudir
7. El puente está quebrado
8. La Tía Mónica
9. El Pequeño Juan
10. Arroz con leche
11. Don Gato
12. Pinpón
13. La víbora de la mar
14. Compadre no compro coco
15. La Vaca Lola
16. A mi burro

## Tracklist:

### CANCIONES

- |  |                             |
|--|-----------------------------|
| 1. El patio de mi casa                   | 9. El Pequeño Juan          |
| 2. Chequi Morena                         | 10. Arroz con leche         |
| 3. La Bamba                              | 11. Don Gato                |
| 4. Los elefantes                         | 12. Pinpón                  |
| 5. Aserrín aserrán                       | 13. La víbora de la mar     |
| 6. Si tu tienes muchas ganas de aplaudir | 14. Compadre no compro coco |
| 7. El puente está quebrado               | 15. La Vaca Lola            |
| 8. La Tía Mónica                         | 16. A mi burro              |

*Tiempo aproximado: 40 minutos*



Image: This visual displays the complete tracklist of 16 traditional Spanish songs included with the Tonies Spanish Playtime Songs figurine, offering approximately 40 minutes of audio content.

## MAINTENANCE AND CARE

To ensure the longevity of your Tonie figurine:

- Keep the Tonie clean by wiping it with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- Store the Tonie in a dry place, away from direct sunlight and extreme temperatures.
- The Tonie is designed to be durable, but avoid dropping it from significant heights or subjecting it to excessive force.
- Do not immerse the Tonie in water.

## TROUBLESHOOTING

| Problem                               | Possible Cause   | Solution   |
|---------------------------------------|--|--|
| Tonie not playing audio.              | Content not fully downloaded or Toniebox not connected to Wi-Fi. | Ensure your Toniebox is connected to a stable Wi-Fi network. Place the Tonie on the Toniebox and wait for the content to download (LED will turn solid green). |
| Audio is distorted or too quiet/loud. | Volume settings are incorrect.                                   | Adjust the volume using the Toniebox ears.   |
| Toniebox LED is blinking.             | Indicates a connection issue or content download in progress.    | Check your Wi-Fi connection. If downloading, wait for the LED to turn solid green. Refer to your Toniebox manual for specific LED codes.                       |

## PRODUCT SPECIFICATIONS

- **Product Dimensions:** 4.25 x 1.38 x 7.88 inches
- **Item Weight:** 1.44 ounces
- **Model Number:** 10001155
- **Manufacturer Recommended Age:** 3 years and up
- **Language:** Spanish
- **Total Run Time:** Approximately 40 minutes
- **What's in the Box:** Tonie Figurine

## WARRANTY AND SUPPORT

For detailed warranty information, product registration, or further assistance, please visit the official Tonies website or contact Tonies customer support.

**Official Website:** [us.tonies.com](https://us.tonies.com)

**Customer Support:** Refer to the website for contact options (phone, email, FAQ).

## ADDITIONAL RESOURCES

## Product Images



Image: Detailed view of the Tonie figurine, highlighting its hand-painted design.



Image: The Tonie figurine interacting with the Toniebox, illustrating how the characters bring stories to life.



Image: An assortment of Tonie characters alongside a Toniebox, showcasing the wide range of available audio figures.

## Official Product Videos

No official product videos from the seller are available for embedding at this time.


© 2025 Tonies. All rights reserved.

## Related Documents - 10001155



# Toniebox Setup Guide: Welcome to the Tonie-Universe

A comprehensive setup guide for the Toniebox, introducing the Tonie-Universe, explaining how to set up the device, listing popular children's songs, and providing troubleshooting tips.



## Toniebox Beginner's Guide: Setup, Usage, and Support

A comprehensive guide to setting up and using the Toniebox, including information on Tonies, Creative-Tonies, volume control, charging, and troubleshooting.



### [Toniebox Setup Guide: Get Started with Playtime Puppy](#)

A comprehensive guide to setting up your Tonies Toniebox, featuring Playtime Puppy and Disney characters. Learn how to use, charge, and troubleshoot your Toniebox for endless listening fun.



### [Creative-Tonie Setup and Guide | Tonies](#)

Learn how to set up your Tonies Creative-Tonie, upload audio content, and troubleshoot common issues with this concise guide.



### [Toniebox 2 Rosa Play Set Paw Patrol Chase: Interaktiver Audio-Player für Kinder](#)

Entdecken Sie das Toniebox 2 Rosa Play Set mit Paw Patrol. Dieser interaktive Audio-Player für Kinder von 1-9+ Jahren bietet bildschirmfreies Lernen, Geschichten und Spiele, mit Funktionen wie Sleep-Timer, Sonnenaufgangswecker und Bluetooth-Konnektivität. Enthält Paw Patrol-Inhalte und Tonieplay-Spiele.



### [PAW Patrol Heldenhafte Rettung in der Abenteuerbuch Tonieplay Game - Produktinformationen und Spielanleitung](#)

Umfassende Informationen und Spielanleitung für das tonies PAW Patrol Heldenhafte Rettung in der Abenteuerbuch Tonieplay Game M, inklusive Artikelnummer, Altersempfehlung und Spielablauf.