Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TITANO Silla Gamer

TITANO Ergonomic Gaming Chair User Manual

Model: Silla Gamer

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your TITANO Ergonomic Gaming Chair. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.

2. Safety Information

- **Weight Capacity:** Do not exceed the maximum weight capacity of 300 pounds (136 kg). Exceeding this limit may cause damage to the chair or personal injury.
- **Assembly:** Ensure the chair is correctly assembled according to the instructions to guarantee stability and prevent accidents.
- **Children:** Keep children away from the assembly area. Small parts may pose a choking hazard.
- **Maintenance:** Regularly inspect all bolts and screws to ensure they are tight. Retighten as necessary.
- **Usage:** Use the chair only for its intended purpose. Avoid standing on the chair or using it as a ladder.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Backrest
- Seat Cushion
- Armrests (2)
- Base (5-star)
- Casters (5)
- Gas Lift Cylinder
- Gas Lift Cover
- Mechanism Plate

- Headrest Pillow
- Lumbar Support Pillow
- Hardware Kit (screws, washers, Allen wrench)

4. Assembly Instructions

Assembly typically takes 15 to 30 minutes. Follow the step-by-step instructions provided in the physical manual included with your chair. A general overview of the assembly process is provided below.

1. **Attach Casters to Base:** Insert the five casters into the holes on the 5-star base until they click securely into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the base. Cover it with the gas lift cover.
3. **Attach Mechanism Plate to Seat:** Secure the mechanism plate to the underside of the seat cushion using the provided screws. Ensure the front of the mechanism plate faces the front of the seat.
4. **Attach Armrests to Seat:** Fasten the armrests to the sides of the seat cushion using the designated screws.
5. **Attach Backrest to Seat:** Connect the backrest to the seat cushion and armrests using the appropriate screws.
6. **Connect Seat Assembly to Base:** Carefully place the assembled seat onto the gas lift cylinder, ensuring it is centered.
7. **Attach Pillows:** Secure the headrest pillow and lumbar support pillow to the backrest using their integrated straps.

Important: Do not invert the T-bone component during assembly, as this will prevent the chair from reclining properly.



Figure 4.1: Fully assembled TITANO Ergonomic Gaming Chair. Refer to the included manual for detailed assembly steps.

5. Operating Instructions

Your TITANO Gaming Chair offers several adjustable features for personalized comfort.

5.1 Height Adjustment

To adjust the seat height, locate the lever on the right side beneath the seat. While seated, pull the lever up to lower the seat. To raise the seat, stand up slightly and pull the lever up. Release the lever at the desired height to lock it in place.

5.2 Backrest Recline

The backrest can be adjusted between 90 and 140 degrees. Locate the recline lever on the right side of the chair, near the seat. Pull the lever up and lean back to recline the backrest. Release the lever at your desired angle to lock it. To bring the backrest forward, pull the lever and lean forward.



Figure 5.1: The chair's recline function allows adjustment from an upright 90-degree position to a relaxed 140-degree angle. The base also provides 360-degree rotation.

5.3 Swivel and Mobility

The chair features a 360-degree swivel function, allowing for easy rotation. The multi-directional casters enable

smooth movement across various floor surfaces.



Figure 5.2: Key features include a comfortable neck cushion, a base designed for 360-degree rotation, durable vinyl upholstery, and an accessible lever for adjustments.

6. Maintenance

Regular maintenance helps prolong the life and appearance of your gaming chair.

- **Cleaning:** Wipe the PU leather surfaces with a soft, damp cloth. For stubborn stains, use a mild soap solution and dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically check all screws and bolts to ensure they are tight. Retighten any loose fasteners to maintain stability and prevent squeaks.
- **Caster Care:** Clean casters regularly to remove dust, hair, and debris that may hinder smooth movement.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the PU leather to fade or crack.

7. Troubleshooting

If you encounter issues with your TITANO Gaming Chair, refer to the following common problems and solutions.

- **Chair Does Not Recline:**
  - Ensure the T-bone component was not inverted during assembly. Refer to the assembly instructions.
  - Check that the recline lever is fully engaged and not obstructed.
- **Chair Squeaks:**
  - Tighten all screws and bolts, especially those connecting the backrest, seat, and mechanism plate.
  - Apply a small amount of silicone lubricant to moving parts if necessary.
- **Chair Wobbles/Unstable:**
  - Verify that all components are securely fastened and that the gas lift is properly seated in the base.
  - Ensure the casters are fully inserted into the base.
- **Gas Lift Not Functioning:**
  - Check if the gas lift lever is properly connected to the mechanism plate.
  - Ensure no obstructions are preventing the lever from moving freely.

8. Specifications

Feature	Specification
Brand	TITANO
Model	Silla Gamer
Color	Blue
Product Dimensions (L x W x H)	52 x 62 x 125 cm (20.5 x 24.4 x 49.2 inches)
Material	High-density ecological sponge, 1.8mm thick wood backrest, high-quality PU leather, Polyvinyl Chloride
Special Features	Ergonomic design, Adjustable height, Reclining backrest, Swivel function
Product Weight	14 kg (30.8 lbs)
Maximum Load Capacity	300 lbs (136 kg)
Seat Height Adjustment Range	5.8" - 19.7" (14.7 cm - 50 cm)
Seat Width	15" x 18.9" (38.1 cm x 48 cm)
Backrest Size	21.3" x 31.5" (54.1 cm x 80 cm)
Backrest Recline Angle	90 - 140 degrees
Rotation	360 degrees



Figure 8.1: Detailed dimensions of the TITANO Gaming Chair, including total height, backrest height, seat width, base diameter, and armrest length.

9. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or contact TITANO customer service through the retailer where the product was purchased. Please have your purchase receipt and product model number (Silla Gamer) available when contacting support.

© 2025 TITANO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09MY8Q3PK

More documents and user manuals: **https://manuals.plus/**