

[Manuals.plus](#) /

› [RIG](#) /

› RIG Nacon MG-X for Android - Wireless Mobile Gaming Controller for Android Smartphones User Manual

RIG MG-X

RIG Nacon MG-X for Android - Wireless Mobile Gaming Controller

MODEL: MG-X | BRAND: RIG

1. Introduction

The RIG Nacon MG-X is a wireless mobile gaming controller designed to bring console-like precision to your Android smartphone. It is optimized for use with Xbox Game Pass Ultimate and other compatible mobile games, offering an enhanced gaming experience on the go.



Figure 1: RIG Nacon MG-X Controller with a smartphone.

Key features include:

- Designed for Xbox for seamless integration with Xbox Game Pass Ultimate.
- Compact and secure design with an adjustable opening to hold smartphones up to 6.7 inches.
- Wireless Bluetooth 4.2 connectivity for reliable pairing.
- Up to 20 hours of gameplay on a single charge via USB-C.
- Textured grip surfaces for optimal control.

2. Package Contents

Ensure all items are present in the package:

- RIG Nacon MG-X Android phone gaming controller
- USB-C Charge Cable (0.8m)

3. Setup

3.1. Inserting Your Smartphone

1. Gently extend the two halves of the MG-X controller.
2. Carefully place your Android smartphone (up to 6.7 inches) into the controller's adjustable opening. Ensure it is securely seated within the rubberized grips.
3. Verify that the phone is centered and stable before use.



Figure 2: Universal fit for Android smartphones up to 6.7 inches.

3.2. Bluetooth Pairing

1. Ensure your MG-X controller is charged.
2. On your Android smartphone, navigate to the Bluetooth settings.
3. Press and hold the Bluetooth pairing button on the MG-X controller until the indicator light begins to flash, indicating it is in pairing mode.
4. On your smartphone, select "Nacon MG-X" from the list of available devices.
5. Once connected, the indicator light on the controller will become solid.



Figure 3: Bluetooth 4.2+BLE connection for fast and reliable pairing.

4. Operating the Controller

The MG-X controller features a layout similar to an official Xbox controller, providing intuitive controls for mobile gaming.



FUNCTIONALITY AND FEEL OF AN OFFICIAL CONTROLLER

Figure 4: Functionality and feel of an official controller.

Familiarize yourself with the button layout:

- **Left Analog Stick:** Movement and navigation.
- **D-Pad:** Directional input.
- **Right Analog Stick:** Camera control and aiming.
- **A, B, X, Y Buttons:** Action buttons, typically color-coded.
- **Shoulder Buttons (L1/LB, R1/RB):** Quick actions.
- **Triggers (L2/LT, R2/RT):** Analog input for precise control in racing or shooting games.
- **Menu/Options Buttons:** Access in-game menus and system functions.
- **Xbox Button:** Home button, often used to launch Xbox Game Pass.

The controller is designed to provide a responsive and immersive gaming experience, especially for titles available through Xbox Game Pass Ultimate.



Figure 5: Designed for Xbox Game Pass Ultimate.

5. Charging and Battery Life

The MG-X controller features a built-in rechargeable battery providing up to 20 hours of gameplay. Battery life may vary depending on usage and the game being played.



Figure 6: Up to 20 hours of battery life.

To charge the controller:

- Connect the supplied USB-C charging cable to the USB-C port on the controller.
- Connect the other end of the cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
- An LED light on the controller indicates the battery level and charging status. Refer to the controller's LED guide for specific indications.

6. Compatibility

The RIG Nacon MG-X is universally compatible with Android smartphones running Android 6 or later. It supports devices with screens up to 6.7 inches (152.4 mm). Compatibility with specific games from the Google Play Store may vary; always check game descriptions for controller support.

7. Maintenance

To ensure the longevity and optimal performance of your MG-X controller, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the controller. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the ports or internal components.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the controller or subjecting it to strong impacts. Do not force your smartphone into the holder if it does not fit properly.

8. Troubleshooting

If you encounter issues with your RIG Nacon MG-X controller, try the following common solutions:

- **Controller Not Connecting:** Ensure the controller is fully charged. Verify Bluetooth is enabled on your smartphone and the controller is in pairing mode. Try restarting both the controller and your smartphone.
- **Buttons/Sticks Unresponsive:** Check for any physical obstructions. Ensure the controller's firmware is up to date (if applicable, check the manufacturer's website).
- **Phone Not Fitting Securely:** Ensure your phone's dimensions are within the supported range (up to 6.7 inches). Remove any bulky phone cases that might prevent a secure fit.
- **Battery Draining Quickly:** Ensure the controller is fully charged before use. Reduce screen brightness on your smartphone to conserve overall battery life.

For more detailed troubleshooting or persistent issues, please refer to the official user guide PDF available at [RIG Nacon MG-X User Guide \(PDF\)](#).

9. Specifications

Feature	Detail
Model Number	MG-X
Connectivity	Bluetooth 4.2
Compatibility	Android 6 and later (up to 6.7 inch screens)
Battery Life	Up to 20 hours
Charging Port	USB-C
Product Dimensions	1.42 x 7.36 x 3.62 inches
Item Weight	1.15 pounds
Manufacturer	RIG
First Available Date	December 2, 2021

10. Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the official RIG Nacon website or contact their customer service directly. You can also find detailed information in the comprehensive user guide PDF:

Download Official User Guide (PDF)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question