

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [Govee](#) /
- › Govee Smart Tower Fan User Manual

Govee H7101

Govee Smart Tower Fan User Manual

Model: H7101 (Includes Govee Thermo-Hygrometer Model H5177)

For Smart and Efficient Cooling

INTRODUCTION

This manual provides detailed instructions for the safe operation, installation, and maintenance of your Govee Smart Tower Fan (Model H7101). Please read this manual thoroughly before use and retain it for future reference. The fan is designed to provide efficient air circulation and smart control for your home or office environment.

SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury, please observe the following safety precautions:

- Ensure the power source matches the fan's voltage requirements.
- Do not operate the fan with a damaged cord or plug.
- Keep fingers, pencils, or any other objects out of the fan grille when operating.
- Unplug the fan from the outlet when not in use, when moving it from one location to another, and before cleaning.
- Do not use the fan in wet or damp locations.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

PACKAGE CONTENTS

- 1 × Govee Smart Tower Fan (H7101)
- 1 × Govee Thermo-Hygrometer (Model H5177)
- 1 × Screw Nut
- 2 × Base Plates
- 1 × User Manual & Quick Start Guide

PRODUCT OVERVIEW

The Govee Smart Tower Fan H7101 is a sleek, oscillating fan designed for optimal air circulation. It features a user-friendly control panel on top and integrates seamlessly with the Govee Home App and voice assistants.



Image: The Govee Smart Tower Fan H7101, showcasing its slim design, the included Govee Thermo-Hygrometer H5177, and a smartphone displaying the Govee Home App interface.

Always Stay in Control

Smart hands-free control via app or voice assistant




Image: The Govee Smart Tower Fan H7101 in a room setting, highlighting its compatibility with Google Assistant, Alexa, and the Govee Home App for hands-free control.

SETUP

Follow these steps to assemble and set up your Govee Smart Tower Fan:

1. Carefully remove all components from the packaging.
2. Assemble the two base plates by clicking them into place at the bottom of the fan.
3. Route the power wire through the assembled base and secure it with the provided screw nut.
4. Place the fan on a flat, stable surface.

5. Plug the power cord into a standard electrical outlet.

For a visual guide on installation, please refer to the official Govee installation video:

Your browser does not support the video tag.

Video: Official Govee guide on how to install the Govee 36 Inch Tower Fan H7101, demonstrating the assembly process.

OPERATING INSTRUCTIONS

Manual Control Panel

The fan features a touch-sensitive control panel on its top for basic operations:

- **Power Button:** Turns the fan on or off.
- **Mode Button:** Cycles through Normal, Sleep, and Nature modes.
- **Speed Buttons:** Adjusts fan speed (1-8).
- **Oscillation Button:** Toggles the 75° widespread oscillation.

Govee Home App Control

For full functionality and smart features, download the Govee Home App from the App Store or Google Play Store.

1. Download and open the Govee Home App.
2. Register or log in to your account.
3. Tap the "+" icon in the top right corner to add a new device.
4. Select "Smart Tower Fan" (H7101) from the device list.
5. Follow the in-app instructions to connect the fan to your Wi-Fi network.

Once connected, you can control all fan functions, including:

- Power On/Off
- Adjusting 8 fan speeds
- Selecting from Normal, Sleep, Nature, and Custom modes
- Controlling oscillation
- Setting a 24-hour timer
- Creating schedules
- Activating Auto Mode with the Govee Thermo-Hygrometer H5177

Hands-Free Auto Mode

Automate your fan speed with the Govee Thermo-Hygrometer



Image: A smartphone displaying the Govee Home App interface for the Smart Tower Fan, showing options for 8 speeds and various modes like Normal, Sleep, and Nature.

Voice Control (Alexa & Google Assistant)

The Govee Smart Tower Fan is compatible with Amazon Alexa and Google Assistant for convenient voice control. Ensure your fan is connected to the Govee Home App and your voice assistant is linked to your Govee account.

- Enable the "Govee Home" skill in your Alexa or Google Home app.
- Discover devices.
- Use commands such as:

- "Alexa, turn on the tower fan."
- "Hey Google, set tower fan speed to 5."
- "Alexa, turn off oscillation on the tower fan."

Auto Mode with Govee Thermo-Hygrometer H5177

The included Govee Thermo-Hygrometer Model H5177 allows the fan to automatically adjust its speed based on the ambient temperature, maintaining a comfortable environment.

1. Ensure your Govee Home App is updated to version 4.8.0 or above.
2. Connect the oscillating fan to Wi-Fi via the app.
3. Unplug the fan, then plug it back in, and wait approximately 30 minutes.
4. The "Bind" option will appear on the fan's control page in the app.
5. Pair the Thermo-Hygrometer H5177 with the fan through this option.
6. Set your desired temperature range within the app for automatic speed adjustments.

Effective Air Circulation

Get More Coverage with 75° Widespread Oscillation



Air Supply
Distance: Up to 26ft



Oscillation
Angle: 75°



Maximum Wind
Speed: 20ft/s



Image: The Govee Smart Tower Fan H7101 operating in Auto Mode, illustrating how fan speed adjusts based on temperature readings from the Govee Thermo-Hygrometer H5177.



Image: The Govee Home App interface highlighting the Auto, Custom, Timer, and Scheduling features for the Smart Tower Fan, with the H5177 hygrometer visible.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your Govee Smart Tower Fan:

- **Cleaning:** Unplug the fan before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Dust Removal:** Use a vacuum cleaner with a brush attachment to remove dust from the air intake and exhaust grilles.
- **Storage:** If storing the fan for an extended period, cover it to protect from dust and store in a cool, dry place.

TROUBLESHOOTING

If you encounter issues with your Govee Smart Tower Fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power; power cord not securely plugged in.	Ensure the fan is plugged into a working outlet. Check for tripped circuit breakers.
Fan not connecting to Wi-Fi/App.	Incorrect Wi-Fi password; fan too far from router; app version outdated.	Verify Wi-Fi password. Move fan closer to router. Update Govee Home App. Restart fan and router.
Auto Mode not working with hygrometer.	Hygrometer not paired; app not updated; fan not reset after Wi-Fi connection.	Ensure app is v4.8.0+. Unplug fan for 30s, plug back in, wait 30 mins for "Bind" option, then pair H5177.

Problem	Possible Cause	Solution
Fan makes unusual noise or wobbles.	Loose base; debris inside; unstable surface.	Ensure base is securely attached. Unplug and check for obstructions. Place on a flat, stable surface.

SPECIFICATIONS

Feature	Detail
Brand	Govee
Model Name	H7101
Included Hygrometer Model	H5177
Color	Black
Product Dimensions	10.63"D x 10.63"W x 38.3"H
Power Source	AC
Wattage	34 watts
Voltage	5 Volts
Noise Level	34 dB
Number of Power Levels	8
Oscillation Angle	75°
Control Method	App, Voice (Alexa, Google Assistant)
Timer	24H
Indoor/Outdoor Usage	Indoor

WARRANTY AND SUPPORT

Govee products come with a limited warranty. For detailed warranty information, product support, FAQs, and customer service, please visit the official Govee website or contact their support team directly. You can also find additional resources and contact information on the [Govee Store on Amazon](#).