

[Manuals.plus](#) /

› [Yeaki](#) /

› Yeaki Selfie Stick Tripod with Bluetooth Remote User Manual

Yeaki K-10

Yeaki Selfie Stick Tripod with Bluetooth Remote

USER MANUAL

1. INTRODUCTION

Thank you for choosing the Yeaki Selfie Stick Tripod with Bluetooth Remote. This versatile device combines a selfie stick and a stable tripod, designed for capturing photos and videos with ease. Its compact and lightweight design makes it ideal for travel, daily use, and various indoor and outdoor activities. This manual provides essential information on how to set up, operate, and maintain your device.



Image: The Yeaki Selfie Stick Tripod shown in both its extended tripod configuration and its compact handheld selfie stick form, demonstrating its dual functionality. A smartphone is mounted on the holder, and the detachable Bluetooth remote is visible.

2. PRODUCT FEATURES

- **Pocket-Sized Portability:** Weighing only 5.54 oz and folding to 8.3 inches, this selfie stick is designed for ultimate portability, fitting easily into bags or pockets.
- **Detachable Bluetooth Remote:** Equipped with a wireless remote control, allowing you to capture photos and videos from up to 33 feet away.

Bluetooth Remote Widely Compatible



Image: A detailed view of the selfie stick's handle, illustrating how the Bluetooth remote can be detached. Icons for iOS and Android are displayed, emphasizing the remote's broad compatibility with various mobile operating systems.

- **Enhanced Stability Tripod:** Features a unique enlarged design with 4-point support for superior balance and stability, preventing accidental tipping.

Super Balanced Tripod

Unique Enlarged Design



Image: A visual comparison demonstrating the enhanced stability of the Yeaki tripod, which features a wider and more robust base, contrasted with a less stable, narrower tripod. This illustrates the 'Super Balanced Tripod' design.

- **Durable Aluminum Alloy Construction:** Crafted from aviation-grade aluminum alloy, ensuring high hardness, light weight, and enhanced durability with a unique oxidized finish.

Aluminum Alloy Selfie Stick Tripod



Small & light



Durable



Beautiful

Image: A close-up shot highlighting the aluminum alloy construction of the selfie stick's rod. Accompanying text points out its attributes: 'Small & light', 'Durable', and 'Beautiful', showcasing the quality of its material and finish.

- **Optimal Shooting Angles:** Extends from 8.3 inches to 38 inches, offering a longer reach than many alternatives. The phone holder features 360° horizontal rotation and 200° vertical angle adjustment for versatile shooting.

360° Angle Adjustment

Universal Compatibility



Image: A diagram illustrating the 360-degree rotational capability of the phone holder. A smartphone is depicted rotating from a vertical (portrait) to a horizontal (landscape) orientation, demonstrating the flexibility in capturing various angles.

- **Wide Compatibility:** Fully compatible with iOS and Android smartphones, suitable for a broad range of devices.
- **Versatile Applications:** Ideal for gatherings, travel, camping, online learning, remote work, and live streaming.



Image: A composite image showcasing the diverse applications of the selfie stick tripod. It depicts users engaging in activities such as live sharing, taking travel selfies, participating in telecommuting, and conducting online learning sessions.

3. PACKAGE CONTENTS

Upon opening your package, please ensure all the following items are present:

- 1x Yeaki Selfie Stick Tripod
- 1x Wireless Bluetooth Remote Control
- 1x User Manual (this document)

4. SETUP GUIDE

4.1 Unfolding the Selfie Stick Tripod

1. Hold the handle firmly and gently pull the top section upwards to extend the telescopic rod.
2. If using as a tripod, spread the three legs at the base outwards until they lock into place, forming a stable triangular base.

4.2 Attaching Your Smartphone

1. Locate the phone holder at the top of the extended stick.
2. Gently pull the spring-loaded upper clamp of the phone holder upwards.
3. Carefully insert your smartphone into the holder, ensuring it is securely gripped by both the upper and lower clamps.

The holder is designed to accommodate phones between 2.36 and 3.74 inches in width.



Image: A three-panel illustration demonstrating key features: the phone holder's 360-degree rotation, the functionality of the detachable Bluetooth remote, and the selfie stick's extendable length from 8.3 inches to 38 inches.

4.3 Pairing the Bluetooth Remote

1. Remove the Bluetooth remote control from its slot on the selfie stick handle.
2. Press and hold the button on the remote until the indicator light begins to flash, indicating it is in pairing mode.
3. On your smartphone, go to **Settings > Bluetooth**.
4. Turn on Bluetooth and search for available devices.
5. Select the device named "Selfie" or similar from the list to pair.
6. Once paired, the indicator light on the remote will stop flashing and remain solid or turn off.

5. OPERATING INSTRUCTIONS

5.1 Taking Photos/Videos

1. Ensure your smartphone is securely mounted and the Bluetooth remote is paired.
2. Open your smartphone's camera application.
3. Position the selfie stick or tripod as desired.
4. Press the button on the Bluetooth remote control to trigger the camera shutter or start/stop video recording.

5.2 Adjusting Angles

- The phone holder allows for 360° horizontal rotation. Simply rotate your phone within the holder to switch between portrait and landscape orientations without remounting.
- The phone holder also offers 200° vertical angle adjustment. Tilt the holder up or down to achieve your desired shooting angle.

5.3 Using as a Tripod

1. Extend the tripod legs fully and ensure they are stable on a flat surface.
2. Adjust the telescopic rod to your desired height.
3. Use the Bluetooth remote to capture group photos, time-lapses, or stable video footage without holding the device.

6. MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, collapse the selfie stick to its most compact size and store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care (Remote):** If the remote control's battery is low, replace it with a new CR1632 coin cell battery. Ensure correct polarity.
- **Avoid Over-extension:** Do not force the telescopic rod beyond its maximum extension limit.

7. TROUBLESHOOTING

- **Remote Not Connecting:**
 - Ensure the remote is charged or has a fresh battery.
 - Make sure Bluetooth is enabled on your phone.
 - Try unpairing and re-pairing the remote in your phone's Bluetooth settings.
 - Ensure the remote is within the 33-foot operating range.
- **Phone Not Fitting Securely:**
 - Check if your phone's dimensions are within the supported range (2.36"-3.74" width).
 - Remove any bulky phone cases that might prevent a secure fit.
- **Tripod Instability:**
 - Ensure the tripod legs are fully extended and locked into position.
 - Place the tripod on a flat, stable surface.
 - Avoid placing heavy objects on the stick or extending it to its maximum height in windy conditions.

8. SPECIFICATIONS

Feature	Specification
Model Number	K-10
Material	Aluminum Alloy
Folded Size	8.3 inches
Minimum Height	8.3 inches
Maximum Height	38 inches (96 Centimeters)

Item Weight	6.7 ounces
Weight Limit	1.2 Ounces (for phone)
Bluetooth Remote Range	Up to 33 feet
Compatible Devices	iOS/Android smartphones (e.g., iPhone 4/5/6S/8/X/XR/XS/XS Max/11 Pro/12/13/13 Pro, Galaxy S10/S21/Note8/Note20, Huawei)
Phone Holder Width	2.36 - 3.74 inches
Color	White

9. WARRANTY AND SUPPORT

Your Yeaki Selfie Stick Tripod comes with a worry-free 1-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures your satisfaction with the product.

For any questions, technical support, or warranty claims, please contact our friendly customer service team. Refer to the contact information provided on the product packaging or the retailer's website where you purchased the product.

We are committed to providing excellent support and ensuring you have the best experience with your Yeaki product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09MZ56WN4>

More documents and user manuals: <https://manuals.plus/>