Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RC200

ALLIMITY RC200 Remote Control User Manual

Model: RC200 | Brand: ALLIMITY

1. Product Overview

The ALLIMITY RC200 is a replacement remote control designed to function seamlessly with various Hannspree television models. It provides all the essential functions of your original remote, ensuring a familiar and convenient user experience without the need for complex programming.





Figure 1: Front view of the ALLIMITY RC200 Remote Control

2. Key Features

- **Direct Replacement:** The RC200 remote control covers all functions of your original remote control.
- **No Programming Required:** Simply install the batteries, and the remote is ready for immediate use.
- **Wide Compatibility:** Compatible with a range of Hannspree TV models.
- **Infrared Technology:** Utilizes reliable infrared connectivity for stable operation.

3. Specifications

Brand	ALLIMITY
Item Model Number	RC200
Connectivity Technology	Infrared
Maximum Range	10 Meters

Battery Description	Alkaline
Maximum Supported Devices	1
Manufacturer	ALLIMITYQYSY
Country of Origin	China

4. Setup

4.1 Battery Installation

To begin using your ALLIMITY RC200 remote control, you will need to install two AAA alkaline batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by the arrow to open it.
3. Insert two AAA alkaline batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

The remote control is now ready for use with your compatible Hannspree TV.



Figure 2: Angled view of the remote control

5. Operating Instructions

The ALLIMITY RC200 remote control is designed to replicate the functionality of your original Hannspree TV remote. No special pairing or programming is required. Simply point the remote at your TV and press the desired button.

5.1 Basic Functions

- **Power Button ( ):** Press to turn the TV on or off.
- **Number Buttons (0-9):** Use to directly enter channel numbers.
- **Volume Up/Down (+ / -):** Adjust the sound volume.
- **Channel Up/Down (P ▲ / P ▼):** Change TV channels sequentially.
- **Mute Button ( ):** Mute or unmute the TV sound.
- **Source Button:** Select input sources (e.g., HDMI, AV, Component).

5.2 Menu and Navigation

- **Menu Button:** Access the TV's main menu.
- **Navigation Buttons (▲ ▼ ◄ ►):** Use the arrow keys to navigate through menu options.
- **OK Button:** Confirm a selection or enter a submenu.
- **Exit Button:** Exit the current menu or on-screen display.
- **Return Button:** Go back to the previous screen or menu.

5.3 Special Functions

- **Info Button:** Display information about the current program or input.
- **Guide Button:** Access the electronic program guide (EPG).
- **ECO Button:** Activate or deactivate power-saving modes.
- **TEXT Button:** Access Teletext services.
- **SUBTITLE Button:** Toggle subtitles on/off.
- **LIST Button:** Display a list of channels or media.
- **TV Button:** Switch to TV mode.
- **Lang Button:** Change audio language.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or interactive services, as indicated on screen.



Figure 3: Side view of the remote control

6. Compatibility

The ALLIMITY RC200 remote control is compatible with the following Hannspree TV models:

- AD32-UMMB
- SE32LMNB
- HSG1189/SL40
- SL32FMNB
- HSG1187/SK42
- HSG1210
- HSG1188
- HSG1211/SE40
- SL32UMNB

- SK32TMNB
- HSG1211
- HSG1235/AD32
- SK42TMNB
- HSG1188/SL32
- SE40LMNB
- LT29-32E1

If your TV model is not listed, please verify its compatibility with the RC200 remote before purchase.

7. Troubleshooting

7.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old or depleted batteries with fresh alkaline batteries.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared sensor.
- **Distance:** Ensure you are within the maximum operating range of 10 meters.
- **TV Sensor:** Verify that the TV's infrared sensor is clean and not blocked.

7.2 Specific Buttons Not Working

- **Battery Check:** Low batteries can sometimes cause intermittent button functionality. Replace them.
- **Clean Remote:** Dust or debris might be interfering with button contacts. Gently clean around the buttons.
- **Compatibility:** While the RC200 is a direct replacement, some very specific functions might vary slightly depending on the exact TV model. Refer to your TV's original manual for specific button functions if needed.

8. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Care:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

9. Warranty and Support

For any questions, technical support, or warranty inquiries regarding your ALLIMITY RC200 remote control, please contact the seller or manufacturer directly through the platform where you purchased the product. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09MZ8676R

More documents and user manuals: **https://manuals.plus/**