

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Samsers](#) /

› [Samsers Multi-Device Foldable Bluetooth Keyboard User Manual](#)

## Samsers KT03M

# Samsers Multi-Device Foldable Bluetooth Keyboard User Manual

Model: KT03M

## 1. INTRODUCTION

---

Thank you for choosing the Samsers Multi-Device Foldable Bluetooth Keyboard. This portable and versatile keyboard is designed to enhance your productivity across various devices, offering both 2.4G wireless and Bluetooth connectivity. Its compact, foldable design and integrated touchpad make it an ideal companion for on-the-go use. This manual provides detailed instructions to help you set up, operate, and maintain your new keyboard.

## 2. SAFETY INFORMATION

---

- Keep the keyboard away from water, moisture, and extreme temperatures.
- Avoid dropping or subjecting the keyboard to strong impacts.
- Do not attempt to disassemble or repair the keyboard yourself. Contact customer support for assistance.
- Use only the provided USB cable for charging to prevent damage.
- Store the keyboard in a clean, dry environment when not in use.

## 3. PACKAGE CONTENTS

---

# Package Include



Image: The Samsers Foldable Bluetooth Keyboard, a USB charging cable, a phone stand, and the user manual are included in the package.

Please check the package contents to ensure all items are present:

- Samsers Multi-Device Foldable Bluetooth Keyboard with Touchpad
- USB Cable
- Phone Stand Holder
- User Manual

## 4. PRODUCT OVERVIEW

The Samsers foldable keyboard features a unique tri-fold design, making it highly portable. It integrates a sensitive

touchpad for mouse functionality and supports connections via both 2.4G wireless and Bluetooth, allowing seamless switching between up to three devices.



Image: The Samsers foldable keyboard is shown fully unfolded, with a smartphone placed vertically on the included stand, demonstrating a typical setup.

### Key Features:

- **Dual-Mode Connectivity:** Supports 2.4G wireless (via USB receiver) and Bluetooth (BT1, BT2) for connecting up to 3 devices simultaneously.
- **Foldable Design:** Ultra-slim and portable, easily fits into pockets or bags.
- **Sensitive Touchpad:** Integrated touchpad with left and right click functions for convenient navigation.
- **Rechargeable Battery:** Built-in battery provides long working and standby times.
- **Wide Compatibility:** Compatible with iOS, Android, Windows, and Mac OS devices.
- **Included Phone Stand:** A portable stand is provided for optimal device viewing angles.



Image: A detailed view highlighting the power switch, connect button, charging port, magnetic adsorption points, and anti-slip silicone pads on the keyboard.

## Components:

- **Power Switch:** Located on the side to turn the keyboard On/Off.
- **Connect Button:** Used for initiating Bluetooth pairing.
- **Charging Port:** USB-C port for recharging the keyboard.
- **Touchpad:** Multi-touch surface for cursor control.
- **Indicator Lights:** For battery status, connection status, and Caps Lock.
- **Folding Hinges:** Durable hinges for the tri-fold mechanism.

## 5. SETUP

### 5.1 Charging the Keyboard

# Rechargeable Foldable Keyboard



2-3 hours  
Charge Time



48 hours  
Working Time



560 hours  
Standby Time



Image: The foldable keyboard is shown connected to a laptop via a USB-C cable, illustrating the charging process. Icons indicate 2-3 hours charge time, 48 hours working time, and 560 hours standby time.

Before first use, fully charge the keyboard. Connect the provided USB-C cable to the keyboard's charging port and the other end to a USB power source (e.g., computer, wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged. A full charge typically takes 2-3 hours, providing approximately 48 hours of working time or 560 hours of standby time.

## 5.2 Power On/Off

To power on the keyboard, simply unfold it. The keyboard will automatically power on. To power off, fold the keyboard. It will automatically power off to conserve battery.

## 5.3 Connecting to Devices

The keyboard supports dual-mode connectivity: 2.4G wireless and Bluetooth (BT1, BT2). You can connect up to

three devices simultaneously and switch between them.

### 5.3.1 2.4G Wireless Connection



Image: The keyboard is shown unfolded next to a laptop, with the 2.4G USB receiver plugged into the laptop's USB port, indicating a stable 2.4G connection.

1. Locate the 2.4G USB receiver (usually stored in a compartment on the keyboard).
2. Plug the USB receiver into an available USB port on your computer or device.
3. Turn on the keyboard by unfolding it.
4. Press **Fn + A** to switch to 2.4G mode. The indicator light will confirm the connection.

### 5.3.2 Bluetooth Connection (BT1 / BT2)

# Bluetooth & 2.4 Dual Mode

Connect your cell phone/tablet and PC simultaneously and switch among them easily



 **Bluetooth**

 1 Press Fn+S

 2 Press Fn+D



 **USB**

Press Fn+A



Image: A graphic illustrating the dual-mode connectivity, showing Bluetooth pairing via Fn+S and Fn+D, and 2.4G USB connection via Fn+A.

1. Turn on the keyboard by unfolding it.
2. Press **Fn + S** for Bluetooth Channel 1 or **Fn + D** for Bluetooth Channel 2. The corresponding indicator light will flash rapidly, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for new devices.
4. Select "Samsers Keyboard" (or similar name) from the list of available devices.
5. Follow any on-screen prompts to complete the pairing process. The indicator light on the keyboard will stop flashing and remain solid once connected.

## 5.4 Compatibility

# Extensive Compatibility

## Tablet



Apple iPad



SAMSUNG



Amazon



HUAWEI

## Laptop



MacBook



DELL



HP



Lenovo

## Phone



SAMSUNG



iPhone



HUAWEI



Image: A visual representation of the keyboard's extensive compatibility with various operating systems and devices, including Apple iPad, Samsung, Amazon, Huawei tablets, MacBook, Dell, HP, Lenovo laptops, and Samsung, iPhone, Huawei phones.

The Samsers keyboard is compatible with a wide range of operating systems:

- iOS (Note: Touchpad may not work for systems below iOS 13.4)
- Android (Note: Touchpad may not work for systems below Android 3.0)
- Windows
- Mac OS

## 6. OPERATING INSTRUCTIONS

## 6.1 Touchpad Usage




Image: A close-up of the highly sensitive touchpad, emphasizing its responsiveness for precise control. Note: Not for systems below iOS 13.4.

The integrated touchpad allows for precise cursor control, similar to a laptop touchpad.

- **Single Finger Tap:** Left click.
- **Two Finger Tap:** Right click.
- **Two Finger Scroll:** Scroll up or down.

## 6.2 Multimedia Shortcut Functions



Image: The keyboard layout highlighting the richer and more practical multimedia shortcut functions, designed to improve work efficiency.

The keyboard features various multimedia shortcut keys (accessed by pressing the **Fn** key in combination with the corresponding function key):

- **Fn + F1:** Home
- **Fn + F2:** Brightness Down
- **Fn + F3:** Brightness Up
- **Fn + F4:** Search
- **Fn + F5:** Previous Track
- **Fn + F6:** Play/Pause
- **Fn + F7:** Next Track
- **Fn + F8:** Mute
- **Fn + F9:** Volume Down
- **Fn + F10:** Volume Up
- **Fn + F11:** Lock Screen
- **Fn + F12:** Screenshot

### 6.3 Switching Between Connected Devices

To switch between your connected devices (2.4G, BT1, BT2), simply press the corresponding function key:

- Press **Fn + A** to switch to 2.4G wireless mode.
- Press **Fn + S** to switch to Bluetooth Channel 1.
- Press **Fn + D** to switch to Bluetooth Channel 2.

### 6.4 Auto Sleep Function

- ① Power Switch
- ② Connect button
- ③ Charging port



**10mins**  
Auto sleep



Scissor Switch Key



Image: A visual demonstrating the keyboard's auto-sleep feature after 10 minutes of inactivity to save power, and highlighting the scissor switch key mechanism.

To conserve battery life, the keyboard will automatically enter sleep mode after 10 minutes of inactivity. To wake it up, simply press any key. It will automatically reconnect to the last connected device.

## 7. MAINTENANCE

### 7.1 Cleaning

To clean the keyboard, gently wipe the surface with a soft, damp cloth. Do not use harsh chemicals, abrasive cleaners, or excessive moisture. Ensure the keyboard is powered off before cleaning.

### 7.2 Storage

When not in use for extended periods, fold the keyboard to protect the keys and touchpad. Store it in a cool, dry place away from direct sunlight and extreme temperatures.

## 8. TROUBLESHOOTING

If you encounter any issues with your Samsers keyboard, please refer to the following common solutions:

- **Keyboard not connecting:**
  - Ensure the keyboard is fully charged.
  - Make sure the keyboard is unfolded and powered on.
  - For Bluetooth, ensure your device's Bluetooth is enabled and the keyboard is in pairing mode (flashing indicator light). Try unpairing and re-pairing.
  - For 2.4G, ensure the USB receiver is securely plugged into your device.
  - Try restarting both the keyboard and your device.
- **Touchpad not working:**
  - Verify your device's operating system version meets the minimum requirements (iOS 13.4+, Android 3.0+).
  - Ensure the keyboard is properly connected.
  - Try restarting the keyboard and device.
- **Keys are unresponsive or typing incorrectly:**
  - Check battery level and recharge if necessary.
  - Ensure the keyboard is on a stable, flat surface.
  - If specific keys are affected, gently clean around them.
- **Short battery life:**
  - Ensure the keyboard is fully charged before use.
  - The keyboard automatically enters sleep mode after 10 minutes of inactivity; ensure it's not being left unfolded when not in use.

If the problem persists after trying these steps, please contact Samsers customer support for further assistance.

## 9. SPECIFICATIONS



Image: The folded keyboard is shown with its compact dimensions (5.98 inches length, 3.82 inches width, 0.71 inches thickness), highlighting its portability.

**Feature**

**Description**

Product Dimensions	11.89 x 3.85 x 0.22 inches (unfolded)
Item Weight	6.9 ounces
Model Number	KT03M
Batteries	1 Lithium Polymer batteries required (included)
Connectivity Technology	2.4G Wireless, Bluetooth
Compatible Devices	Laptop, PC, Smartphone, Tablet (iOS, Android, Windows, Mac OS)
Special Feature	Foldable, Lightweight, Portable, Rechargeable, Touchpad
Number of Keys	64
Keyboard Backlighting	Single Color

## 10. WARRANTY AND SUPPORT

---

Samsers products are designed for reliability and performance. For any questions, technical support, or warranty claims, please contact Samsers customer service. Refer to the contact information provided on the product packaging or the official Samsers website for the most up-to-date support details.