Oraimo OEB-E104D

Oraimo OEB-E104D TWS Wireless Earbuds User Manual

Model: OEB-E104D
Brand: Oraimo

Product Overview

The Oraimo OEB-E104D TWS Wireless Earbuds are designed to provide a high-quality audio experience with convenience and portability. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your earbuds.



Figure 1: Oraimo OEB-E104D TWS Wireless Earbuds and their charging case. The earbuds are black, sleek, and designed for in-ear use, while the compact charging case features LED indicators for battery status.

Setup Guide

1. Unboxing and Package Contents

Upon opening the package, ensure all components are present. The standard package includes:

- Oraimo OEB-E104D TWS Wireless Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable

- Multiple sizes of ear tips for a comfortable fit
- User Manual



Figure 2: Contents of the Oraimo OEB-E104D package, including the earbuds, charging case, USB-C cable, and various ear tip sizes.

2. Initial Charging

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case, then connect the USB Type-C cable to the charging port on the case and to a power source.

- The LED indicators on the charging case will illuminate to show charging status.
- A 10-minute charge provides approximately 90 minutes of playback time.
- A full charge of the case and earbuds can provide up to 36 hours of total playtime.



Figure 3: Illustration of the fast charging capability of Oraimo OEB-E104D, highlighting 10 minutes of charge for 90 minutes of playback via Type-C.

3. Pairing with a Device

The Oraimo OEB-E104D features one-step pairing for convenience.

1. Ensure the earbuds are in the charging case and the case lid is open.
2. Turn on Bluetooth on your device (smartphone, tablet, laptop).
3. Search for "oraimo freepods 3" (or similar model name) in the Bluetooth device list.
4. Select the earbuds to connect. Once connected, a voice prompt will confirm successful pairing.



Figure 4: Visual guide demonstrating the one-step pairing process for Oraimo OEB-E104D earbuds with a mobile device.

Operating Instructions

1. Touch Controls

The earbuds are equipped with intuitive touch controls for managing audio playback and calls.

Table 1: Touch Control Functions

Action	Function
Single Tap (Left/Right Earbud)	Play/Pause Music, Answer/End Call
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track

Action	Function
Long Press (Left/Right Earbud)	Activate Voice Assistant, Reject Call



Figure 5: Close-up view of the earbud highlighting the touch control area for easy operation.

2. Battery Life and Charging Indicators

The earbuds offer extended battery life for prolonged listening. The charging case provides additional charges on the go.

- **Single Playtime:** Up to 8 hours on a single charge.
- **Total Playtime:** Up to 36 hours with the charging case.
- **Charging Case Indicators:** LEDs on the case indicate the remaining battery level and charging status.



Figure 6: Diagram illustrating the impressive battery life of the Oraimo OEB-E104D, showing 8 hours of single playtime and 36 hours total with the charging case.

Maintenance

1. Cleaning and Care

To ensure optimal performance and longevity of your earbuds, follow these cleaning guidelines:

- Regularly clean the ear tips and earbud grilles with a soft, dry, lint-free cloth.
- Avoid using abrasive materials, solvents, or chemical cleaners.
- Ensure the charging contacts on both the earbuds and the case are clean and free of debris.

2. Water Resistance

The Oraimo OEB-E104D earbuds are rated IPX5 water resistant, meaning they are protected against low-pressure water jets from any direction. This makes them suitable for workouts and light rain.

- Do not submerge the earbuds in water.
- The charging case is not water resistant. Keep it dry.
- Dry the earbuds completely before placing them back into the charging case to prevent damage.



Figure 7: Visual representation of the IPX5 water resistance of the Oraimo OEB-E104D earbuds, indicating protection against sweat and splashes.

3. Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store the case in a cool, dry place away from extreme temperatures.

Troubleshooting

If you encounter any issues with your Oraimo OEB-E104D earbuds, refer to the following common solutions:

Table 2: Common Troubleshooting Steps

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget the device in Bluetooth settings and re-pair.
No sound from one earbud	Place both earbuds back in the case, close the lid, wait a few seconds, then open and try again. Check device audio settings.
Charging issues	Clean the charging contacts on both earbuds and case. Try a different USB-C cable and power adapter. Ensure the case has power.
Poor sound quality	Ensure ear tips provide a good seal. Clean earbud grilles. Move closer to your device to avoid interference.

If the issue persists, please contact Oraimo customer support for further assistance.

Specifications

Table 3: Product Specifications

Feature	Detail
Model Name	E104D
Model Number	OEB-E104D (Black)
Brand	Oraimo
Connectivity Technology	Wireless
Headphone Form Factor	In Ear
Color	Black
Product Dimensions	5.7 x 14.9 x 17.2 cm
Item Weight	150 grams
Batteries	4 Lithium Ion batteries (included)
Sensitivity	93 dB
Noise Control	None (Environmental Noise Cancellation is a feature, but not active noise cancellation)

Warranty and Support

The Oraimo OEB-E104D TWS Wireless Earbuds come with a**12-month warranty** from the date of purchase, covering manufacturing defects.
For warranty claims, technical support, or any inquiries regarding your product, please contact Oraimo customer service through their official website or the retailer where you purchased the product. Please have your proof of purchase and product model number ready when contacting support.
For more information, visit the official Oraimo website:www.oraimo.com

© 2024 Oraimo. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question