

Qaba 370-198GY

Qaba Kids Tricycle User Manual

Model: 370-198GY

Brand: Qaba

1. SAFETY INFORMATION

Please read and understand all instructions before assembly and use of the Qaba Kids Tricycle. Failure to follow these instructions may result in serious injury.

- Adult Supervision Required:** Always supervise children when they are using the tricycle.
- Age and Weight Limits:** This tricycle is suitable for children aged 12 months to 5 years. The maximum weight capacity is 55 lbs (25 kg). Do not exceed these limits.
- Proper Assembly:** Ensure all parts are correctly assembled and securely fastened before each use. Regularly check for loose screws, bolts, or damaged components.
- Safety Harness and Guardrail:** Always secure your child with the 3-point safety belt and ensure the guardrail is properly latched when in use.
- Brakes:** Familiarize yourself with the rear wheel brakes for safe parking. The front wheel clutch can lock the tire for parent-controlled steering.
- Hazard Awareness:** Avoid using the tricycle near stairs, swimming pools, steep inclines, or busy roads. Ensure the play area is clear of obstacles.
- Footwear:** Ensure the child wears appropriate footwear when using the tricycle.
- Maintenance:** Regularly inspect the tricycle for any signs of wear, damage, or malfunction. Replace worn parts immediately.

2. PRODUCT OVERVIEW

The Qaba Kids Tricycle is a versatile 4-in-1 foldable trike designed to adapt to your child's growth from 12 months to 5 years. It offers multiple configurations for different stages of development and convenience for parents.

Key Features:

- 4-in-1 Multifunction:** Easily switches between Baby Push Car, Toddler Trike with Push Handle, Toddler Bike Stroller, and Kids Tricycle modes.
- Reversible Seat:** Allows the child to face forward or backward, enabling parent-child interaction or forward-facing exploration.

- **Adjustable Parent Handle:** 3-gear adjustable height to suit parents of different heights, providing comfortable control.
- **Safety Features:** Equipped with a removable guardrail, 3-point safety belt, and full-closed wheels for enhanced safety.
- **Wheel Brakes:** Rear wheel brakes for secure parking and a front wheel clutch to lock the tire.
- **Removable Canopy:** Flexible and removable canopy provides shade and protection from the sun.
- **Storage:** Includes two storage baskets and one "Mommy Pocket" for carrying essentials.
- **Foldable Design:** Conveniently folds for easy transport and storage in a car.

Product Dimensions:

- Overall Dimensions: 44" L x 20.5" W x 38.5" H
- Item Weight: 17.6 lbs

Components Included:

- Tricycle Frame with Wheels
- Reversible Seat
- Height Adjustable Push Handle
- Canopy
- Handrail (Guardrail)
- 3-Point Safety Belt
- Storage Baskets
- Mommy Pocket



Image: The Qaba Kids Tricycle in its full assembly, showcasing its grey and black design with a canopy and parent push handle.

4 IN 1 TRICYCLE FOR TODDLER

Suitable for
kids 1-5 years old



Toddler Bike Stroller



Baby Push Car



**Toddler Trike
with Push
Handle**



Kids Tricycle

Image: Visual representation of the tricycle transforming into its four modes: Baby Push Car, Toddler Trike with Push Handle, Toddler Bike Stroller, and Kids Tricycle, suitable for ages 1-5 years.

SECURE & REVERSIBLE SEAT



Parent-Child Mode

Face-to-Face Mode



Removable
Guardrail



3-Point
Safety Belt

Image: Illustration demonstrating the reversible seat function for Parent-Child Mode and Face-to-Face Mode, along with close-ups of the removable guardrail and 3-point safety belt.

REMOVABLE PARENT PUSH HANDLE

- 3-gear adjustable height



Image: A person adjusting the 3-gear height-adjustable parent push handle, showing the different height settings (40.25" and 36.25").

STEPLESSLY ADJUSTABLE CANOPY



Also removable



Image: A person adjusting the steplessly adjustable canopy, highlighting its removable feature for sun protection.



Image: Diagram showing the overall dimensions of the tricycle: 44" length, 20.5" width, and 38.5" height.



Storage Baskets



Mommy Pocket



Clutch



Fully-closed
EVA Wheels

**MORE
DETAILS**



Foldable
footrest

Image: Close-up views of additional features including the "Mommy Pocket", storage baskets, front wheel clutch, fully-closed EVA wheels, and foldable footrest.

3. SETUP

The Qaba Kids Tricycle is designed for easy assembly without the need for special tools. Follow these general steps to set up your tricycle:

- 1. Unpack Components:** Carefully remove all parts from the packaging and verify against the included parts list (if available in physical manual).
- 2. Unfold Frame:** Unfold the main tricycle frame until it locks securely into place.
- 3. Attach Wheels:** Ensure wheels are securely attached. The fully-closed EVA wheels are designed for durability.
- 4. Install Seat:** Attach the reversible seat to the frame. Ensure it clicks into position for both forward and backward facing orientations.

5. **Connect Parent Handle:** Insert the height-adjustable parent push handle into its designated slot at the rear of the tricycle. Adjust to a comfortable height and secure.
6. **Attach Canopy:** Secure the removable canopy to the seat unit.
7. **Install Guardrail:** Attach the removable guardrail around the seat. Ensure it latches securely.
8. **Final Checks:** Before first use, double-check all connections, bolts, and latches to ensure they are tight and secure. Test the brakes and the front wheel clutch.



Image: Close-ups illustrating the easy assembly and folding mechanisms of the tricycle, indicating tool-free setup.

4. OPERATING INSTRUCTIONS

4.1. Adjusting Modes (4-in-1 Functionality)

The tricycle can be configured to suit your child's age and development stage:

- **Baby Push Car (12-18 months):** Use with parent handle, canopy, guardrail, and footrest. Child is secured by

the safety belt.

- **Toddler Trike with Push Handle (18-36 months):** Remove guardrail, child can begin to pedal while parent steers with the handle.
- **Toddler Bike Stroller (2-3 years):** Similar to push trike, but child has more control over steering.
- **Kids Tricycle (3-5 years):** Remove parent handle and canopy. Child pedals and steers independently.

4.2. Seat Reversal

To reverse the seat direction, locate the release mechanism (usually a button or lever) beneath the seat. Press or pull the mechanism, lift the seat, rotate it 180 degrees, and re-attach until it locks securely in the desired orientation (forward-facing or parent-facing).

4.3. Parent Handle Adjustment

To adjust the height of the parent push handle, locate the adjustment buttons or levers on the handle's shaft. Press or release them, slide the handle to one of the three desired height settings, and ensure it locks into place before use.

4.4. Canopy Adjustment and Removal

The canopy can be adjusted to provide optimal shade by pushing or pulling it along its pivot points. To remove the canopy, locate the attachment points and detach it from the seat unit.

4.5. Using Brakes and Clutch

- **Rear Wheel Brakes:** Push down the levers located near the rear wheels to engage the brakes for parking. Lift them up to release.
- **Front Wheel Clutch:** The front wheel features a clutch mechanism. Engage the clutch to allow the parent to control the steering without the child's pedals rotating. Disengage it when the child is ready to pedal independently.

4.6. Folding for Storage/Transport

To fold the tricycle, identify the folding mechanisms (often red buttons or levers) on the frame. Follow the specific folding sequence outlined in the detailed product manual (not provided here, but generally involves collapsing the frame, handlebars, and footrests). Ensure all parts are securely folded before lifting or storing.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your Qaba Kids Tricycle.

- **Cleaning:** Wipe down plastic and metal parts with a damp cloth and mild soap. The seat fabric is skin-friendly and durable, but non-detachable for washing. Spot clean as needed. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Before each use, inspect the tricycle for:
 - Loose bolts, nuts, or screws. Tighten as necessary.
 - Cracks or damage to plastic components, especially the seat, frame, and wheels.
 - Wear and tear on the safety harness, buckles, and guardrail.
 - Proper functioning of brakes and the front wheel clutch.
 - Obstructions in the wheels or moving parts.
- **Lubrication:** Periodically apply a small amount of silicone-based lubricant to moving parts like wheel axles

and folding mechanisms to ensure smooth operation.

- **Storage:** Store the tricycle in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation. If storing outdoors, use a protective cover.

6. TROUBLESHOOTING

If you encounter issues with your Qaba Kids Tricycle, consider the following common solutions:

- **Difficulty Folding/Unfolding:** Ensure all locking mechanisms are disengaged. Check for any obstructions or misaligned parts. Apply a small amount of lubricant to hinges if stiff.
- **Wobbly or Loose Parts:** Re-check all bolts, nuts, and screws. Tighten any that are loose. Ensure all components are fully inserted and locked into their respective positions.
- **Brakes Not Engaging/Releasing Properly:** Inspect the brake mechanism for debris or wear. Ensure the brake levers are fully depressed or released.
- **Wheels Not Turning Smoothly:** Check for debris wrapped around the axles. Ensure wheels are properly attached and not rubbing against the frame.
- **Seat Not Reversing:** Ensure the seat release mechanism is fully activated. Check for any obstructions preventing rotation or locking.

If the problem persists after attempting these solutions, please contact Qaba customer support for further assistance.

7. SPECIFICATIONS

Product Dimensions	44" L x 20.5" W x 38.5" H
Item Weight	17.6 lbs
Model Number	370-198GY
ASIN	B09N33YRRD
Recommended Age	12 months - 5 years
Maximum Weight Capacity	55 lbs (25 kg)
Manufacturer	Aosom LLC
Material	Metal frame, plastic components, EVA wheels, fabric seat

8. WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the documentation included with your purchase or visit

the official Qaba website. Warranty terms and conditions may vary.

If you require technical support, have questions about assembly, or need replacement parts, please contact Qaba customer service. Contact details can typically be found on the product packaging or the manufacturer's website.

Qaba Official Website: www.aosom.com/qaba

© 2024 Qaba. All rights reserved.