

[manuals.plus](#) /

› [BarcaLounger](#) /
› [BarcaLounger Mission 7-3323 Manual Recliner Chair User Manual](#)

BarcaLounger BarcaMissionShoreBlue

BarcaLounger Mission 7-3323 Manual Recliner Chair User Manual

Model: BarcaMissionShoreBlue

1. INTRODUCTION

Thank you for choosing the BarcaLounger Mission 7-3323 Manual Recliner Chair. This manual provides essential information for the safe and effective use, maintenance, and care of your new recliner. Please read it thoroughly before use and retain it for future reference.



Image 1.1: The Barcalounger Mission 7-3323 Manual Recliner Chair in Shoreham Blue Leather, showcasing its classic craftsman styling and comfortable design.

2. IMPORTANT SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage to the product:

- Do not exceed the maximum weight capacity of 285 pounds.
- Ensure at least 16.2 inches of wall proximity for safe reclining operation.
- Keep children and pets away from the reclining mechanism.
- Avoid placing fingers or hands near moving parts of the mechanism.
- Handle with care due to the chair's weight of 100 pounds during relocation.

3. PARTS LIST

The Barcalounger Mission 7-3323 Manual Recliner Chair is delivered fully assembled. No separate parts require assembly.

4. SETUP AND PLACEMENT

Your recliner arrives pre-assembled and ready for use. Follow these steps for optimal placement:

1. Carefully remove the chair from its packaging.
2. Place the chair in your desired location, ensuring there is at least 16.2 inches of clear space behind the chair to allow for full recline without obstruction.
3. Verify the chair is stable on a level surface before use.



Image 4.1: Product dimensions showing the chair's width (32.7"), depth (37.5"), and height (42").

5. OPERATING INSTRUCTIONS

The BarcaLounger Mission 7-3323 is a manual push-back recliner. It features a Leggett & Platt mechanism designed for smooth operation.

To Recline:

1. Sit comfortably in the chair.

2. Apply gentle pressure to the backrest by leaning back. The mechanism requires approximately 2.5 lbs of pressure to activate.
3. Continue to lean back to achieve your desired reclining position. The footrest will elevate as you recline.

To Return to Upright Position:

1. Lean forward and gently push the footrest down with your legs.
2. The chair will return to its upright, seated position.



Image 5.1: The recliner shown in a partially reclined state, demonstrating the extended footrest.

6. MAINTENANCE AND CARE

Leather Care:

- Regularly dust the leather with a soft, dry cloth.
- For spills, blot immediately with a clean, absorbent cloth. Do not rub.
- Avoid direct sunlight and heat sources to prevent fading and drying of the leather.
- Use a reputable leather cleaner and conditioner specifically designed for genuine leather, following

the product's instructions. Test on an inconspicuous area first.

Wood Frame Care:

- Wipe the mahogany wood finish with a soft, damp cloth. Dry immediately.
- Avoid using abrasive cleaners or polishes that may damage the finish.
- Protect the wood from excessive moisture and extreme temperature changes.

Mechanism Care:

- The Leggett & Platt mechanism features delrin bushings to ensure seamless motion and prevent squeaking. No lubrication is typically required.
- Mechanisms are attached to the frame with bolts and t-nuts to increase stability and durability. Avoid attempting to tighten or adjust these unless instructed by a qualified technician.

7. TROUBLESHOOTING

- **Chair does not recline smoothly:** Ensure no objects are obstructing the mechanism or the space behind the chair. Apply consistent, gentle pressure to the backrest.
- **Squeaking noise:** The Leggett & Platt mechanism is designed to be silent. If squeaking occurs, inspect for any loose connections or foreign objects. Contact customer support if the issue persists.
- **Footrest does not retract:** Ensure you are leaning forward and applying sufficient pressure to the footrest with your legs. Check for obstructions.

8. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	BarcaLounger
Model Number	BarcaMissionShoreBlue
Product Dimensions (D x W x H)	37.5"D x 32.7"W x 42"H
Seat Depth	19 inches
Item Weight	100 pounds
Maximum Weight Recommendation	285 Pounds
Material	Genuine All Leather, Mahogany Wood Finish
Reclining Mechanism	Leggett & Platt Push Back Manual
Wall Proximity for Recline	16.2 inches

9. WARRANTY AND CUSTOMER SUPPORT

Warranty Information:

The BarcaLounger Mission 7-3323 Manual Recliner Chair comes with a **BarcaLounger Factory One Year Warranty**. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

Customer Support:

For further assistance, troubleshooting, or warranty inquiries, please visit the official BarcaLounger store or contact their customer service department. You can find more information and contact details on the [BarcaLounger Store on Amazon](#).